

Naval Research Laboratory

Stennis Space Center, MS 39529-5004



NRL/MR/7432--97-8041

Continuously Logged Sediment Acoustical and Physical Properties Data, R/V Haakon Mosby Cores, Norwegian/Greenland Sea

WILLIAM B. SAWYER
FREDERICK A. BOWLES

*Seafloor Sciences Branch
Marine Geosciences Division*

EIRIK SUNDVOR

*Institute of Solid Earth Geophysics
University of Bergen
Bergen, Norway*

LISA PHELPS

*Institute of Marine Sciences
University of Southern Mississippi
Hattiesburg, MS*

WILLIAM R. BRYANT

*Department of Oceanography
Texas A&M University
College Station, TX*

PETER R. VOGT
KATHLEEN CRANE
JOAN GARDNER

*Marine Physics Branch
Marine Geosciences Division*

19970609 135

April 18, 1997

JOINT QUALITY INSPECTED &

Approved for public release; distribution unlimited.

REPORT DOCUMENTATION PAGE

Form Approved
OBM No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

| | | | | | |
|---|---|--|-----------------------------------|--|--|
| 1. AGENCY USE ONLY (Leave blank) | | 2. REPORT DATE April 18, 1997 | | 3. REPORT TYPE AND DATES COVERED Final | |
| 4. TITLE AND SUBTITLE Continuously Logged Sediment Acoustical and Physical Properties Data, R/V Haakon Mosby Cores, Norwegian/Greenland Sea | | | | 5. FUNDING NUMBERS Job Order No. 574-6630-00 Program Element No. 0602435N Project No. Task No. BE-35-2-02 Accession No. | |
| 6. AUTHOR(S) William B. Sawyer, Frederick A. Bowles, Lisa Phelps*, Peter R. Vogt, Kathleen Crane, Joan Gardner, Eirik Sundvor†, and William R. Bryant†† | | | | | |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) Naval Research Laboratory Marine Geosciences Division Stennis Space Center, MS 39529-5004 | | | | 8. PERFORMING ORGANIZATION REPORT NUMBER NRL/MR/7432--97-8041 | |
| 9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) Office of Naval Research 800 North Quincy Street Arlington, VA 22217-5000 | | | | 10. SPONSORING/MONITORING AGENCY REPORT NUMBER | |
| 11. SUPPLEMENTARY NOTES *Institute of Marine Sciences, University of Southern Mississippi, Hattiesburg, MS; †Institute of Solid Earth Geophysics, University of Bergen, Bergen, Norway; ††Department of Oceanography, Texas A&M University, College Station, TX | | | | | |
| 12a. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release; distribution unlimited. | | | | 12b. DISTRIBUTION CODE | |
| 13. ABSTRACT (Maximum 200 words) Sediment cores were collected in the Greenland/Norwegian Sea for the purpose of ground-truthing previously collected sidescan imagery. This report presents the results of shore-based analyses performed on the cores. Interpretive results are not included. The unopened cores were continuously logged at 2-cm intervals for compressional-wave velocity and gamma-ray attenuation. Wet bulk density, porosity, water content, and void ratio were calculated from the attenuation measurements. Analytical results are presented in the form of spreadsheets and graphs. | | | | | |
| 14. SUBJECT TERMS acoustics, marine geology, active sonar, ASW, MCM | | | | 15. NUMBER OF PAGES 165 | |
| | | | | 16. PRICE CODE | |
| 17. SECURITY CLASSIFICATION OF REPORT Unclassified | 18. SECURITY CLASSIFICATION OF THIS PAGE Unclassified | 19. SECURITY CLASSIFICATION OF ABSTRACT Unclassified | 20. LIMITATION OF ABSTRACT SAR | | |

Continuously-Logged, Sediment Acoustical and physical Properties data, R/V Haakon Mosby Cores, Norwegian/Greenland Sea

Background:

The Naval Research Laboratory (NRL), in cooperation with the University of Bergen (Norway), embarked on a long-term geological/geophysical study of Greenland/Norwegian seafloor processes. In August/September 1995, a joint cruise, partially funded by the U. S. Naval Oceanographic Office, was conducted in the area to "ground-truth" and age-date selected features previously discovered by sidescan imaging. Core analyses were performed in order to address questions of scientific interest. This report is a compilation of these analyses; it does not include interpretative results.

Core Recovery and Handling:

Forty-eight hydroplastic gravity cores were collected at 43 stations (Table 1 and Figure 1), with a recovery of over 100 linear meters of sediment. The core pipe was approximately 5-in diameter (O.D.), PVC cut in 10 ft (3 m) lengths. Each core was cut into 1-m sections and sealed with plastic caps secured with metal hose-clamps. Plastic electrical tape was then wrapped around the cap and clamp to prevent loss of water. The cores were maintained in an upright position until being laid horizontally on the deck for sectioning. Each section was then stored upright for the duration of the cruise. Subsequently, the cores were boxed (upright) and air freighted to NRL for analyses.

Analytical Method:

All the cores but one (HM-76 was not logged) were analyzed at 2 cm intervals for sediment physical and acoustical properties; specifically, compressional-wave (P-wave) velocity, saturated wet bulk density, porosity, water content, and void ratio. The instrument used for these determinations was Texas A&M University's GEOTEK Multisensor Core Logger, a logging device providing continuous measurements of compressional-wave velocity (p-wave), gamma-ray attenuation, and magnetic susceptibility on unopened cores. The cores were logged for p-wave velocity at 500 kHz (Schultheiss and

McPhail, 1989). The p-wave transducers were calibrated to distilled water to 20°C. The gamma-ray attenuations, obtained with a ^{137}Cs source and scintillation tube, were used to determine saturated wet bulk densities (Boyce, 1976; Weber et al., 1997) which, in turn, were used to derive the other parameters, i.e., porosity, water content, and void ratio. The magnetic susceptibility portion of the logger was not operational. As noted above, each core pipe was cut into three 1-meter long sections. Although this size is convenient for shipping, the main reason is that the logger can accommodate core lengths of only 1 meter.

Data Processing:

The raw velocity and attenuation measurements were processed via a program developed by Jia Y. Liu (Texas A&M University) that reads in logger-generated PC file to produce final parameter outputs (see Appendix). In order to make the calculations, a grain density of 2.67 g/cm^3 and a pore-water density of 1.024 g/cm^3 were assumed. In addition, the gamma-ray portion of the logger must be calibrated by measuring a material of known density, in this case, a cylinder of aluminum alloy 6060-T6, 2.71 g/cm^3 .

Data Output:

The sediment analyses are presented as: (1) spreadsheets, and (2) profiles showing the downcore variation of each property. Data gaps are readily apparent in both formats, but especially in the velocity profiles. The gaps usually occur at the tops and bottoms of each 1-meter section because of poor coupling between the acoustic transducer and the plastic end-caps. Additional data gaps within sections may be caused by either (1) poor coupling between the transducer and the core pipe, (2) air between the core pipe and the sediment inside, or (3) no sediment. It is also apparent that the uppermost few centimeters of the first section of each core (e.g., 0-5 cm, and sometimes as much as 0-20 cm), is usually unlogged. Failure to log the upper part is due to the soupy nature (i.e., low strength) of the most recently deposited sediment, resulting in; (1) a void caused by sediment compaction, and (2) flow of the sediment when the core is laid on its side for logging; thus, allowing air to get between the sediment and the liner.

Continuing Study:

Select cores are being opened for additional analysis in the laboratory. The applied goals of these studies are (a) to understand, and better exploit, the qualitative and quantitative relation between bottom/ subbottom physical/geoacoustic properties and the backscatter strength variations implied by existing seaMARC and SEAMAP data, and (b) to measure or estimate the stability (e.g., shear strength) of the seafloor materials. A suite of cores (HM41-65) taken on the Bear Island submarine fan (Vogt et al., 1993) are presently being studied. Analytical results will be presented at a special session (High-Latitude Gas Venting, Hydrates, and Mass Wasting) of the American Geophysical Union (AGU) Spring Meeting in Baltimore, Maryland (1997). In addition to the problem of marine hydrates, other presented papers will deal with geoacoustic and rheological properties of the mudflows and surrounding hemipelagic sediments, sediment mineralogy, sediment fabric, and correlations between acoustic backscatter imagery and sediment core ground-truthing.

Acknowledgments:

We thank: L. Polyak, C. Jones, E. Mcphee, and A. Nilsen (members of the scientific team), for collecting many of the the cores; the Captain, officers, and crew of the R/V Haakon Mosby; N. Slowey (Texas A&M) for assistance with the core logger, and C. Kennedy (NRL) for machining the aluminum standard and other support. Sediment analyses were supported by the Office of Naval Research through the Naval Research Laboratory-sponsored Bottom Interaction Project, Program Element 0602435N, Project Number BE-35-2-02.

References:

- Boyce, R. E., 1976. Definitions and laboratory techniques of compressional sound velocity parameters and wet-water content, wet-bulk density, and porosity parameters by gravimetric and gamma-ray attenuation techniques. In: S. O. Schlanger, E. Jackson et al. (Editors), Init. Rep. DSDP, 33, 931-958.
- Schultheiss, P. J. and McPhail, S. D., 1989. An automated p-wave logger for recording fine scale compressional wave velocity

structures in sediments. In: W. Ruddiman, M. Sarnthein et al. (Editors), Proc. ODP Sci. Results, 108: 407-413.

Vogt, P. R., Crane, K., and Sundvor, E., 1993). Glacigenic mudflows on the Bear Island submarine fan. Eos., Trans. Am. Geophys. Union, 74, 449/452-452.

Weber, M. E., Niessen, F., Kuhn, G. and Wiedicke M., 1997. Calibration and application of marine sedimentary physical properties using a multi-sensor core logger. Mar. Geol., 136, 151-172.

Table 1. Locations (in tenths of degrees) of R/V Haakon Mosby gravity cores. Missing numbers represent box core (7), current meter (1), dredge (1), and heat flow (22) stations. In addition, no sediment was recovered at seven gravity core stations.

| core | Longitude East (°) | Latitude North (°) | Corrected Depth (m) |
|-------|-----------------------|-----------------------|------------------------|
| HM 3 | 7.954 | 80.068 | 500 |
| HM 4 | 7.000 | 79.750 | 854 |
| HM 5 | 6.521 | 79.190 | 1465 |
| HM 9 | 7.969 | 80.043 | 507 |
| HM 11 | 6.136 | 79.111 | 1237 |
| HM 12 | 5.198 | 79.142 | 1349 |
| HM 16 | 5.195 | 79.138 | 1346 |
| HM 17 | 7.076 | 77.341 | 2054 |
| HM 19 | 10.425 | 75.725 | 2317 |
| HM 29 | 14.601 | 74.848 | 1605 |
| HM 31 | 14.673 | 74.841 | 1536 |
| HM 32 | 11.441 | 74.648 | 2402 |
| HM 34 | 11.493 | 74.626 | 2362 |
| HM 36 | 12.238 | 74.407 | 2264 |
| HM 37 | 12.337 | 74.365 | 2229 |
| HM 38 | 12.573 | 74.365 | 2213 |
| HM 40 | 12.728 | 74.395 | 2204 |
| HM 41 | 9.331 | 73.899 | 2476 |
| HM 43 | 9.265 | 73.845 | 2455 |
| HM 44 | 9.240 | 73.766 | 2424 |
| HM 46 | 10.193 | 73.656 | 2260 |
| HM 48 | 8.875 | 73.512 | 2459 |
| HM 49 | 9.431 | 73.197 | 2300 |
| HM 50 | 9.618 | 73.135 | 2254 |
| HM 51 | 9.748 | 73.187 | |
| HM 52 | 9.901 | 73.061 | 2201 |
| HM 53 | 10.082 | 73.007 | 2167 |
| HM 54 | 8.780 | 73.013 | 2359 |
| HM 56 | 8.593 | 73.012 | 2386 |
| HM 58 | 11.928 | 73.021 | 1762 |
| HM 59 | 11.920 | 73.075 | 1764 |
| HM 60 | 13.765 | 73.208 | 1193 |
| HM 63 | 13.753 | 73.371 | 1253 |
| HM 64 | 15.958 | 73.257 | 478 |
| HM 65 | 15.833 | 73.083 | 470 |
| HM 68 | 14.567 | 72.035 | 1261 |
| HM 69 | 14.577 | 72.036 | 1269 |
| HM 72 | 14.728 | 72.008 | 1255 |
| HM 73 | 14.662 | 71.947 | 1302 |
| HM 74 | 14.652 | 71.929 | 1314 |
| HM 75 | 14.778 | 71.919 | 1245 |
| HM 77 | 14.417 | 71.917 | 1419 |
| HM 78 | 14.233 | 71.900 | 1521 |
| HM 80 | 14.067 | 71.940 | 1506 |
| HM 81 | 13.790 | 72.017 | 1416 |
| HM 86 | 15.692 | 72.049 | 684 |
| HM 87 | 15.145 | 70.477 | 2310 |



FIG. 1

HM 3

HM 3

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 0 | | | | | | 60 | 1.84 | 39.00 | 1.02 | 50.42 | 1536 |
| 2 | | | | | | 62 | 1.82 | 40.96 | 1.07 | 51.65 | 1532 |
| 4 | | | | | | 64 | 1.86 | 37.51 | 0.98 | 49.44 | 1548 |
| 6 | | | | | | 66 | 1.80 | 42.92 | 1.12 | 52.81 | 1531 |
| 8 | | | | | | 68 | 1.78 | 45.21 | 1.18 | 54.11 | 1523 |
| 10 | | | | | | 70 | 1.79 | 44.27 | 1.15 | 53.58 | 1520 |
| 12 | 1.77 | 46.20 | 1.20 | 54.64 | | 72 | 1.80 | 43.44 | 1.13 | 53.11 | 1530 |
| 14 | 1.82 | 40.49 | 1.06 | 51.36 | | 74 | 1.81 | 42.33 | 1.10 | 52.47 | 1535 |
| 16 | 1.87 | 36.23 | 0.94 | 48.57 | | 76 | 1.79 | 43.89 | 1.14 | 53.37 | 1527 |
| 18 | 1.93 | 31.39 | 0.82 | 45.01 | 1569 | 78 | 1.89 | 34.86 | 0.91 | 47.61 | |
| 20 | 1.94 | 30.46 | 0.79 | 44.27 | 1584 | 80 | 1.78 | 44.61 | 1.16 | 53.77 | 1525 |
| 22 | 1.92 | 32.28 | 0.84 | 45.70 | 1582 | 82 | 1.76 | 47.30 | 1.23 | 55.22 | 1519 |
| 24 | 1.88 | 35.69 | 0.93 | 48.20 | 1567 | 84 | 1.78 | 45.36 | 1.18 | 54.19 | 1519 |
| 26 | 1.86 | 37.50 | 0.98 | 49.44 | 1547 | 86 | 1.72 | 52.51 | 1.37 | 57.79 | 1510 |
| 28 | 1.87 | 36.51 | 0.95 | 48.77 | | 88 | 1.74 | 50.10 | 1.31 | 56.64 | 1513 |
| 30 | 1.83 | 40.36 | 1.05 | 51.27 | 1553 | 90 | 1.74 | 50.11 | 1.31 | 56.65 | 1513 |
| 32 | 1.73 | 50.47 | 1.32 | 56.82 | 1514 | 92 | 1.80 | 42.94 | 1.12 | 52.82 | 1517 |
| 34 | 1.71 | 53.08 | 1.38 | 58.05 | 1504 | 94 | 1.80 | 43.33 | 1.13 | 53.05 | |
| 36 | 1.66 | 61.23 | 1.60 | 61.49 | 1495 | 96 | 1.73 | 51.40 | 1.34 | 57.27 | |
| 38 | 1.66 | 61.42 | 1.60 | 61.56 | 1499 | 98 | 1.81 | 41.58 | 1.08 | 52.02 | 1549 |
| 40 | 1.81 | 42.22 | 1.10 | 52.40 | 1539 | 100 | | | | | 1554 |
| 42 | 1.71 | 53.15 | 1.39 | 58.09 | 1507 | 102 | | | | | |
| 44 | 1.73 | 51.31 | 1.34 | 57.23 | 1511 | 104 | | | | | |
| 46 | 1.75 | 48.53 | 1.27 | 55.86 | 1513 | 106 | | | | | |
| 48 | 1.73 | 50.66 | 1.32 | 56.91 | 1506 | 108 | 1.78 | 44.61 | 1.16 | 53.77 | |
| 50 | 1.74 | 49.51 | 1.29 | 56.35 | 1513 | 110 | 1.74 | 49.71 | 1.30 | 56.45 | |
| 52 | 1.77 | 45.79 | 1.19 | 54.42 | 1517 | 112 | 1.70 | 54.59 | 1.42 | 58.74 | |
| 54 | 1.79 | 43.91 | 1.14 | 53.38 | 1525 | 114 | 1.74 | 49.63 | 1.29 | 56.41 | |
| 56 | 1.80 | 42.62 | 1.11 | 52.64 | 1534 | 116 | 1.79 | 44.22 | 1.15 | 53.56 | |
| 58 | 1.81 | 41.92 | 1.09 | 52.22 | 1531 | 118 | 1.81 | 41.60 | 1.08 | 52.03 | |

HM 3

HM 3

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 120 | 1.82 | 41.42 | 1.08 | 51.92 | | 180 | 1.93 | 31.12 | 0.81 | 44.80 | 1572 |
| 122 | 1.81 | 42.29 | 1.10 | 52.44 | | 182 | 1.95 | 30.12 | 0.79 | 43.99 | 1574 |
| 124 | 1.81 | 41.49 | 1.08 | 51.97 | | 184 | 1.93 | 31.20 | 0.81 | 44.86 | 1570 |
| 126 | 1.79 | 44.37 | 1.16 | 53.64 | | 186 | 1.93 | 31.03 | 0.81 | 44.73 | 1568 |
| 128 | 1.78 | 45.31 | 1.18 | 54.16 | | 188 | 1.92 | 31.85 | 0.83 | 45.37 | 1567 |
| 130 | 1.82 | 41.28 | 1.08 | 51.84 | | 190 | 1.93 | 31.42 | 0.82 | 45.03 | 1569 |
| 132 | 1.85 | 38.52 | 1.00 | 50.11 | | 192 | 1.93 | 31.46 | 0.82 | 45.07 | 1569 |
| 134 | 1.96 | 29.35 | 0.77 | 43.35 | | 194 | 1.93 | 31.42 | 0.82 | 45.04 | 1566 |
| 136 | 1.95 | 29.56 | 0.77 | 43.53 | 1536 | 196 | 1.94 | 30.64 | 0.80 | 44.41 | 1570 |
| 138 | 1.87 | 36.23 | 0.94 | 48.58 | 1553 | 198 | 1.98 | 28.02 | 0.73 | 42.21 | 1584 |
| 140 | 1.90 | 34.00 | 0.89 | 46.99 | 1557 | 200 | 1.89 | 34.24 | 0.89 | 47.17 | 1601 |
| 142 | 1.89 | 34.84 | 0.91 | 47.60 | 1555 | 202 | 1.91 | 32.55 | 0.85 | 45.91 | 1605 |
| 144 | 1.93 | 31.53 | 0.82 | 45.12 | 1569 | 204 | | | | | 1612 |
| 146 | 1.95 | 29.52 | 0.77 | 43.50 | 1566 | | | | | | |
| 148 | 1.90 | 33.78 | 0.88 | 46.83 | 1564 | | | | | | |
| 150 | 1.95 | 29.81 | 0.78 | 43.73 | 1571 | | | | | | |
| 152 | 1.94 | 30.93 | 0.81 | 44.64 | 1566 | | | | | | |
| 154 | 1.93 | 30.96 | 0.81 | 44.67 | 1566 | | | | | | |
| 156 | 1.95 | 29.50 | 0.77 | 43.48 | 1571 | | | | | | |
| 158 | 1.96 | 29.43 | 0.77 | 43.42 | 1577 | | | | | | |
| 160 | 1.95 | 29.77 | 0.78 | 43.70 | 1572 | | | | | | |
| 162 | 1.96 | 28.85 | 0.75 | 42.93 | 1570 | | | | | | |
| 164 | 1.97 | 28.09 | 0.73 | 42.28 | 1567 | | | | | | |
| 166 | 1.93 | 31.61 | 0.82 | 45.18 | 1570 | | | | | | |
| 168 | 1.94 | 30.36 | 0.79 | 44.18 | 1571 | | | | | | |
| 170 | 1.94 | 30.50 | 0.80 | 44.30 | 1579 | | | | | | |
| 172 | 2.05 | 23.11 | 0.60 | 37.60 | | | | | | | |
| 174 | 2.00 | 26.34 | 0.69 | 40.71 | 1590 | | | | | | |
| 176 | 2.00 | 26.59 | 0.69 | 40.94 | 1591 | | | | | | |
| 178 | 1.94 | 30.84 | 0.80 | 44.58 | 1565 | | | | | | |

HM 4

HM 4

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.61 | 69.69 | 1.82 | 64.50 | |
| 2 | 1.49 | 96.32 | 2.51 | 71.52 | | 62 | 1.66 | 61.33 | 1.60 | 61.53 | 1482 |
| 4 | 1.68 | 58.46 | 1.52 | 60.38 | | 64 | 1.74 | 49.69 | 1.30 | 56.44 | 1540 |
| 6 | 1.80 | 43.26 | 1.13 | 53.01 | | 66 | | | | | |
| 8 | 1.82 | 41.31 | 1.08 | 51.85 | 1549 | 68 | 1.70 | 55.16 | 1.44 | 58.99 | |
| 10 | 1.78 | 45.57 | 1.19 | 54.30 | 1535 | 70 | 1.69 | 57.03 | 1.49 | 59.79 | |
| 12 | 1.77 | 46.44 | 1.21 | 54.77 | 1512 | 72 | 1.75 | 48.85 | 1.27 | 56.02 | |
| 14 | 1.64 | 63.55 | 1.66 | 62.36 | 1498 | 74 | 1.73 | 51.44 | 1.34 | 57.29 | |
| 16 | 1.61 | 68.52 | 1.79 | 64.12 | 1494 | 76 | 1.68 | 57.27 | 1.49 | 59.89 | |
| 18 | 1.62 | 66.99 | 1.75 | 63.59 | 1493 | 78 | 1.72 | 51.94 | 1.35 | 57.52 | |
| 20 | 1.59 | 72.48 | 1.89 | 65.40 | 1491 | 80 | 1.70 | 54.97 | 1.43 | 58.90 | |
| 22 | 1.62 | 67.22 | 1.75 | 63.67 | 1491 | 82 | 1.67 | 59.16 | 1.54 | 60.67 | |
| 24 | 1.63 | 64.98 | 1.69 | 62.89 | 1493 | 84 | 1.63 | 65.43 | 1.71 | 63.05 | 1498 |
| 26 | 1.63 | 65.49 | 1.71 | 63.07 | 1491 | 86 | 1.70 | 54.96 | 1.43 | 58.90 | 1498 |
| 28 | 1.66 | 61.48 | 1.60 | 61.58 | 1492 | 88 | 1.70 | 55.07 | 1.44 | 58.95 | 1500 |
| 30 | 1.66 | 60.52 | 1.58 | 61.21 | 1492 | 90 | 1.70 | 54.79 | 1.43 | 58.82 | 1499 |
| 32 | 1.65 | 62.63 | 1.63 | 62.02 | 1493 | 92 | 1.67 | 59.43 | 1.55 | 60.78 | 1493 |
| 34 | 1.65 | 61.85 | 1.61 | 61.73 | 1494 | 94 | 1.68 | 58.08 | 1.51 | 60.23 | 1494 |
| 36 | 1.63 | 66.30 | 1.73 | 63.35 | 1495 | 96 | 1.67 | 59.32 | 1.55 | 60.73 | 1495 |
| 38 | 1.66 | 60.28 | 1.57 | 61.11 | 1500 | 98 | 1.75 | 48.72 | 1.27 | 55.95 | |
| 40 | 1.70 | 55.36 | 1.44 | 59.07 | 1503 | 100 | 1.74 | 49.37 | 1.29 | 56.28 | |
| 42 | 1.72 | 52.07 | 1.36 | 57.59 | 1507 | 102 | 1.73 | 50.73 | 1.32 | 56.95 | 1501 |
| 44 | 1.70 | 55.30 | 1.44 | 59.05 | 1504 | 104 | 1.72 | 52.23 | 1.36 | 57.66 | 1502 |
| 46 | 1.67 | 59.23 | 1.54 | 60.70 | 1496 | 106 | 1.73 | 50.80 | 1.32 | 56.98 | 1503 |
| 48 | 1.68 | 58.62 | 1.53 | 60.45 | 1496 | 108 | 1.73 | 51.38 | 1.34 | 57.26 | 1503 |
| 50 | 1.65 | 61.83 | 1.61 | 61.72 | 1495 | 110 | 1.75 | 48.39 | 1.26 | 55.78 | 1510 |
| 52 | 1.64 | 64.42 | 1.68 | 62.68 | 1490 | 112 | 1.76 | 47.74 | 1.24 | 55.45 | 1509 |
| 54 | 1.61 | 69.00 | 1.80 | 64.27 | 1488 | 114 | 1.71 | 53.02 | 1.38 | 58.03 | 1503 |
| 56 | 1.65 | 62.21 | 1.62 | 61.86 | 1492 | 116 | 1.73 | 51.65 | 1.35 | 57.39 | 1502 |
| 58 | 1.68 | 57.54 | 1.50 | 60.01 | 1496 | 118 | 1.74 | 50.03 | 1.30 | 56.61 | 1505 |
| | | | | | | 120 | 1.74 | 49.20 | 1.28 | 56.20 | 1509 |

HM 4

HM 4

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.74 | 49.32 | 1.29 | 56.25 | 1513 | 184 | 1.77 | 46.61 | 1.22 | 54.86 | 1462 |
| 124 | 1.86 | 37.59 | 0.98 | 49.50 | 1516 | 186 | 1.79 | 43.86 | 1.14 | 53.35 | 1422 |
| 126 | 1.87 | 36.11 | 0.94 | 48.50 | 1538 | 188 | 1.83 | 40.24 | 1.05 | 51.20 | 1470 |
| 128 | 1.88 | 35.40 | 0.92 | 48.00 | 1551 | 190 | 1.80 | 43.44 | 1.13 | 53.11 | 1425 |
| 130 | 1.99 | 26.74 | 0.70 | 41.08 | 1589 | 192 | 1.85 | 38.03 | 0.99 | 49.79 | 1506 |
| 132 | 1.98 | 27.65 | 0.72 | 41.90 | 1589 | 194 | 1.80 | 43.47 | 1.13 | 53.13 | 1509 |
| 134 | 1.99 | 27.11 | 0.71 | 41.42 | 1585 | 196 | 1.72 | 51.87 | 1.35 | 57.49 | 1497 |
| 136 | 1.94 | 30.50 | 0.80 | 44.30 | 1566 | 198 | 1.69 | 55.98 | 1.46 | 59.34 | 1493 |
| 138 | 1.99 | 27.18 | 0.71 | 41.48 | 1583 | 200 | 1.69 | 56.91 | 1.48 | 59.74 | 1472 |
| 140 | 1.95 | 29.54 | 0.77 | 43.51 | 1573 | 202 | 1.78 | 44.90 | 1.17 | 53.93 | 1509 |
| 142 | 1.96 | 28.95 | 0.75 | 43.01 | 1583 | 204 | 1.76 | 47.80 | 1.25 | 55.48 | 1508 |
| 144 | 2.01 | 25.84 | 0.67 | 40.26 | 1584 | 206 | 1.72 | 52.08 | 1.36 | 57.59 | 1502 |
| 146 | 1.95 | 29.88 | 0.78 | 43.79 | 1568 | 208 | 1.75 | 48.16 | 1.26 | 55.67 | 1502 |
| 148 | 1.97 | 28.10 | 0.73 | 42.29 | 1579 | 210 | 1.74 | 49.34 | 1.29 | 56.27 | 1495 |
| 150 | 1.96 | 29.03 | 0.76 | 43.09 | 1562 | 212 | 1.81 | 42.08 | 1.10 | 52.32 | 1527 |
| 152 | 1.97 | 28.18 | 0.73 | 42.36 | 1563 | 214 | 1.84 | 39.43 | 1.03 | 50.69 | 1531 |
| 154 | 1.87 | 36.65 | 0.96 | 48.86 | 1539 | 216 | 1.85 | 37.96 | 0.99 | 49.74 | 1524 |
| 156 | 2.00 | 26.51 | 0.69 | 40.87 | 1549 | 218 | 1.83 | 39.61 | 1.03 | 50.81 | 1527 |
| 158 | 1.98 | 27.86 | 0.73 | 42.08 | 1547 | 220 | 1.74 | 49.25 | 1.28 | 56.22 | 1482 |
| 160 | 1.84 | 39.02 | 1.02 | 50.43 | | 222 | 1.73 | 50.97 | 1.33 | 57.06 | 1502 |
| 162 | 1.97 | 28.50 | 0.74 | 42.63 | 1559 | 224 | 1.68 | 58.34 | 1.52 | 60.34 | |
| 164 | 1.98 | 27.57 | 0.72 | 41.82 | | 226 | 1.70 | 55.69 | 1.45 | 59.22 | 1491 |
| 166 | | | | | | 228 | 1.51 | 92.24 | 2.40 | 70.63 | |
| 168 | 1.70 | 55.15 | 1.44 | 58.98 | | | | | | | |
| 170 | 1.71 | 53.39 | 1.39 | 58.20 | | | | | | | |
| 172 | 1.77 | 45.72 | 1.19 | 54.38 | | | | | | | |
| 174 | 1.75 | 48.79 | 1.27 | 55.99 | | | | | | | |
| 176 | 1.77 | 46.61 | 1.22 | 54.86 | | | | | | | |
| 178 | 1.78 | 44.85 | 1.17 | 53.91 | | | | | | | |
| 180 | 1.76 | 47.48 | 1.24 | 55.32 | | | | | | | |
| 182 | 1.77 | 46.18 | 1.20 | 54.63 | | | | | | | |

HM 5

HM 5

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 64 | 1.51 | 92.31 | 2.41 | 70.65 | 1485 |
| 2 | | | | | | 66 | 1.52 | 87.69 | 2.29 | 69.57 | 1483 |
| 4 | | | | | | 68 | 1.50 | 94.04 | 2.45 | 71.03 | 1481 |
| 6 | 1.46 | 107.69 | 2.81 | 73.74 | | 70 | 1.51 | 92.09 | 2.40 | 70.60 | 1482 |
| 8 | 1.53 | 85.72 | 2.24 | 69.09 | | 72 | 1.50 | 94.97 | 2.48 | 71.23 | 1481 |
| 10 | 1.52 | 89.37 | 2.33 | 69.97 | | 74 | 1.51 | 90.42 | 2.36 | 70.22 | 1483 |
| 12 | 1.53 | 85.35 | 2.23 | 69.00 | | 76 | 1.52 | 89.73 | 2.34 | 70.06 | 1481 |
| 14 | 1.50 | 92.98 | 2.42 | 70.80 | | 78 | 1.53 | 86.17 | 2.25 | 69.20 | 1483 |
| 16 | 1.53 | 86.27 | 2.25 | 69.22 | 1487 | 80 | 1.51 | 91.78 | 2.39 | 70.53 | 1481 |
| 18 | 1.53 | 85.44 | 2.23 | 69.02 | 1485 | 82 | 1.51 | 91.61 | 2.39 | 70.49 | 1481 |
| 20 | 1.53 | 86.71 | 2.26 | 69.33 | 1486 | 84 | 1.51 | 91.32 | 2.38 | 70.42 | 1482 |
| 22 | 1.52 | 89.62 | 2.34 | 70.03 | 1487 | 86 | 1.52 | 89.97 | 2.35 | 70.11 | 1482 |
| 24 | 1.53 | 86.91 | 2.27 | 69.38 | 1487 | 88 | 1.53 | 86.38 | 2.25 | 69.25 | 1483 |
| 26 | 1.55 | 82.72 | 2.16 | 68.32 | 1487 | 90 | 1.55 | 82.20 | 2.14 | 68.19 | 1484 |
| 28 | 1.53 | 86.66 | 2.26 | 69.32 | 1484 | 92 | 1.55 | 81.60 | 2.13 | 68.03 | 1487 |
| 30 | 1.53 | 87.65 | 2.29 | 69.56 | 1483 | 94 | 1.57 | 78.23 | 2.04 | 67.10 | 1489 |
| 32 | 1.51 | 92.85 | 2.42 | 70.77 | 1484 | 96 | 1.49 | 96.09 | 2.51 | 71.47 | 1509 |
| 34 | 1.51 | 90.71 | 2.37 | 70.28 | 1483 | 98 | 1.55 | 81.61 | 2.13 | 68.03 | 1507 |
| 36 | 1.54 | 82.85 | 2.16 | 68.36 | 1484 | 100 | 1.55 | 81.41 | 2.12 | 67.98 | |
| 38 | 1.57 | 78.10 | 2.04 | 67.07 | 1487 | 102 | 1.43 | 115.54 | 3.01 | 75.08 | |
| 40 | 1.55 | 80.57 | 2.10 | 67.75 | 1486 | 104 | 1.42 | 121.58 | 3.17 | 76.02 | |
| 42 | 1.55 | 81.86 | 2.13 | 68.10 | 1485 | 106 | 1.50 | 94.79 | 2.47 | 71.19 | |
| 44 | 1.53 | 85.35 | 2.23 | 69.00 | 1484 | 108 | 1.54 | 83.59 | 2.18 | 68.55 | |
| 46 | 1.55 | 82.42 | 2.15 | 68.24 | 1481 | 110 | 1.46 | 104.96 | 2.74 | 73.24 | |
| 48 | 1.52 | 90.11 | 2.35 | 70.15 | 1480 | 112 | 1.48 | 100.36 | 2.62 | 72.35 | |
| 50 | 1.52 | 88.13 | 2.30 | 69.68 | 1481 | 114 | 1.52 | 89.22 | 2.33 | 69.94 | |
| 52 | 1.52 | 88.64 | 2.31 | 69.80 | 1482 | 116 | 1.54 | 83.73 | 2.18 | 68.58 | |
| 54 | 1.53 | 86.60 | 2.26 | 69.31 | 1481 | 118 | 1.54 | 83.62 | 2.18 | 68.56 | |
| 56 | 1.54 | 83.61 | 2.18 | 68.55 | 1482 | 120 | 1.60 | 71.57 | 1.87 | 65.11 | |
| 58 | 1.55 | 82.03 | 2.14 | 68.14 | 1482 | 122 | 1.56 | 80.25 | 2.09 | 67.66 | |
| 60 | 1.51 | 90.47 | 2.36 | 70.23 | 1481 | 124 | 1.54 | 83.04 | 2.17 | 68.41 | |
| 62 | 1.52 | 90.16 | 2.35 | 70.16 | 1481 | 126 | 1.57 | 78.15 | 2.04 | 67.08 | |

HM 5

HM 5

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 130 | 1.61 | 69.82 | 1.82 | 64.55 | | 196 | 1.69 | 56.59 | 1.48 | 59.61 | 1534 |
| 132 | 1.59 | 73.14 | 1.91 | 65.60 | | 198 | 1.73 | 50.54 | 1.32 | 56.85 | 1533 |
| 134 | 1.60 | 71.80 | 1.87 | 65.18 | | 200 | | | | | 1551 |
| 136 | 1.64 | 64.29 | 1.68 | 62.64 | | 202 | | | | | |
| 138 | 1.60 | 70.52 | 1.84 | 64.77 | | 204 | 1.66 | 61.66 | 1.61 | 61.65 | |
| 140 | 1.60 | 72.13 | 1.88 | 65.29 | | 206 | 1.69 | 56.49 | 1.47 | 59.56 | |
| 142 | 1.68 | 58.13 | 1.52 | 60.25 | | 208 | 1.73 | 51.20 | 1.34 | 57.18 | |
| 144 | 1.68 | 58.47 | 1.52 | 60.39 | 1492 | 210 | 1.73 | 50.45 | 1.32 | 56.81 | |
| 146 | 1.68 | 58.56 | 1.53 | 60.43 | 1494 | 212 | 1.79 | 43.68 | 1.14 | 53.25 | |
| 148 | 1.66 | 60.94 | 1.59 | 61.37 | 1492 | 214 | 1.78 | 45.15 | 1.18 | 54.07 | |
| 150 | 1.65 | 62.23 | 1.62 | 61.87 | 1493 | 216 | 1.75 | 48.41 | 1.26 | 55.80 | 1504 |
| 152 | 1.63 | 65.65 | 1.71 | 63.12 | 1486 | 218 | 1.70 | 55.00 | 1.43 | 58.92 | 1498 |
| 154 | 1.63 | 66.64 | 1.74 | 63.47 | 1487 | 220 | 1.71 | 53.88 | 1.41 | 58.42 | 1497 |
| 156 | 1.66 | 61.45 | 1.60 | 61.57 | 1494 | 222 | 1.72 | 52.96 | 1.38 | 58.00 | 1497 |
| 158 | 1.66 | 61.55 | 1.60 | 61.61 | 1496 | 224 | 1.68 | 57.93 | 1.51 | 60.17 | 1495 |
| 160 | 1.71 | 53.96 | 1.41 | 58.45 | 1503 | 226 | 1.69 | 56.64 | 1.48 | 59.63 | 1494 |
| 162 | 1.68 | 58.28 | 1.52 | 60.31 | 1488 | 228 | 1.68 | 57.40 | 1.50 | 59.95 | 1495 |
| 164 | 1.86 | 37.59 | 0.98 | 49.50 | 1492 | 230 | 1.68 | 58.28 | 1.52 | 60.31 | 1496 |
| 166 | 1.73 | 51.34 | 1.34 | 57.24 | | 232 | 1.73 | 50.44 | 1.32 | 56.81 | 1504 |
| 168 | 1.74 | 49.70 | 1.30 | 56.44 | 1509 | 234 | 1.73 | 51.54 | 1.34 | 57.34 | 1503 |
| 170 | 1.65 | 62.66 | 1.63 | 62.03 | 1493 | 236 | 1.70 | 54.89 | 1.43 | 58.87 | 1495 |
| 172 | 1.65 | 62.47 | 1.63 | 61.96 | 1494 | 238 | 1.69 | 56.08 | 1.46 | 59.39 | 1497 |
| 174 | 1.67 | 59.06 | 1.54 | 60.63 | 1492 | 240 | 1.68 | 57.47 | 1.50 | 59.98 | 1495 |
| 176 | 1.65 | 62.86 | 1.64 | 62.11 | 1494 | 242 | 1.70 | 54.91 | 1.43 | 58.88 | 1496 |
| 178 | 1.70 | 54.86 | 1.43 | 58.85 | 1503 | 244 | 1.71 | 53.98 | 1.41 | 58.46 | 1497 |
| 180 | 1.72 | 52.04 | 1.36 | 57.57 | 1503 | 246 | 1.71 | 54.24 | 1.41 | 58.58 | 1499 |
| 182 | 1.70 | 55.63 | 1.45 | 59.19 | 1497 | 248 | 1.64 | 63.55 | 1.66 | 62.36 | |
| 184 | 1.68 | 58.03 | 1.51 | 60.21 | 1499 | 250 | 1.59 | 73.93 | 1.93 | 65.84 | |
| 186 | 1.61 | 69.14 | 1.80 | 64.32 | 1487 | | | | | | |
| 188 | 1.63 | 66.56 | 1.74 | 63.44 | 1489 | | | | | | |
| 190 | 1.64 | 63.46 | 1.65 | 62.33 | 1493 | | | | | | |
| 192 | 1.72 | 52.77 | 1.38 | 57.91 | 1505 | | | | | | |
| 194 | 1.69 | 56.76 | 1.48 | 59.68 | | | | | | | |

HM 9

HM 9

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.95 | 29.90 | 0.78 | 43.81 | 1580 |
| 2 | | | | | | 62 | 1.97 | 28.69 | 0.75 | 42.80 | 1580 |
| 4 | | | | | | 64 | 1.96 | 28.89 | 0.75 | 42.96 | 1580 |
| 6 | | | | | | 66 | 1.95 | 29.66 | 0.77 | 43.61 | 1577 |
| 8 | | | | | | 68 | 1.95 | 29.79 | 0.78 | 43.71 | 1576 |
| 10 | | | | | | 70 | 1.96 | 29.16 | 0.76 | 43.19 | 1577 |
| 12 | | | | | | 72 | 1.96 | 28.76 | 0.75 | 42.86 | 1576 |
| 14 | | | | | | 74 | 1.98 | 27.76 | 0.72 | 41.99 | 1574 |
| 16 | 2.03 | 24.12 | 0.63 | 38.61 | | 76 | 1.95 | 29.85 | 0.78 | 43.76 | 1575 |
| 18 | 2.03 | 24.43 | 0.64 | 38.92 | | 78 | 1.98 | 27.64 | 0.72 | 41.88 | 1578 |
| 20 | 1.91 | 32.57 | 0.85 | 45.92 | 1567 | 80 | 1.95 | 29.57 | 0.77 | 43.53 | 1580 |
| 22 | 1.89 | 34.29 | 0.89 | 47.20 | 1550 | 82 | 1.96 | 29.15 | 0.76 | 43.19 | 1578 |
| 24 | 1.89 | 34.54 | 0.90 | 47.38 | 1551 | 84 | 1.96 | 29.11 | 0.76 | 43.15 | 1574 |
| 26 | 1.95 | 30.10 | 0.78 | 43.97 | 1566 | 86 | 1.96 | 28.85 | 0.75 | 42.93 | 1575 |
| 28 | 1.97 | 28.06 | 0.73 | 42.25 | 1583 | 88 | 1.96 | 29.18 | 0.76 | 43.21 | 1574 |
| 30 | 1.99 | 27.31 | 0.71 | 41.59 | 1589 | 90 | 1.95 | 29.70 | 0.77 | 43.64 | 1576 |
| 32 | 1.96 | 29.31 | 0.76 | 43.32 | 1585 | 92 | 1.94 | 30.26 | 0.79 | 44.11 | 1577 |
| 34 | 1.94 | 30.75 | 0.80 | 44.50 | 1574 | 94 | 1.98 | 27.80 | 0.72 | 42.03 | 1579 |
| 36 | 1.95 | 29.65 | 0.77 | 43.60 | 1578 | 96 | 1.94 | 30.51 | 0.80 | 44.31 | 1577 |
| 38 | 1.98 | 27.83 | 0.73 | 42.05 | 1582 | 98 | 1.95 | 29.63 | 0.77 | 43.59 | 1577 |
| 40 | 1.93 | 31.10 | 0.81 | 44.78 | 1577 | 100 | 1.97 | 28.60 | 0.75 | 42.71 | 1576 |
| 42 | 1.92 | 32.27 | 0.84 | 45.69 | 1562 | 102 | 1.94 | 30.75 | 0.80 | 44.50 | 1578 |
| 44 | 1.89 | 34.18 | 0.89 | 47.13 | 1561 | 104 | 1.96 | 29.14 | 0.76 | 43.18 | 1574 |
| 46 | 1.94 | 30.23 | 0.79 | 44.08 | 1576 | 106 | 1.95 | 29.77 | 0.78 | 43.70 | 1572 |
| 48 | 1.94 | 30.45 | 0.79 | 44.25 | 1575 | 108 | 1.96 | 29.25 | 0.76 | 43.27 | 1573 |
| 50 | 1.94 | 30.75 | 0.80 | 44.50 | 1572 | 110 | 1.95 | 29.64 | 0.77 | 43.59 | 1576 |
| 52 | 1.94 | 30.55 | 0.80 | 44.34 | 1573 | 112 | 1.96 | 28.98 | 0.76 | 43.04 | 1578 |
| 54 | 1.94 | 30.41 | 0.79 | 44.22 | 1574 | 114 | 1.97 | 28.66 | 0.75 | 42.77 | 1583 |
| 56 | 1.97 | 28.47 | 0.74 | 42.60 | 1583 | 116 | 1.92 | 32.21 | 0.84 | 45.65 | |
| 58 | 1.96 | 29.34 | 0.76 | 43.34 | 1583 | 118 | 1.90 | 33.46 | 0.87 | 46.59 | |
| | 1.96 | 29.34 | 0.77 | 43.34 | 1580 | 120 | 1.95 | 29.88 | 0.78 | 43.79 | 1601 |

HM 11

HM 11

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.68 | 57.72 | 1.50 | 60.08 | 1502 |
| 2 | | | | | | 62 | 1.65 | 62.00 | 1.62 | 61.78 | 1496 |
| 4 | | | | | | 64 | 1.65 | 62.00 | 1.62 | 61.78 | 1495 |
| 6 | | | | | | 66 | 1.65 | 63.22 | 1.65 | 62.24 | 1494 |
| 8 | | | | | | 68 | 1.64 | 64.45 | 1.68 | 62.69 | 1495 |
| 10 | | | | | | 70 | 1.64 | 64.34 | 1.68 | 62.65 | 1494 |
| 12 | | | | | | 72 | 1.65 | 62.55 | 1.63 | 61.99 | 1497 |
| 14 | | | | | | 74 | 1.59 | 74.08 | 1.93 | 65.89 | 1495 |
| 16 | | | | | | 76 | 1.60 | 71.13 | 1.85 | 64.97 | 1492 |
| 18 | | | | | | 78 | 1.57 | 76.56 | 2.00 | 66.62 | 1491 |
| 20 | | | | | | 80 | 1.48 | 100.99 | 2.63 | 72.48 | 1494 |
| 22 | | | | | | 82 | 1.63 | 66.29 | 1.73 | 63.35 | 1492 |
| 24 | 1.45 | 109.06 | 2.84 | 73.98 | | 84 | 1.62 | 67.89 | 1.77 | 63.90 | 1492 |
| 26 | 1.45 | 110.02 | 2.87 | 74.15 | | 86 | 1.62 | 68.03 | 1.77 | 63.95 | 1495 |
| 28 | 1.46 | 105.40 | 2.75 | 73.32 | | 88 | 1.59 | 73.48 | 1.92 | 65.71 | 1494 |
| 30 | 1.48 | 100.22 | 2.61 | 72.32 | | 90 | 1.63 | 65.94 | 1.72 | 63.23 | 1493 |
| 32 | 1.51 | 91.72 | 2.39 | 70.52 | | 92 | 1.63 | 65.89 | 1.72 | 63.21 | 1491 |
| 34 | 1.58 | 76.14 | 1.99 | 66.50 | | 94 | 1.60 | 70.37 | 1.83 | 64.73 | 1491 |
| 36 | 1.63 | 66.08 | 1.72 | 63.28 | | 96 | 1.52 | 88.12 | 2.30 | 69.67 | 1510 |
| 38 | 1.67 | 59.39 | 1.55 | 60.76 | | 98 | 1.57 | 76.23 | 1.99 | 66.53 | 1517 |
| 40 | 1.67 | 60.04 | 1.57 | 61.02 | 1501 | 100 | 1.52 | 88.23 | 2.30 | 69.70 | 1517 |
| 42 | 1.69 | 56.00 | 1.46 | 59.35 | 1499 | 102 | | | | | |
| 44 | 1.67 | 59.65 | 1.56 | 60.86 | 1495 | 104 | 1.76 | 47.55 | 1.24 | 55.35 | |
| 46 | 1.64 | 64.59 | 1.68 | 62.75 | 1493 | 106 | 1.72 | 52.30 | 1.36 | 57.69 | |
| 48 | 1.67 | 59.37 | 1.55 | 60.75 | 1494 | 108 | 1.78 | 44.75 | 1.17 | 53.85 | 1527 |
| 50 | 1.65 | 61.87 | 1.61 | 61.73 | 1496 | 110 | 1.80 | 43.00 | 1.12 | 52.86 | 1437 |
| 52 | 1.67 | 60.11 | 1.57 | 61.05 | 1499 | 112 | 1.80 | 42.82 | 1.12 | 52.75 | 1548 |
| 54 | 1.70 | 55.69 | 1.45 | 59.22 | 1500 | 114 | 1.82 | 40.91 | 1.07 | 51.61 | 1548 |
| 56 | 1.66 | 60.59 | 1.58 | 61.24 | 1497 | 116 | 1.83 | 40.33 | 1.05 | 51.26 | 1550 |
| 58 | 1.68 | 58.17 | 1.52 | 60.27 | 1501 | 118 | 1.82 | 40.89 | 1.07 | 51.60 | 1546 |
| | | | | | | 120 | 1.82 | 40.99 | 1.07 | 51.66 | 1545 |

HM 11

HM 11

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.82 | 41.17 | 1.07 | 51.77 | 1542 | 184 | 1.84 | 39.18 | 1.02 | 50.54 | 1546 |
| 124 | 1.83 | 40.16 | 1.05 | 51.15 | 1541 | 186 | 1.85 | 37.93 | 0.99 | 49.72 | 1546 |
| 126 | 1.82 | 41.08 | 1.07 | 51.72 | 1543 | 188 | 1.85 | 38.51 | 1.00 | 50.11 | 1548 |
| 128 | 1.82 | 40.88 | 1.07 | 51.59 | 1542 | 190 | 1.86 | 36.84 | 0.96 | 48.99 | 1550 |
| 130 | 1.80 | 42.54 | 1.11 | 52.59 | 1543 | 192 | 1.84 | 38.88 | 1.01 | 50.34 | 1551 |
| 132 | 1.83 | 39.56 | 1.03 | 50.77 | 1543 | 194 | 1.88 | 35.47 | 0.92 | 48.04 | 1553 |
| 134 | 1.84 | 38.67 | 1.01 | 50.21 | 1543 | 196 | 1.78 | 45.25 | 1.18 | 54.12 | |
| 136 | 1.84 | 38.74 | 1.01 | 50.25 | 1539 | 198 | 1.86 | 36.72 | 0.96 | 48.91 | |
| 138 | 1.84 | 39.39 | 1.03 | 50.67 | 1541 | 200 | 1.88 | 35.78 | 0.93 | 48.27 | 1544 |
| 140 | 1.83 | 39.86 | 1.04 | 50.96 | 1544 | 202 | | | | | |
| 142 | 1.83 | 40.18 | 1.05 | 51.17 | 1544 | 204 | | | | | |
| 144 | 1.82 | 40.82 | 1.06 | 51.56 | 1543 | 206 | 1.43 | 116.75 | 3.04 | 75.27 | |
| 146 | 1.84 | 39.09 | 1.02 | 50.48 | 1538 | 208 | 1.49 | 98.29 | 2.56 | 71.93 | |
| 148 | 1.83 | 40.43 | 1.05 | 51.32 | 1538 | 210 | 1.48 | 101.22 | 2.64 | 72.52 | |
| 150 | 1.81 | 41.79 | 1.09 | 52.15 | 1541 | 212 | 1.41 | 123.70 | 3.23 | 76.33 | |
| 152 | 1.82 | 40.92 | 1.07 | 51.62 | 1540 | 214 | 1.48 | 99.30 | 2.59 | 72.14 | 1482 |
| 154 | 1.82 | 41.27 | 1.08 | 51.83 | 1542 | 216 | 1.44 | 113.23 | 2.95 | 74.70 | 1484 |
| 156 | 1.84 | 38.64 | 1.01 | 50.19 | 1542 | 218 | 1.42 | 121.11 | 3.16 | 75.95 | |
| 158 | 1.83 | 39.55 | 1.03 | 50.77 | 1543 | 220 | 1.46 | 104.87 | 2.73 | 73.22 | |
| 160 | 1.81 | 41.53 | 1.08 | 51.99 | 1544 | 222 | 1.54 | 85.03 | 2.22 | 68.92 | 1459 |
| 162 | 1.82 | 40.60 | 1.06 | 51.43 | 1543 | 224 | 1.55 | 82.49 | 2.15 | 68.26 | 1465 |
| 164 | 1.85 | 38.51 | 1.00 | 50.10 | 1545 | 226 | 1.53 | 86.09 | 2.24 | 69.18 | 1473 |
| 166 | 1.82 | 40.88 | 1.07 | 51.60 | 1545 | 228 | 1.49 | 98.49 | 2.57 | 71.97 | 1484 |
| 168 | 1.83 | 40.31 | 1.05 | 51.25 | 1547 | 230 | 1.53 | 86.76 | 2.26 | 69.35 | 1459 |
| 170 | 1.84 | 39.18 | 1.02 | 50.53 | 1546 | 232 | 1.54 | 84.52 | 2.20 | 68.79 | 1485 |
| 172 | 1.82 | 40.54 | 1.06 | 51.39 | 1544 | 234 | 1.52 | 87.90 | 2.29 | 69.62 | 1484 |
| 174 | 1.83 | 39.73 | 1.04 | 50.88 | 1544 | 236 | | | | | |
| 176 | 1.85 | 37.82 | 0.99 | 49.65 | 1546 | 238 | 1.53 | 85.35 | 2.23 | 69.00 | 1473 |
| 178 | 1.83 | 40.18 | 1.05 | 51.16 | 1546 | 240 | 1.52 | 89.06 | 2.32 | 69.90 | 1482 |
| 180 | 1.84 | 39.37 | 1.03 | 50.65 | 1547 | 242 | 1.51 | 91.36 | 2.38 | 70.43 | 1481 |
| 182 | 1.81 | 41.69 | 1.09 | 52.09 | 1536 | 244 | | | | | 1479 |

HM 11

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.48 | 98.77 | 2.58 | 72.03 | 1480 |
| 248 | 1.51 | 91.40 | 2.38 | 70.44 | 1480 |
| 250 | 1.53 | 85.46 | 2.23 | 69.02 | 1481 |
| 252 | 1.52 | 88.93 | 2.32 | 69.87 | 1479 |
| 254 | 1.50 | 93.56 | 2.44 | 70.93 | 1478 |
| 256 | 1.47 | 102.34 | 2.67 | 72.74 | 1479 |
| 258 | 1.53 | 86.36 | 2.25 | 69.25 | 1481 |
| 260 | 1.54 | 83.12 | 2.17 | 68.43 | 1480 |
| 262 | 1.54 | 83.04 | 2.17 | 68.41 | 1479 |
| 264 | 1.57 | 76.72 | 2.00 | 66.67 | 1480 |
| 266 | 1.56 | 79.40 | 2.07 | 67.43 | 1479 |
| 268 | 1.56 | 78.71 | 2.05 | 67.24 | 1481 |
| 270 | 1.60 | 70.39 | 1.84 | 64.73 | 1483 |
| 272 | 1.54 | 85.00 | 2.22 | 68.91 | |
| 274 | 1.58 | 75.50 | 1.97 | 66.31 | 1514 |
| 276 | 1.59 | 73.19 | 1.91 | 65.62 | 1508 |
| 278 | | | | | 1504 |

HM 12

HM 12

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 0 | | | | | | 60 | 1.49 | 96.47 | 2.52 | 71.55 | 1487 |
| 2 | | | | | | 62 | 1.49 | 96.65 | 2.52 | 71.59 | 1490 |
| 4 | | | | | | 64 | 1.49 | 95.93 | 2.50 | 71.44 | 1492 |
| 6 | | | | | | 66 | 1.52 | 89.82 | 2.34 | 70.08 | 1490 |
| 8 | | | | | | 68 | 1.49 | 98.04 | 2.56 | 71.88 | 1487 |
| 10 | | | | | | 70 | 1.51 | 91.55 | 2.39 | 70.48 | 1486 |
| 12 | 1.43 | 116.81 | | | | 72 | 1.51 | 92.69 | 2.42 | 70.73 | 1485 |
| 14 | 1.47 | 102.66 | | | | 74 | 1.49 | 96.17 | 2.51 | 71.49 | 1486 |
| 16 | 1.49 | 97.06 | | | | 76 | 1.51 | 91.58 | 2.39 | 70.48 | 1486 |
| 18 | 1.46 | 107.90 | | | | 78 | 1.49 | 97.35 | 2.54 | 71.74 | 1485 |
| 20 | 1.47 | 101.80 | | | | 80 | 1.48 | 99.40 | 2.59 | 72.16 | 1483 |
| 22 | 1.47 | 102.02 | | | | 82 | 1.49 | 96.89 | 2.53 | 71.64 | 1483 |
| 24 | 1.46 | 106.27 | | | | 84 | 1.48 | 99.74 | 2.60 | 72.23 | 1483 |
| 26 | 1.47 | 103.37 | | | | 86 | 1.49 | 96.19 | 2.51 | 71.49 | 1484 |
| 28 | 1.51 | 92.09 | | | | 88 | 1.51 | 92.56 | 2.41 | 70.70 | 1484 |
| 30 | 1.48 | 100.70 | | | | 90 | 1.48 | 98.84 | 2.58 | 72.05 | 1484 |
| 32 | 1.47 | 102.81 | | | | 92 | 1.52 | 89.28 | 2.33 | 69.95 | 1485 |
| 34 | 1.48 | 101.60 | | | | 94 | 1.48 | 99.53 | 2.60 | 72.18 | 1485 |
| 36 | 1.50 | 95.18 | | | | 96 | 1.42 | 119.93 | 3.13 | 75.77 | |
| 38 | 1.49 | 98.00 | | | | 98 | 1.49 | 97.01 | 2.53 | 71.67 | 1504 |
| 40 | 1.46 | 105.47 | | | | 100 | 1.51 | 90.84 | 2.37 | 70.31 | 1507 |
| 42 | 1.49 | 95.93 | | | | 102 | | | | | |
| 44 | 1.50 | 94.22 | | | | 104 | | | | | |
| 46 | 1.50 | 94.56 | | | | 106 | | | | | |
| 48 | 1.47 | 104.58 | | | | 108 | 1.43 | 118.74 | 3.10 | 75.59 | |
| 50 | 1.50 | 94.55 | | | | 110 | 1.47 | 101.72 | 2.65 | 72.62 | |
| 52 | 1.49 | 96.39 | | | | 112 | 1.50 | 93.52 | 2.44 | 70.92 | |
| 54 | 1.49 | 95.78 | | | | 114 | 1.47 | 101.72 | 2.65 | 72.62 | |
| 56 | 1.49 | 98.34 | | | | 116 | 1.43 | 119.06 | 3.10 | 75.64 | |
| 58 | 1.49 | 98.01 | | | | 118 | 1.48 | 99.72 | 2.60 | 72.22 | |
| | | | | | | 120 | 1.45 | 109.24 | 2.85 | 74.01 | |

HM 12

HM 12

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.48 | 99.62 | 2.60 | 72.20 | | 184 | 1.51 | 92.59 | 2.41 | 70.71 | 1480 |
| 124 | 1.44 | 112.19 | 2.93 | 74.52 | | 186 | 1.48 | 98.99 | 2.58 | 72.07 | 1481 |
| 126 | 1.50 | 93.11 | 2.43 | 70.83 | | 188 | 1.52 | 89.15 | 2.32 | 69.92 | 1481 |
| 128 | 1.52 | 89.38 | 2.33 | 69.97 | | 190 | 1.48 | 99.00 | 2.58 | 72.08 | 1481 |
| 130 | 1.50 | 93.31 | 2.43 | 70.87 | | 192 | 1.53 | 86.81 | 2.26 | 69.36 | 1484 |
| 132 | 1.52 | 89.45 | 2.33 | 69.99 | | 194 | 1.52 | 89.86 | 2.34 | 70.09 | 1485 |
| 134 | 1.52 | 89.31 | 2.33 | 69.96 | | 196 | 1.45 | 110.99 | 2.89 | 74.32 | |
| 136 | 1.48 | 100.13 | 2.61 | 72.31 | 1477 | 198 | 1.50 | 94.64 | 2.47 | 71.16 | 1501 |
| 138 | 1.46 | 107.53 | 2.80 | 73.71 | 1480 | 200 | 1.42 | 119.33 | 3.11 | 75.68 | 1507 |
| 140 | 1.46 | 105.17 | 2.74 | 73.28 | 1483 | 202 | | | | | |
| 142 | 1.47 | 101.72 | 2.65 | 72.62 | 1484 | 204 | | | | | |
| 144 | 1.48 | 99.40 | 2.59 | 72.16 | 1482 | 206 | | | | | |
| 146 | 1.47 | 102.24 | 2.67 | 72.72 | 1481 | 208 | | | | | |
| 148 | 1.46 | 104.92 | 2.74 | 73.23 | 1481 | 210 | 1.41 | 126.59 | 3.30 | 76.75 | |
| 150 | 1.48 | 100.56 | 2.62 | 72.39 | 1480 | 212 | 1.46 | 105.27 | 2.74 | 73.30 | |
| 152 | 1.45 | 108.83 | 2.84 | 73.94 | 1481 | 214 | 1.42 | 122.50 | 3.19 | 76.16 | |
| 154 | 1.44 | 114.58 | 2.99 | 74.92 | 1481 | 216 | 1.37 | 143.40 | 3.74 | 78.90 | |
| 156 | 1.46 | 107.68 | 2.81 | 73.74 | 1481 | 218 | 1.50 | 93.35 | 2.43 | 70.88 | |
| 158 | 1.49 | 97.62 | 2.55 | 71.79 | 1482 | 220 | 1.48 | 100.84 | 2.63 | 72.45 | |
| 160 | 1.49 | 98.41 | 2.57 | 71.96 | 1481 | 222 | 1.48 | 98.90 | 2.58 | 72.06 | |
| 162 | 1.46 | 105.48 | 2.75 | 73.33 | 1481 | 224 | 1.49 | 98.11 | 2.56 | 71.90 | |
| 164 | 1.47 | 104.10 | 2.71 | 73.08 | 1481 | 226 | 1.51 | 90.65 | 2.36 | 70.27 | |
| 166 | 1.44 | 112.14 | 2.92 | 74.52 | 1480 | 228 | 1.50 | 95.61 | 2.49 | 71.37 | |
| 168 | 1.49 | 96.60 | 2.52 | 71.58 | 1479 | 230 | 1.49 | 95.86 | 2.50 | 71.42 | |
| 170 | 1.51 | 91.17 | 2.38 | 70.39 | 1482 | 232 | 1.48 | 99.83 | 2.60 | 72.25 | |
| 172 | 1.50 | 93.18 | 2.43 | 70.84 | 1482 | 234 | 1.53 | 85.83 | 2.24 | 69.12 | |
| 174 | 1.50 | 93.78 | 2.45 | 70.97 | 1481 | 236 | 1.52 | 89.14 | 2.32 | 69.92 | |
| 176 | 1.49 | 97.57 | 2.54 | 71.78 | 1480 | 238 | 1.50 | 93.84 | 2.45 | 70.99 | |
| 178 | 1.51 | 92.24 | 2.41 | 70.63 | 1480 | 240 | 1.48 | 98.67 | 2.57 | 72.01 | |
| 180 | 1.49 | 96.68 | 2.52 | 71.60 | 1480 | 242 | 1.52 | 87.86 | 2.29 | 69.61 | |
| 182 | 1.50 | 95.21 | 2.48 | 71.29 | 1481 | 244 | 1.51 | 91.39 | 2.38 | 70.44 | |

HM 12

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.49 | 97.92 | 2.55 | 71.86 | |
| 248 | 1.50 | 93.16 | 2.43 | 70.84 | |
| 250 | 1.54 | 83.45 | 2.18 | 68.51 | |
| 252 | 1.52 | 89.62 | 2.34 | 70.03 | 1482 |
| 254 | 1.49 | 98.10 | 2.56 | 71.89 | 1480 |
| 256 | 1.50 | 95.57 | 2.49 | 71.36 | 1481 |
| 258 | 1.50 | 95.03 | 2.48 | 71.25 | 1480 |
| 260 | 1.48 | 101.10 | 2.64 | 72.50 | 1481 |
| 262 | 1.51 | 92.38 | 2.41 | 70.66 | 1480 |
| 264 | 1.49 | 95.70 | 2.50 | 71.39 | 1479 |
| 266 | 1.47 | 104.09 | 2.71 | 73.08 | 1479 |
| 268 | 1.49 | 97.35 | 2.54 | 71.74 | 1479 |
| 270 | 1.50 | 94.89 | 2.47 | 71.22 | 1480 |
| 272 | 1.48 | 98.60 | 2.57 | 72.00 | 1479 |
| 274 | 1.48 | 101.39 | 2.64 | 72.55 | 1479 |
| 276 | 1.49 | 96.46 | 2.52 | 71.55 | 1480 |
| 278 | 1.51 | 91.76 | 2.39 | 70.52 | 1480 |
| 280 | 1.49 | 96.05 | 2.50 | 71.46 | 1480 |
| 282 | 1.46 | 107.56 | 2.80 | 73.71 | 1479 |
| 284 | 1.49 | 98.52 | 2.57 | 71.98 | 1480 |
| 286 | 1.49 | 98.37 | 2.56 | 71.95 | 1480 |
| 288 | 1.48 | 98.83 | 2.58 | 72.04 | 1480 |
| 290 | 1.51 | 90.94 | 2.37 | 70.34 | 1481 |
| 292 | 1.48 | 100.30 | 2.62 | 72.34 | 1480 |
| 294 | 1.51 | 91.89 | 2.40 | 70.55 | |

HM 16

HM 16

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.50 | 94.14 | 2.45 | 71.05 | 1482 |
| 2 | | | | | | 62 | 1.48 | 99.12 | 2.58 | 72.10 | 1481 |
| 4 | | | | | | 64 | 1.49 | 97.89 | 2.55 | 71.85 | 1481 |
| 6 | | | | | | 66 | 1.50 | 95.06 | 2.48 | 71.25 | 1480 |
| 8 | | | | | | 68 | 1.49 | 96.59 | 2.52 | 71.58 | 1479 |
| 10 | | | | | | 70 | 1.51 | 91.76 | 2.39 | 70.52 | 1481 |
| 12 | 1.46 | 106.09 | 2.77 | 73.45 | | 72 | 1.49 | 95.87 | 2.50 | 71.43 | 1481 |
| 14 | 1.45 | 109.80 | 2.86 | 74.11 | | 74 | 1.50 | 95.67 | 2.49 | 71.38 | 1481 |
| 16 | 1.46 | 105.96 | 2.76 | 73.42 | | 76 | 1.51 | 91.38 | 2.38 | 70.44 | 1481 |
| 18 | 1.46 | 105.02 | 2.74 | 73.25 | 1480 | 78 | 1.48 | 101.49 | 2.65 | 72.57 | 1481 |
| 20 | 1.51 | 91.82 | 2.39 | 70.54 | 1488 | 80 | 1.47 | 103.39 | 2.70 | 72.94 | 1480 |
| 22 | 1.52 | 89.93 | 2.34 | 70.10 | 1486 | 82 | 1.48 | 101.41 | 2.64 | 72.56 | 1482 |
| 24 | 1.49 | 97.35 | 2.54 | 71.74 | 1486 | 84 | 1.50 | 95.54 | 2.49 | 71.36 | 1482 |
| 26 | 1.51 | 92.00 | 2.40 | 70.58 | 1487 | 86 | 1.48 | 99.92 | 2.61 | 72.26 | 1481 |
| 28 | 1.53 | 86.65 | 2.26 | 69.32 | 1489 | 88 | 1.47 | 104.08 | 2.71 | 73.07 | 1480 |
| 30 | 1.54 | 83.77 | 2.18 | 68.59 | 1491 | 90 | 1.48 | 101.32 | 2.64 | 72.54 | 1480 |
| 32 | 1.52 | 89.07 | 2.32 | 69.90 | 1487 | 92 | 1.45 | 109.46 | 2.85 | 74.05 | 1481 |
| 34 | 1.51 | 91.17 | 2.38 | 70.39 | 1486 | 94 | 1.44 | 114.32 | 2.98 | 74.88 | |
| 36 | 1.49 | 97.06 | 2.53 | 71.68 | 1485 | 96 | 1.47 | 102.93 | 2.68 | 72.85 | 1500 |
| 38 | 1.50 | 94.53 | 2.46 | 71.14 | 1485 | 98 | | | | | 1504 |
| 40 | 1.48 | 101.13 | 2.64 | 72.50 | 1487 | 100 | | | | | |
| 42 | 1.49 | 98.35 | 2.56 | 71.94 | 1486 | 102 | | | | | 1509 |
| 44 | 1.46 | 105.28 | 2.75 | 73.30 | 1483 | 104 | | | | | 1500 |
| 46 | 1.49 | 98.41 | 2.57 | 71.96 | 1484 | 106 | | | | | |
| 48 | 1.49 | 97.25 | 2.54 | 71.72 | 1482 | 108 | | | | | 1486 |
| 50 | 1.47 | 104.37 | 2.72 | 73.13 | 1482 | 110 | 1.53 | 87.44 | 2.28 | 69.51 | 1485 |
| 52 | 1.47 | 101.89 | 2.66 | 72.65 | 1482 | 112 | 1.54 | 84.58 | 2.21 | 68.80 | 1484 |
| 54 | 1.48 | 100.48 | 2.62 | 72.38 | 1482 | 114 | 1.51 | 90.61 | 2.36 | 70.26 | 1481 |
| 56 | 1.46 | 107.60 | 2.81 | 73.72 | 1481 | 116 | 1.50 | 94.20 | 2.46 | 71.07 | 1480 |
| 58 | 1.46 | 106.49 | 2.78 | 73.52 | 1481 | 118 | 1.52 | 89.18 | 2.33 | 69.93 | 1482 |
| | | | | | | 120 | 1.49 | 97.02 | 2.53 | 71.67 | 1478 |

HM 16

HM 16

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.49 | 98.25 | 2.56 | 71.92 | 1478 | 184 | 1.48 | 100.98 | 2.63 | 72.47 | 1480 |
| 124 | 1.53 | 87.04 | 2.27 | 69.42 | 1481 | 186 | 1.46 | 106.54 | 2.78 | 73.53 | 1480 |
| 126 | 1.53 | 86.37 | 2.25 | 69.25 | 1482 | 188 | 1.47 | 104.42 | 2.72 | 73.14 | 1480 |
| 128 | 1.54 | 84.95 | 2.21 | 68.89 | 1483 | 190 | 1.49 | 96.83 | 2.52 | 71.63 | 1480 |
| 130 | 1.53 | 87.31 | 2.28 | 69.48 | 1482 | 192 | 1.47 | 103.00 | 2.69 | 72.87 | 1482 |
| 132 | 1.55 | 81.86 | 2.13 | 68.10 | 1483 | 194 | 1.45 | 108.55 | 2.83 | 73.89 | |
| 134 | 1.53 | 85.85 | 2.24 | 69.12 | 1483 | 196 | 1.42 | 119.34 | 3.11 | 75.68 | 1492 |
| 136 | 1.52 | 88.34 | 2.30 | 69.73 | 1483 | 198 | 1.46 | 106.29 | 2.77 | 73.48 | 1499 |
| 138 | 1.52 | 88.59 | 2.31 | 69.79 | 1484 | 200 | | | | | 1497 |
| 140 | 1.50 | 92.98 | 2.42 | 70.80 | 1482 | 202 | | | | | |
| 142 | 1.49 | 95.95 | 2.50 | 71.44 | 1481 | 204 | | | | | |
| 144 | 1.48 | 98.78 | 2.58 | 72.03 | 1481 | 206 | | | | | |
| 146 | 1.51 | 92.70 | 2.42 | 70.74 | 1482 | 208 | 1.45 | 110.81 | 2.89 | 74.29 | |
| 148 | 1.50 | 93.16 | 2.43 | 70.84 | 1481 | 210 | 1.46 | 106.81 | 2.79 | 73.58 | |
| 150 | 1.46 | 108.11 | 2.82 | 73.81 | 1481 | 212 | 1.46 | 107.97 | 2.82 | 73.79 | |
| 152 | 1.50 | 93.64 | 2.44 | 70.94 | 1481 | 214 | 1.47 | 102.95 | 2.68 | 72.86 | |
| 154 | 1.53 | 85.75 | 2.24 | 69.10 | 1484 | 216 | 1.46 | 107.03 | 2.79 | 73.62 | |
| 156 | 1.47 | 101.76 | 2.65 | 72.63 | 1483 | 218 | 1.47 | 102.10 | 2.66 | 72.69 | |
| 158 | 1.49 | 97.71 | 2.55 | 71.81 | 1480 | 220 | 1.51 | 91.79 | 2.39 | 70.53 | |
| 160 | 1.48 | 99.06 | 2.58 | 72.09 | 1482 | 222 | 1.50 | 95.34 | 2.49 | 71.31 | |
| 162 | 1.49 | 97.68 | 2.55 | 71.81 | 1481 | 224 | 1.49 | 95.94 | 2.50 | 71.44 | |
| 164 | 1.50 | 93.30 | 2.43 | 70.87 | 1480 | 226 | 1.48 | 98.83 | 2.58 | 72.04 | |
| 166 | 1.49 | 97.50 | 2.54 | 71.77 | 1479 | 228 | 1.47 | 104.45 | 2.72 | 73.14 | |
| 168 | 1.49 | 98.01 | 2.56 | 71.87 | 1480 | 230 | 1.46 | 105.40 | 2.75 | 73.32 | 1474 |
| 170 | 1.51 | 91.12 | 2.38 | 70.38 | 1481 | 232 | 1.46 | 107.28 | 2.80 | 73.67 | 1484 |
| 172 | 1.50 | 93.30 | 2.43 | 70.87 | 1480 | 234 | 1.52 | 87.81 | 2.29 | 69.60 | 1485 |
| 174 | 1.50 | 93.16 | 2.43 | 70.84 | 1480 | 236 | 1.50 | 93.52 | 2.44 | 70.92 | 1483 |
| 176 | 1.49 | 97.46 | 2.54 | 71.76 | 1479 | 238 | 1.47 | 102.16 | 2.66 | 72.71 | 1479 |
| 178 | 1.47 | 103.40 | 2.70 | 72.94 | 1480 | 240 | 1.49 | 97.55 | 2.54 | 71.78 | 1479 |
| 180 | 1.49 | 96.17 | 2.51 | 71.49 | 1481 | 242 | 1.52 | 90.11 | 2.35 | 70.15 | 1481 |
| 182 | 1.50 | 94.03 | 2.45 | 71.03 | 1481 | 244 | 1.54 | 83.35 | 2.17 | 68.49 | 1483 |

HM 16

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.50 | 93.03 | 2.43 | 70.81 | 1480 |
| 248 | 1.51 | 90.75 | 2.37 | 70.29 | 1481 |
| 250 | 1.52 | 89.43 | 2.33 | 69.99 | 1481 |
| 252 | 1.50 | 94.80 | 2.47 | 71.20 | 1480 |
| 254 | 1.50 | 93.71 | 2.44 | 70.96 | 1481 |
| 256 | 1.52 | 89.39 | 2.33 | 69.98 | 1481 |
| 258 | 1.50 | 95.23 | 2.48 | 71.29 | 1481 |
| 260 | 1.52 | 87.79 | 2.29 | 69.60 | 1482 |
| 262 | 1.51 | 90.95 | 2.37 | 70.34 | 1481 |
| 264 | 1.51 | 90.87 | 2.37 | 70.32 | 1481 |
| 266 | 1.53 | 86.20 | 2.25 | 69.21 | 1483 |
| 268 | 1.55 | 82.21 | 2.14 | 68.19 | 1482 |
| 270 | 1.55 | 82.58 | 2.15 | 68.29 | 1484 |
| 272 | 1.55 | 81.69 | 2.13 | 68.05 | 1485 |
| 274 | 1.57 | 76.26 | 1.99 | 66.54 | 1486 |
| 276 | 1.58 | 74.87 | 1.95 | 66.13 | 1488 |
| 278 | 1.59 | 72.54 | 1.89 | 65.42 | 1488 |
| 280 | 1.60 | 72.19 | 1.88 | 65.31 | 1487 |
| 282 | 1.61 | 69.32 | 1.81 | 64.38 | 1490 |
| 284 | 1.61 | 69.12 | 1.80 | 64.32 | 1487 |
| 286 | 1.59 | 73.93 | 1.93 | 65.84 | |
| 288 | 1.62 | 67.86 | 1.77 | 63.89 | 1511 |
| 290 | 1.65 | 62.16 | 1.62 | 61.84 | |

HM 17

HM 17

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 62 | 1.50 | 92.99 | 2.42 | 70.80 | 1479 |
| 2 | | | | | | 64 | 1.47 | 101.93 | 2.66 | 72.66 | 1481 |
| 4 | | | | | | 66 | 1.51 | 90.96 | 2.37 | 70.34 | 1484 |
| 6 | | | | | | 68 | 1.54 | 84.74 | 2.21 | 68.84 | 1486 |
| 8 | | | | | | 70 | 1.52 | 87.89 | 2.29 | 69.62 | 1491 |
| 10 | | | | | | 72 | 1.49 | 98.55 | 2.57 | 71.99 | 1479 |
| 12 | | | | | | 74 | 1.48 | 99.28 | 2.59 | 72.13 | 1478 |
| 14 | | | | | | 76 | 1.50 | 94.72 | 2.47 | 71.18 | 1479 |
| 16 | 1.40 | 131.16 | 3.42 | 77.37 | | 78 | 1.49 | 98.20 | 2.56 | 71.91 | 1477 |
| 18 | 1.41 | 126.16 | 3.29 | 76.69 | | 80 | 1.47 | 102.26 | 2.67 | 72.72 | 1479 |
| 20 | 1.40 | 128.17 | 3.34 | 76.97 | | 82 | 1.47 | 102.99 | 2.69 | 72.87 | 1479 |
| 22 | 1.44 | 113.47 | 2.96 | 74.74 | | 84 | 1.48 | 99.66 | 2.60 | 72.21 | 1479 |
| 24 | 1.42 | 120.77 | 3.15 | 75.90 | | 86 | 1.48 | 101.33 | 2.64 | 72.54 | 1479 |
| 26 | 1.41 | 124.50 | 3.25 | 76.45 | | 88 | 1.49 | 97.57 | 2.54 | 71.78 | 1478 |
| 28 | 1.43 | 115.34 | 3.01 | 75.05 | | 90 | 1.48 | 100.76 | 2.63 | 72.43 | 1478 |
| 30 | 1.53 | 87.05 | 2.27 | 69.42 | | 92 | 1.45 | 110.37 | 2.88 | 74.21 | 1481 |
| 32 | 1.48 | 101.05 | 2.63 | 72.49 | | 94 | 1.49 | 97.89 | 2.55 | 71.85 | 1481 |
| 34 | 1.44 | 114.70 | 2.99 | 74.94 | | 96 | 1.51 | 91.67 | 2.39 | 70.50 | 1482 |
| 36 | 1.42 | 120.58 | 3.14 | 75.87 | | 98 | 1.47 | 103.90 | 2.71 | 73.04 | 1479 |
| 38 | 1.44 | 115.24 | 3.00 | 75.03 | | 100 | 1.47 | 103.06 | 2.69 | 72.88 | 1478 |
| 40 | 1.44 | 111.92 | 2.92 | 74.48 | | 102 | | | | | |
| 42 | 1.46 | 106.63 | 2.78 | 73.55 | 1490 | 104 | 1.36 | 148.09 | 3.86 | 79.43 | |
| 44 | 1.49 | 95.92 | 2.50 | 71.44 | 1491 | 106 | 1.47 | 102.13 | 2.66 | 72.70 | |
| 46 | 1.48 | 98.63 | 2.57 | 72.00 | 1484 | 108 | 1.48 | 98.75 | 2.57 | 72.03 | |
| 48 | 1.40 | 129.80 | 3.38 | 77.19 | 1485 | 110 | 1.49 | 98.12 | 2.56 | 71.90 | |
| 50 | 1.47 | 102.31 | 2.67 | 72.73 | 1485 | 112 | 1.49 | 97.94 | 2.55 | 71.86 | |
| 52 | 1.48 | 98.96 | 2.58 | 72.07 | 1481 | 114 | 1.49 | 97.94 | 2.55 | 71.86 | |
| 54 | 1.49 | 97.76 | 2.55 | 71.82 | 1479 | 116 | 1.48 | 100.86 | 2.63 | 72.45 | |
| 56 | 1.48 | 99.47 | 2.59 | 72.17 | 1479 | 118 | 1.53 | 86.99 | 2.27 | 69.40 | 1492 |
| 58 | 1.46 | 107.12 | 2.79 | 73.64 | 1483 | 120 | 1.55 | 80.99 | 2.11 | 67.86 | 1488 |
| 60 | 1.49 | 95.82 | 2.50 | 71.42 | 1479 | 122 | 1.50 | 93.56 | 2.44 | 70.93 | 1475 |

HM 17

HM 17

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 124 | 1.55 | 81.96 | 2.14 | 68.12 | 1481 | 184 | 1.64 | 63.85 | 1.66 | 62.48 | 1486 |
| 126 | 1.53 | 85.84 | 2.24 | 69.12 | 1481 | 186 | 1.67 | 60.02 | 1.57 | 61.01 | 1495 |
| 128 | 1.57 | 77.46 | 2.02 | 66.88 | 1482 | 188 | 1.66 | 60.14 | 1.57 | 61.06 | 1494 |
| 130 | 1.55 | 80.89 | 2.11 | 67.84 | 1483 | 190 | 1.66 | 61.63 | 1.61 | 61.64 | 1492 |
| 132 | 1.58 | 75.40 | 1.97 | 66.28 | 1483 | 192 | 1.66 | 60.79 | 1.59 | 61.32 | 1493 |
| 134 | 1.61 | 69.18 | 1.80 | 64.33 | 1486 | 194 | 1.66 | 60.86 | 1.59 | 61.34 | 1494 |
| 136 | 1.59 | 73.06 | 1.90 | 65.58 | 1486 | 196 | 1.71 | 53.98 | 1.41 | 58.46 | 1502 |
| 138 | 1.61 | 70.11 | 1.83 | 64.64 | 1488 | 198 | 1.71 | 54.27 | 1.42 | 58.59 | 1501 |
| 140 | 1.60 | 71.88 | 1.87 | 65.21 | 1490 | 200 | 1.70 | 55.37 | 1.44 | 59.08 | 1500 |
| 142 | 1.63 | 65.27 | 1.70 | 62.99 | 1494 | 202 | 1.68 | 57.72 | 1.51 | 60.08 | 1500 |
| 144 | 1.65 | 63.22 | 1.65 | 62.24 | 1494 | 204 | 1.67 | 59.60 | 1.55 | 60.85 | 1498 |
| 146 | 1.65 | 63.15 | 1.65 | 62.22 | 1490 | 206 | 1.66 | 60.99 | 1.59 | 61.39 | |
| 148 | 1.62 | 67.41 | 1.76 | 63.74 | 1491 | | | | | | |
| 150 | 1.61 | 69.72 | 1.82 | 64.51 | 1491 | | | | | | |
| 152 | 1.62 | 67.24 | 1.75 | 63.68 | 1495 | | | | | | |
| 154 | 1.58 | 75.31 | 1.96 | 66.26 | 1484 | | | | | | |
| 156 | 1.59 | 73.01 | 1.90 | 65.56 | 1487 | | | | | | |
| 158 | 1.62 | 67.00 | 1.75 | 63.60 | 1489 | | | | | | |
| 160 | 1.64 | 64.63 | 1.69 | 62.76 | 1493 | | | | | | |
| 162 | 1.61 | 68.49 | 1.79 | 64.10 | 1493 | | | | | | |
| 164 | 1.65 | 62.70 | 1.63 | 62.05 | 1506 | | | | | | |
| 166 | 1.70 | 54.52 | 1.42 | 58.71 | 1507 | | | | | | |
| 168 | 1.71 | 54.17 | 1.41 | 58.55 | 1511 | | | | | | |
| 170 | 1.68 | 58.18 | 1.52 | 60.27 | 1509 | | | | | | |
| 172 | 1.69 | 56.08 | 1.46 | 59.39 | 1512 | | | | | | |
| 174 | 1.67 | 59.35 | 1.55 | 60.74 | 1502 | | | | | | |
| 176 | 1.63 | 66.01 | 1.72 | 63.25 | 1495 | | | | | | |
| 178 | 1.66 | 61.37 | 1.60 | 61.54 | 1496 | | | | | | |
| 180 | 1.66 | 60.23 | 1.57 | 61.09 | 1502 | | | | | | |
| 182 | 1.69 | 56.44 | 1.47 | 59.54 | 1494 | | | | | | |

HM 19

HM 19

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.62 | 67.22 | 1.75 | 63.67 | 1492 |
| 2 | | | | | | 62 | 1.59 | 72.77 | 1.90 | 65.49 | 1482 |
| 4 | | | | | | 64 | 1.54 | 84.61 | 2.21 | 68.81 | 1476 |
| 6 | | | | | | 66 | 1.55 | 82.65 | 2.16 | 68.31 | 1474 |
| 8 | | | | | 1493 | 68 | 1.57 | 76.57 | 2.00 | 66.63 | 1476 |
| 10 | 1.47 | 102.92 | 2.68 | 72.85 | 1488 | 70 | 1.59 | 72.83 | 1.90 | 65.51 | 1478 |
| 12 | 1.50 | 94.01 | 2.45 | 71.02 | 1486 | 72 | 1.59 | 73.38 | 1.91 | 65.68 | 1480 |
| 14 | 1.62 | 67.73 | 1.77 | 63.85 | 1496 | 74 | 1.61 | 70.17 | 1.83 | 64.66 | 1479 |
| 16 | 1.45 | 108.50 | 2.83 | 73.88 | 1484 | 76 | 1.57 | 76.23 | 1.99 | 66.53 | 1478 |
| 18 | 1.48 | 98.90 | 2.58 | 72.06 | 1484 | 78 | 1.56 | 79.42 | 2.07 | 67.43 | 1478 |
| 20 | 1.49 | 97.20 | 2.53 | 71.71 | 1483 | 80 | 1.55 | 81.01 | 2.11 | 67.87 | 1477 |
| 22 | 1.48 | 100.00 | 2.61 | 72.28 | 1481 | 82 | 1.58 | 74.87 | 1.95 | 66.13 | 1478 |
| 24 | 1.46 | 107.35 | 2.80 | 73.68 | 1480 | 84 | 1.59 | 73.72 | 1.92 | 65.78 | 1478 |
| 26 | 1.41 | 124.60 | 3.25 | 76.46 | 1477 | 86 | 1.58 | 74.98 | 1.96 | 66.16 | 1478 |
| 28 | 1.49 | 96.64 | 2.52 | 71.59 | 1479 | 88 | 1.68 | 58.04 | 1.51 | 60.21 | 1498 |
| 30 | 1.57 | 76.63 | 2.00 | 66.65 | 1486 | 90 | 1.56 | 79.76 | 2.08 | 67.53 | 1476 |
| 32 | 1.61 | 69.52 | 1.81 | 64.45 | 1492 | 92 | 1.70 | 54.42 | 1.42 | 58.66 | 1485 |
| 34 | 1.67 | 59.28 | 1.55 | 60.72 | 1502 | 94 | 1.65 | 61.73 | 1.61 | 61.68 | 1495 |
| 36 | 1.72 | 52.52 | 1.37 | 57.79 | 1509 | 96 | 1.71 | 54.33 | 1.42 | 58.62 | 1500 |
| 38 | 1.72 | 51.79 | 1.35 | 57.46 | 1510 | 98 | 1.64 | 63.78 | 1.66 | 62.45 | 1491 |
| 40 | 1.68 | 58.53 | 1.53 | 60.41 | 1502 | 100 | 1.77 | 45.93 | 1.20 | 54.50 | 1521 |
| 42 | 1.69 | 56.77 | 1.48 | 59.68 | 1503 | 102 | 1.66 | 60.47 | 1.58 | 61.19 | 1521 |
| 44 | 1.69 | 55.91 | 1.46 | 59.32 | 1501 | 104 | 1.71 | 53.39 | 1.39 | 58.19 | |
| 46 | 1.69 | 56.00 | 1.46 | 59.35 | 1493 | 106 | | | | | |
| 48 | 1.80 | 43.16 | 1.13 | 52.95 | 1547 | 108 | 1.67 | 59.14 | 1.54 | 60.66 | |
| 50 | 1.70 | 54.51 | 1.42 | 58.70 | 1518 | 110 | 1.66 | 61.69 | 1.61 | 61.66 | |
| 52 | 1.68 | 58.55 | 1.53 | 60.42 | 1511 | 112 | 1.63 | 66.40 | 1.73 | 63.39 | |
| 54 | 1.70 | 55.60 | 1.45 | 59.18 | 1506 | 114 | 1.67 | 58.87 | 1.54 | 60.55 | |
| 56 | 1.66 | 60.55 | 1.58 | 61.22 | 1497 | 116 | 1.72 | 52.90 | 1.38 | 57.97 | |
| 58 | 1.67 | 58.69 | 1.53 | 60.48 | 1494 | 118 | 1.72 | 52.58 | 1.37 | 57.82 | |
| | | | | | | 120 | | | | | |

HM 19

HM 19

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.69 | 56.21 | 1.47 | 59.44 | | 184 | 1.85 | 38.00 | 0.99 | 49.77 | 1530 |
| 124 | 1.69 | 55.87 | 1.46 | 59.30 | | 186 | 1.86 | 37.17 | 0.97 | 49.22 | 1529 |
| 126 | 1.68 | 57.47 | 1.50 | 59.98 | | 188 | 1.81 | 41.75 | 1.09 | 52.12 | 1520 |
| 128 | 1.68 | 57.55 | 1.50 | 60.01 | | 190 | 1.80 | 43.05 | 1.12 | 52.89 | 1519 |
| 130 | 1.67 | 59.55 | 1.55 | 60.83 | | 192 | 1.81 | 41.49 | 1.08 | 51.97 | 1521 |
| 132 | 1.67 | 59.28 | 1.55 | 60.72 | | 194 | 1.93 | 31.25 | 0.81 | 44.90 | 1569 |
| 134 | 1.67 | 59.46 | 1.55 | 60.79 | 1487 | 196 | 1.95 | 30.18 | 0.79 | 44.04 | |
| 136 | 1.67 | 59.72 | 1.56 | 60.90 | 1486 | 198 | 2.01 | 25.41 | 0.66 | 39.85 | 1521 |
| 138 | 1.67 | 59.50 | 1.55 | 60.81 | 1488 | 200 | 1.97 | 28.56 | 0.74 | 42.68 | |
| 140 | 1.70 | 55.16 | 1.44 | 58.99 | 1500 | | | | | | |
| 142 | 1.79 | 43.80 | 1.14 | 53.31 | 1516 | | | | | | |
| 144 | 1.71 | 53.40 | 1.39 | 58.20 | 1502 | | | | | | |
| 146 | 1.67 | 58.73 | 1.53 | 60.50 | 1491 | | | | | | |
| 148 | 1.73 | 51.25 | 1.34 | 57.20 | 1498 | | | | | | |
| 150 | 1.89 | 34.39 | 0.90 | 47.27 | 1557 | | | | | | |
| 152 | 1.93 | 31.04 | 0.81 | 44.73 | 1572 | | | | | | |
| 154 | 2.13 | 18.49 | 0.48 | 32.53 | 1663 | | | | | | |
| 156 | 2.16 | 17.26 | 0.45 | 31.04 | 1675 | | | | | | |
| 158 | 2.17 | 16.58 | 0.43 | 30.19 | 1680 | | | | | | |
| 160 | 2.18 | 16.36 | 0.43 | 29.91 | 1686 | | | | | | |
| 162 | 2.17 | 16.92 | 0.44 | 30.61 | 1685 | | | | | | |
| 164 | 2.20 | 15.29 | 0.40 | 28.50 | 1687 | | | | | | |
| 166 | 2.19 | 15.78 | 0.41 | 29.15 | 1685 | | | | | | |
| 168 | 2.17 | 16.54 | 0.43 | 30.14 | 1698 | | | | | | |
| 170 | 2.17 | 16.66 | 0.43 | 30.29 | 1697 | | | | | | |
| 172 | 2.06 | 22.74 | 0.59 | 37.22 | 1695 | | | | | | |
| 174 | 1.83 | 39.60 | 1.03 | 50.80 | 1538 | | | | | | |
| 176 | 1.83 | 39.87 | 1.04 | 50.97 | 1527 | | | | | | |
| 178 | 1.83 | 39.61 | 1.03 | 50.80 | 1525 | | | | | | |
| 180 | 1.84 | 38.62 | 1.01 | 50.18 | 1526 | | | | | | |
| 182 | 1.83 | 40.19 | 1.05 | 51.17 | 1527 | | | | | | |

HM 29

HM 29

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.49 | 96.48 | 2.52 | 71.56 | 1490 |
| 2 | | | | | | 62 | 1.50 | 94.75 | 2.47 | 71.19 | 1490 |
| 4 | | | | | | 64 | 1.48 | 100.38 | 2.62 | 72.36 | 1487 |
| 6 | | | | | | 66 | 1.48 | 100.03 | 2.61 | 72.28 | 1486 |
| 8 | 1.48 | 100.48 | 2.62 | 72.37 | | 68 | 1.45 | 108.32 | 2.82 | 73.85 | 1485 |
| 10 | 1.49 | 98.19 | 2.56 | 71.91 | 1492 | 70 | 1.47 | 102.97 | 2.68 | 72.86 | 1485 |
| 12 | 1.48 | 100.80 | 2.63 | 72.44 | 1490 | 72 | 1.48 | 99.26 | 2.59 | 72.13 | 1484 |
| 14 | 1.48 | 99.35 | 2.59 | 72.15 | 1490 | 74 | 1.46 | 107.88 | 2.81 | 73.77 | 1483 |
| 16 | 1.44 | 113.50 | 2.96 | 74.74 | 1490 | 76 | 1.42 | 120.21 | 3.13 | 75.81 | 1484 |
| 18 | 1.47 | 104.18 | 2.72 | 73.09 | 1491 | 78 | 1.43 | 116.94 | 3.05 | 75.30 | 1485 |
| 20 | 1.46 | 107.34 | 2.80 | 73.68 | 1493 | 80 | 1.41 | 123.97 | 3.23 | 76.37 | 1486 |
| 22 | 1.48 | 100.65 | 2.62 | 72.41 | 1494 | 82 | 1.45 | 109.89 | 2.87 | 74.13 | 1486 |
| 24 | 1.46 | 108.01 | 2.82 | 73.80 | 1494 | 84 | 1.45 | 108.69 | 2.83 | 73.92 | 1486 |
| 26 | 1.46 | 107.30 | 2.80 | 73.67 | 1492 | 86 | 1.45 | 108.51 | 2.83 | 73.89 | 1488 |
| 28 | 1.48 | 99.47 | 2.59 | 72.17 | 1490 | 88 | 1.47 | 103.39 | 2.70 | 72.94 | 1485 |
| 30 | 1.46 | 106.06 | 2.77 | 73.44 | 1488 | 90 | 1.46 | 105.51 | 2.75 | 73.34 | 1485 |
| 32 | 1.45 | 108.53 | 2.83 | 73.89 | 1488 | 92 | 1.51 | 92.73 | 2.42 | 70.74 | 1486 |
| 34 | 1.43 | 115.51 | 3.01 | 75.07 | 1487 | 94 | 1.49 | 97.59 | 2.54 | 71.79 | 1485 |
| 36 | 1.47 | 103.69 | 2.70 | 73.00 | 1487 | 96 | | | | | |
| 38 | 1.50 | 94.27 | 2.46 | 71.08 | 1489 | 98 | 1.49 | 96.13 | 2.51 | 71.48 | 1510 |
| 40 | 1.48 | 99.78 | 2.60 | 72.23 | 1489 | 100 | | | | | |
| 42 | 1.48 | 101.33 | 2.64 | 72.54 | 1490 | 102 | | | | | |
| 44 | 1.49 | 97.26 | 2.54 | 71.72 | 1492 | 104 | | | | | |
| 46 | 1.46 | 107.82 | 2.81 | 73.76 | 1492 | 106 | | | | | |
| 48 | 1.50 | 95.60 | 2.49 | 71.37 | 1492 | 108 | | | | | |
| 50 | 1.45 | 108.95 | 2.84 | 73.96 | 1490 | 110 | | | | | |
| 52 | 1.48 | 99.17 | 2.59 | 72.11 | 1487 | 112 | 1.50 | 94.33 | 2.46 | 71.10 | |
| 54 | 1.47 | 103.49 | 2.70 | 72.96 | 1487 | 114 | | | | | |
| 56 | 1.48 | 101.39 | 2.64 | 72.56 | 1487 | 116 | 1.54 | 84.33 | 2.20 | 68.74 | |
| 58 | 1.45 | 108.26 | 2.82 | 73.84 | 1492 | 118 | 1.57 | 76.37 | 1.99 | 66.57 | |
| | | | | | | 120 | 1.62 | 67.34 | 1.76 | 63.71 | |

HM 29

HM 29

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.61 | 70.04 | 1.83 | 64.62 | | 184 | 1.89 | 34.40 | 0.90 | 47.29 | 1559 |
| 124 | 1.64 | 63.69 | 1.66 | 62.42 | | 186 | 1.91 | 32.54 | 0.85 | 45.90 | 1558 |
| 126 | 1.69 | 56.53 | 1.47 | 59.58 | | 188 | 1.87 | 36.66 | 0.96 | 48.87 | 1557 |
| 128 | 1.68 | 58.56 | 1.53 | 60.43 | 1502 | 190 | 1.82 | 40.55 | 1.06 | 51.40 | 1541 |
| 130 | 1.68 | 57.68 | 1.50 | 60.06 | 1504 | 192 | 1.82 | 40.70 | 1.06 | 51.48 | |
| 132 | 1.64 | 64.40 | 1.68 | 62.67 | 1497 | 194 | 1.80 | 43.22 | 1.13 | 52.99 | |
| 134 | 1.69 | 56.75 | 1.48 | 59.67 | 1500 | 196 | 1.83 | 40.44 | 1.05 | 51.32 | 1568 |
| 136 | 1.69 | 56.25 | 1.47 | 59.46 | 1497 | 198 | | | | | 1574 |
| 138 | 1.69 | 56.34 | 1.47 | 59.50 | 1499 | | | | | | |
| 140 | 1.73 | 50.76 | 1.32 | 56.96 | 1514 | | | | | | |
| 142 | 1.79 | 43.97 | 1.15 | 53.41 | 1524 | | | | | | |
| 144 | 1.80 | 43.46 | 1.13 | 53.12 | 1524 | | | | | | |
| 146 | 1.74 | 50.21 | 1.31 | 56.69 | 1503 | | | | | | |
| 148 | 1.75 | 48.35 | 1.26 | 55.77 | 1510 | | | | | | |
| 150 | 1.79 | 44.33 | 1.16 | 53.61 | 1515 | | | | | | |
| 152 | 1.73 | 50.75 | 1.32 | 56.96 | 1506 | | | | | | |
| 154 | 1.72 | 52.15 | 1.36 | 57.62 | 1513 | | | | | | |
| 156 | 1.73 | 50.48 | 1.32 | 56.83 | 1510 | | | | | | |
| 158 | 1.78 | 45.35 | 1.18 | 54.18 | 1518 | | | | | | |
| 160 | 1.77 | 46.04 | 1.20 | 54.55 | 1517 | | | | | | |
| 162 | 1.77 | 46.42 | 1.21 | 54.76 | 1516 | | | | | | |
| 164 | 1.79 | 43.70 | 1.14 | 53.26 | 1519 | | | | | | |
| 166 | 1.83 | 39.92 | 1.04 | 51.00 | 1523 | | | | | | |
| 168 | 1.82 | 40.48 | 1.06 | 51.35 | 1529 | | | | | | |
| 170 | 1.87 | 36.70 | 0.96 | 48.90 | 1550 | | | | | | |
| 172 | 1.85 | 37.99 | 0.99 | 49.76 | 1550 | | | | | | |
| 174 | 1.85 | 37.89 | 0.99 | 49.70 | 1549 | | | | | | |
| 176 | 1.89 | 34.14 | 0.89 | 47.10 | 1556 | | | | | | |
| 178 | 1.89 | 34.54 | 0.90 | 47.39 | 1557 | | | | | | |
| 180 | 1.87 | 36.42 | 0.95 | 48.71 | 1555 | | | | | | |
| 182 | 1.89 | 34.20 | 0.89 | 47.14 | 1559 | | | | | | |

HM 31

HM 31

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.52 | 89.94 | 2.35 | 70.11 | 1490 |
| 2 | | | | | | 62 | 1.54 | 85.15 | 2.22 | 68.95 | 1489 |
| 4 | | | | | | 64 | 1.52 | 87.73 | 2.29 | 69.58 | 1490 |
| 6 | | | | | | 66 | 1.51 | 92.02 | 2.40 | 70.58 | 1489 |
| 8 | | | | | | 68 | 1.49 | 97.66 | 2.55 | 71.80 | 1493 |
| 10 | | | | | | 70 | 1.51 | 91.48 | 2.39 | 70.46 | 1491 |
| 12 | | | | | | 72 | 1.50 | 93.05 | 2.43 | 70.81 | 1501 |
| 14 | 1.40 | 130.71 | 3.41 | 77.32 | | 74 | 1.48 | 98.90 | 2.58 | 72.06 | 1505 |
| 16 | 1.38 | 139.40 | 3.63 | 78.42 | | 76 | 1.51 | 90.62 | 2.36 | 70.26 | 1505 |
| 18 | | | | | | 78 | 1.50 | 95.36 | 2.49 | 71.32 | 1506 |
| 20 | 1.46 | 105.31 | 2.75 | 73.30 | | 80 | 1.49 | 97.74 | 2.55 | 71.82 | 1509 |
| 22 | 1.46 | 105.52 | 2.75 | 73.34 | | 82 | 1.52 | 89.75 | 2.34 | 70.06 | 1506 |
| 24 | 1.49 | 95.84 | 2.50 | 71.42 | | 84 | 1.53 | 87.26 | 2.28 | 69.47 | 1498 |
| 26 | 1.46 | 105.90 | 2.76 | 73.41 | | 86 | 1.52 | 89.82 | 2.34 | 70.08 | 1499 |
| 28 | 1.42 | 121.59 | 3.17 | 76.02 | | 88 | 1.47 | 103.75 | 2.71 | 73.01 | 1492 |
| 30 | 1.46 | 107.67 | 2.81 | 73.74 | 1491 | 90 | 1.49 | 97.30 | 2.54 | 71.73 | 1499 |
| 32 | 1.47 | 102.05 | 2.66 | 72.68 | 1494 | 92 | 1.54 | 83.68 | 2.18 | 68.57 | 1509 |
| 34 | 1.48 | 99.74 | 2.60 | 72.23 | 1494 | 94 | 1.48 | 100.15 | 2.61 | 72.31 | 1466 |
| 36 | 1.46 | 107.45 | 2.80 | 73.70 | 1500 | 96 | 1.43 | 117.85 | 3.07 | 75.45 | |
| 38 | 1.50 | 95.45 | 2.49 | 71.34 | 1494 | 98 | 1.52 | 89.66 | 2.34 | 70.04 | 1472 |
| 40 | 1.48 | 100.17 | 2.61 | 72.31 | 1490 | 100 | 1.51 | 91.07 | 2.37 | 70.37 | |
| 42 | 1.49 | 97.90 | 2.55 | 71.85 | 1490 | 102 | 1.36 | 146.97 | 3.83 | 79.31 | |
| 44 | 1.45 | 108.44 | 2.83 | 73.87 | 1497 | 104 | 1.36 | 149.54 | 3.90 | 79.59 | |
| 46 | 1.47 | 103.18 | 2.69 | 72.90 | 1499 | 106 | 1.41 | 125.93 | 3.28 | 76.65 | |
| 48 | 1.47 | 103.85 | 2.71 | 73.03 | 1502 | 108 | 1.34 | 161.33 | 4.21 | 80.79 | |
| 50 | 1.50 | 94.29 | 2.46 | 71.09 | 1488 | 110 | | | | | |
| 52 | 1.49 | 97.66 | 2.55 | 71.80 | 1484 | 112 | 1.33 | 167.50 | 4.37 | 81.37 | |
| 54 | 1.50 | 93.10 | 2.43 | 70.83 | 1484 | 114 | 1.42 | 120.99 | 3.15 | 75.93 | |
| 56 | 1.48 | 99.24 | 2.59 | 72.13 | 1486 | 116 | 1.42 | 119.10 | 3.11 | 75.64 | |
| 58 | 1.51 | 91.85 | 2.39 | 70.54 | 1485 | 118 | 1.40 | 129.12 | 3.37 | 77.10 | |
| | | | | | | 120 | | | | | |

HM 31

HM 31

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.46 | 107.61 | 2.81 | 73.72 | | 184 | 1.50 | 94.01 | 2.45 | 71.03 | 1483 |
| 124 | 1.46 | 107.04 | 2.79 | 73.62 | | 186 | 1.50 | 94.08 | 2.45 | 71.04 | 1485 |
| 126 | 1.45 | 111.24 | 2.90 | 74.36 | | 188 | 1.50 | 93.16 | 2.43 | 70.84 | 1484 |
| 128 | 1.42 | 120.49 | 3.14 | 75.86 | | 190 | 1.52 | 89.01 | 2.32 | 69.89 | 1485 |
| 130 | 1.41 | 126.95 | 3.31 | 76.80 | | 192 | | | | | |
| 132 | 1.45 | 109.40 | 2.85 | 74.04 | | 194 | 1.53 | 85.87 | 2.24 | 69.13 | 1511 |
| 134 | 1.47 | 103.76 | 2.71 | 73.01 | | 196 | 1.55 | 81.77 | 2.13 | 68.07 | 1511 |
| 136 | 1.48 | 101.01 | 2.63 | 72.48 | | 198 | | | | | |
| 138 | 1.46 | 105.09 | 2.74 | 73.26 | | 200 | | | | | |
| 140 | 1.49 | 95.94 | 2.50 | 71.44 | | 202 | | | | | |
| 142 | 1.50 | 93.88 | 2.45 | 71.00 | | 204 | | | | | |
| 144 | 1.51 | 91.55 | 2.39 | 70.48 | 1484 | 206 | | | | | |
| 146 | 1.49 | 97.08 | 2.53 | 71.68 | 1473 | 208 | 1.45 | 108.12 | 2.82 | 73.82 | |
| 148 | 1.52 | 89.60 | 2.34 | 70.03 | 1480 | 210 | 1.48 | 101.31 | 2.64 | 72.54 | |
| 150 | 1.50 | 95.29 | 2.48 | 71.30 | 1484 | 212 | 1.52 | 88.77 | 2.31 | 69.83 | |
| 152 | 1.50 | 92.95 | 2.42 | 70.79 | 1483 | 214 | 1.54 | 84.74 | 2.21 | 68.84 | |
| 154 | 1.54 | 84.52 | 2.20 | 68.79 | 1485 | 216 | 1.52 | 89.84 | 2.34 | 70.08 | |
| 156 | 1.52 | 87.78 | 2.29 | 69.59 | 1485 | 218 | 1.55 | 82.42 | 2.15 | 68.24 | |
| 158 | 1.52 | 89.83 | 2.34 | 70.08 | 1486 | 220 | 1.55 | 81.06 | 2.11 | 67.88 | 1486 |
| 160 | 1.48 | 100.40 | 2.62 | 72.36 | 1486 | 222 | 1.52 | 89.76 | 2.34 | 70.06 | 1485 |
| 162 | 1.52 | 89.73 | 2.34 | 70.06 | 1483 | 224 | 1.50 | 93.02 | 2.43 | 70.81 | 1483 |
| 164 | 1.52 | 89.03 | 2.32 | 69.89 | 1484 | 226 | 1.50 | 92.91 | 2.42 | 70.78 | 1485 |
| 166 | 1.53 | 86.17 | 2.25 | 69.20 | 1484 | 228 | 1.52 | 89.17 | 2.32 | 69.92 | 1485 |
| 168 | 1.51 | 90.46 | 2.36 | 70.23 | 1483 | 230 | 1.51 | 90.64 | 2.36 | 70.27 | 1485 |
| 170 | 1.52 | 89.15 | 2.32 | 69.92 | 1483 | 232 | 1.50 | 94.50 | 2.46 | 71.13 | 1484 |
| 172 | 1.51 | 92.82 | 2.42 | 70.76 | 1484 | 234 | 1.51 | 91.70 | 2.39 | 70.51 | 1484 |
| 174 | 1.52 | 88.41 | 2.31 | 69.74 | 1484 | 236 | 1.50 | 94.67 | 2.47 | 71.17 | 1482 |
| 176 | 1.52 | 89.06 | 2.32 | 69.90 | 1485 | 238 | 1.48 | 99.11 | 2.58 | 72.10 | 1482 |
| 178 | 1.50 | 95.48 | 2.49 | 71.34 | 1483 | 240 | 1.50 | 94.95 | 2.48 | 71.23 | 1483 |
| 180 | 1.51 | 91.54 | 2.39 | 70.47 | 1483 | 242 | 1.51 | 90.39 | 2.36 | 70.21 | 1485 |
| 182 | 1.51 | 91.92 | 2.40 | 70.56 | 1483 | 244 | 1.51 | 91.85 | 2.39 | 70.54 | 1483 |

HM 31

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.52 | 89.81 | 2.34 | 70.08 | 1484 |
| 248 | 1.51 | 90.23 | 2.35 | 70.17 | 1483 |
| 250 | 1.50 | 93.13 | 2.43 | 70.83 | 1483 |
| 252 | 1.49 | 97.69 | 2.55 | 71.81 | 1482 |
| 254 | 1.50 | 92.96 | 2.42 | 70.79 | 1484 |
| 256 | 1.51 | 92.21 | 2.40 | 70.62 | 1484 |
| 258 | 1.53 | 86.51 | 2.26 | 69.28 | 1485 |
| 260 | 1.51 | 92.27 | 2.41 | 70.64 | 1483 |
| 262 | 1.49 | 95.90 | 2.50 | 71.43 | 1484 |
| 264 | 1.50 | 93.81 | 2.45 | 70.98 | 1484 |
| 266 | 1.47 | 101.67 | 2.65 | 72.61 | 1482 |
| 268 | 1.49 | 97.58 | 2.54 | 71.79 | 1483 |
| 270 | 1.52 | 88.79 | 2.32 | 69.83 | 1484 |
| 272 | 1.50 | 94.63 | 2.47 | 71.16 | 1482 |
| 274 | 1.48 | 99.54 | 2.60 | 72.19 | 1481 |
| 276 | 1.51 | 91.65 | 2.39 | 70.50 | 1482 |
| 278 | 1.51 | 90.75 | 2.37 | 70.29 | 1484 |
| 280 | 1.53 | 86.79 | 2.26 | 69.35 | 1484 |
| 282 | 1.51 | 92.02 | 2.40 | 70.58 | 1484 |
| 284 | 1.47 | 104.17 | 2.72 | 73.09 | 1482 |
| 286 | 1.50 | 93.68 | 2.44 | 70.95 | 1484 |
| 288 | 1.52 | 87.96 | 2.29 | 69.64 | 1486 |
| 290 | 1.50 | 94.73 | 2.47 | 71.18 | 1484 |
| 292 | 1.48 | 101.16 | 2.64 | 72.51 | 1483 |
| 294 | 1.47 | 104.64 | 2.73 | 73.18 | 1481 |
| 296 | 1.41 | 124.16 | 3.24 | 76.40 | |
| 298 | 1.49 | 97.36 | 2.54 | 71.74 | 1500 |

HM 32

HM 32

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.77 | 46.56 | 1.21 | 54.83 | 1526 |
| 2 | | | | | | 62 | 1.82 | 40.72 | 1.06 | 51.50 | 1559 |
| 4 | | | | | | 64 | 1.84 | 39.14 | 1.02 | 50.51 | 1550 |
| 6 | | | | | | 66 | 1.87 | 36.39 | 0.95 | 48.69 | 1556 |
| 8 | | | | | | 68 | 1.84 | 38.68 | 1.01 | 50.21 | 1557 |
| 10 | | | | | | 70 | 1.87 | 36.04 | 0.94 | 48.45 | 1553 |
| 12 | | | | | | 72 | 1.86 | 36.97 | 0.96 | 49.09 | 1556 |
| 14 | | | | | | 74 | 1.88 | 35.38 | 0.92 | 47.99 | 1557 |
| 16 | | | | | | 76 | 1.89 | 34.50 | 0.90 | 47.35 | 1558 |
| 18 | | | | | 1492 | 78 | 1.87 | 36.35 | 0.95 | 48.66 | 1557 |
| 20 | 1.52 | 88.97 | 2.32 | 69.88 | 1502 | 80 | 1.88 | 35.10 | 0.92 | 47.79 | 1558 |
| 22 | 1.51 | 92.36 | 2.41 | 70.66 | 1501 | 82 | 1.88 | 35.29 | 0.92 | 47.92 | 1560 |
| 24 | 1.62 | 67.65 | 1.76 | 63.82 | 1508 | 84 | 1.90 | 33.70 | 0.88 | 46.77 | 1559 |
| 26 | 1.70 | 55.44 | 1.45 | 59.11 | 1516 | 86 | 2.00 | 26.03 | 0.68 | 40.43 | 1556 |
| 28 | 1.71 | 53.61 | 1.40 | 58.29 | 1518 | 88 | 1.83 | 40.31 | 1.05 | 51.25 | |
| 30 | 1.89 | 34.19 | 0.89 | 47.13 | 1591 | 90 | 1.85 | 38.02 | 0.99 | 49.78 | 1548 |
| 32 | 1.91 | 32.98 | 0.86 | 46.24 | 1574 | 92 | 1.73 | 51.27 | 1.34 | 57.21 | |
| 34 | 1.86 | 37.37 | 0.97 | 49.35 | 1564 | | | | | | |
| 36 | 1.79 | 44.06 | 1.15 | 53.46 | 1532 | | | | | | |
| 38 | 1.73 | 50.77 | 1.32 | 56.97 | 1517 | | | | | | |
| 40 | 1.74 | 49.80 | 1.30 | 56.50 | 1550 | | | | | | |
| 42 | 1.63 | 64.97 | 1.69 | 62.88 | 1492 | | | | | | |
| 44 | 1.64 | 63.85 | 1.66 | 62.47 | 1495 | | | | | | |
| 46 | 1.57 | 76.26 | 1.99 | 66.54 | 1488 | | | | | | |
| 48 | 1.62 | 67.73 | 1.77 | 63.85 | 1488 | | | | | | |
| 50 | 1.74 | 49.95 | 1.30 | 56.57 | 1516 | | | | | | |
| 52 | 1.73 | 51.64 | 1.35 | 57.38 | 1516 | | | | | | |
| 54 | 1.72 | 52.53 | 1.37 | 57.80 | 1516 | | | | | | |
| 56 | 1.76 | 47.12 | 1.23 | 55.13 | 1522 | | | | | | |
| 58 | 1.75 | 48.29 | 1.26 | 55.74 | 1523 | | | | | | |

HM 34

HM 34

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.78 | 45.09 | 1.18 | 54.03 | 1529 |
| 2 | | | | | | 62 | 1.81 | 41.62 | 1.09 | 52.04 | 1529 |
| 4 | | | | | | 64 | 1.83 | 40.33 | 1.05 | 51.25 | 1553 |
| 6 | | | | | | 66 | 1.85 | 37.94 | 0.99 | 49.73 | 1558 |
| 8 | | | | | | 68 | 1.83 | 39.97 | 1.04 | 51.03 | 1544 |
| 10 | | | | | | 70 | 1.90 | 34.06 | 0.89 | 47.04 | 1552 |
| 12 | | | | | | 72 | 1.88 | 35.51 | 0.93 | 48.08 | 1552 |
| 14 | 1.48 | 99.19 | 2.59 | 72.12 | | 74 | 1.90 | 33.74 | 0.88 | 46.80 | 1554 |
| 16 | 1.49 | 97.06 | 2.53 | 71.68 | | 76 | 1.87 | 35.86 | 0.93 | 48.32 | 1555 |
| 18 | 1.52 | 88.96 | 2.32 | 69.88 | | 78 | 1.86 | 36.81 | 0.96 | 48.97 | 1555 |
| 20 | 1.49 | 98.51 | 2.57 | 71.98 | | 80 | 1.91 | 33.16 | 0.86 | 46.37 | 1553 |
| 22 | 1.59 | 74.01 | 1.93 | 65.87 | | 82 | 1.88 | 35.68 | 0.93 | 48.20 | 1556 |
| 24 | 1.68 | 58.50 | 1.53 | 60.40 | | 84 | 1.90 | 33.67 | 0.88 | 46.75 | 1557 |
| 26 | 1.69 | 56.79 | 1.48 | 59.69 | | 86 | 1.89 | 34.40 | 0.90 | 47.28 | 1557 |
| 28 | 1.76 | 47.70 | 1.24 | 55.43 | | 88 | 1.92 | 32.31 | 0.84 | 45.72 | 1557 |
| 30 | 1.71 | 54.14 | 1.41 | 58.53 | | 90 | 1.92 | 32.03 | 0.84 | 45.51 | 1557 |
| 32 | 1.69 | 56.63 | 1.48 | 59.62 | 1475 | 92 | 1.89 | 34.27 | 0.89 | 47.19 | 1559 |
| 34 | 1.69 | 56.43 | 1.47 | 59.54 | 1513 | 94 | 1.90 | 33.51 | 0.87 | 46.63 | 1557 |
| 36 | 1.75 | 49.15 | 1.28 | 56.17 | 1519 | 96 | 1.93 | 31.33 | 0.82 | 44.96 | 1555 |
| 38 | 1.83 | 39.64 | 1.03 | 50.83 | | 98 | 1.90 | 33.59 | 0.88 | 46.69 | 1557 |
| 40 | 1.73 | 51.48 | 1.34 | 57.30 | 1508 | 100 | 1.88 | 35.68 | 0.93 | 48.19 | 1558 |
| 42 | 1.67 | 59.36 | 1.55 | 60.75 | 1498 | 102 | 1.90 | 34.07 | 0.89 | 47.05 | 1557 |
| 44 | 1.64 | 64.49 | 1.68 | 62.71 | 1494 | 104 | 1.90 | 33.56 | 0.87 | 46.66 | 1559 |
| 46 | 1.69 | 56.48 | 1.47 | 59.56 | 1506 | 106 | 1.90 | 33.54 | 0.87 | 46.65 | 1560 |
| 48 | 1.69 | 56.10 | 1.46 | 59.39 | 1507 | 108 | 1.90 | 33.66 | 0.88 | 46.74 | 1560 |
| 50 | 1.72 | 52.63 | 1.37 | 57.85 | 1513 | 110 | 1.90 | 34.03 | 0.89 | 47.02 | 1559 |
| 52 | 1.76 | 46.95 | 1.22 | 55.04 | 1527 | 112 | 1.91 | 32.67 | 0.85 | 46.00 | 1560 |
| 54 | 1.79 | 44.25 | 1.15 | 53.57 | 1528 | 114 | 1.91 | 32.85 | 0.86 | 46.14 | 1566 |
| 56 | 1.76 | 47.52 | 1.24 | 55.34 | 1523 | 116 | | | | | |
| 58 | 1.75 | 48.24 | 1.26 | 55.71 | 1524 | 118 | | | | | 1552 |
| | | | | | | 120 | | | | | 1542 |

HM 36

HM 36

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 0 | | | | | | 60 | 1.74 | 49.40 | 1.29 | 56.30 | 1512 |
| 2 | | | | | | 62 | 1.73 | 51.39 | 1.34 | 57.26 | 1509 |
| 4 | 1.64 | 64.83 | 1.69 | 62.83 | | 64 | 1.75 | 49.16 | 1.28 | 56.18 | 1513 |
| 6 | 1.62 | 67.67 | 1.76 | 63.83 | | 66 | 1.77 | 46.02 | 1.20 | 54.55 | 1509 |
| 8 | 1.66 | 61.09 | 1.59 | 61.43 | | 68 | 1.79 | 43.96 | 1.15 | 53.41 | 1526 |
| 10 | 1.71 | 53.06 | 1.38 | 58.04 | | 70 | 1.74 | 50.33 | 1.31 | 56.75 | 1514 |
| 12 | 1.67 | 60.12 | 1.57 | 61.05 | | 72 | 1.72 | 52.92 | 1.38 | 57.98 | 1507 |
| 14 | 1.68 | 57.90 | 1.51 | 60.15 | 1450 | 74 | 1.75 | 48.95 | 1.28 | 56.07 | 1511 |
| 16 | 1.72 | 52.47 | 1.37 | 57.77 | | 76 | 1.73 | 50.67 | 1.32 | 56.92 | 1508 |
| 18 | 1.70 | 54.67 | 1.43 | 58.77 | | 78 | 1.75 | 48.49 | 1.26 | 55.84 | 1511 |
| 20 | 1.70 | 55.27 | 1.44 | 59.04 | | 80 | 1.77 | 46.69 | 1.22 | 54.90 | 1517 |
| 22 | 1.70 | 55.51 | 1.45 | 59.14 | | 82 | 1.65 | 62.91 | 1.64 | 62.13 | 1524 |
| 24 | 1.71 | 53.89 | 1.41 | 58.42 | | 84 | 1.66 | 60.99 | 1.59 | 61.39 | 1486 |
| 26 | 1.68 | 58.41 | 1.52 | 60.36 | | 86 | 1.69 | 56.23 | 1.47 | 59.45 | |
| 28 | 1.69 | 55.93 | 1.46 | 59.32 | | 88 | 1.71 | 53.43 | 1.39 | 58.22 | |
| 30 | 1.65 | 63.09 | 1.65 | 62.19 | | 90 | 1.70 | 55.15 | 1.44 | 58.98 | 1527 |
| 32 | 1.71 | 53.77 | 1.40 | 58.37 | | 92 | 1.73 | 51.66 | 1.35 | 57.39 | |
| 34 | 1.68 | 57.84 | 1.51 | 60.13 | | 94 | 1.81 | 42.45 | 1.11 | 52.54 | 1572 |
| 36 | 1.68 | 57.70 | 1.50 | 60.07 | 1490 | 96 | 1.77 | 46.48 | 1.21 | 54.79 | |
| 38 | 1.71 | 53.11 | 1.38 | 58.07 | 1507 | | | | | | |
| 40 | 1.69 | 57.10 | 1.49 | 59.82 | 1502 | | | | | | |
| 42 | 1.71 | 53.81 | 1.40 | 58.39 | 1505 | | | | | | |
| 44 | 1.75 | 49.14 | 1.28 | 56.16 | 1512 | | | | | | |
| 46 | 1.73 | 50.88 | 1.33 | 57.02 | 1504 | | | | | | |
| 48 | 1.71 | 54.23 | 1.41 | 58.58 | 1501 | | | | | | |
| 50 | 1.75 | 48.18 | 1.26 | 55.68 | 1512 | | | | | | |
| 52 | 1.72 | 51.96 | 1.35 | 57.53 | 1515 | | | | | | |
| 54 | 1.74 | 50.27 | 1.31 | 56.72 | 1517 | | | | | | |
| 56 | 1.78 | 44.65 | 1.16 | 53.79 | 1515 | | | | | | |
| 58 | 1.77 | 46.60 | 1.22 | 54.86 | 1520 | | | | | | |

HM 37

HM 37

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.85 | 37.77 | 0.98 | 49.62 | 1548 |
| 2 | | | | | | 62 | 1.86 | 37.29 | 0.97 | 49.30 | 1549 |
| 4 | | | | | | 64 | 1.89 | 34.18 | 0.89 | 47.12 | 1551 |
| 6 | | | | | | 66 | 1.86 | 36.94 | 0.96 | 49.07 | 1555 |
| 8 | 1.56 | 79.95 | 2.08 | 67.58 | 1507 | 68 | 1.90 | 33.86 | 0.88 | 46.89 | 1556 |
| 10 | 1.54 | 84.41 | 2.20 | 68.76 | 1500 | 70 | 1.87 | 36.55 | 0.95 | 48.80 | 1551 |
| 12 | 1.53 | 86.78 | 2.26 | 69.35 | 1491 | 72 | 1.86 | 37.14 | 0.97 | 49.20 | 1551 |
| 14 | 1.55 | 82.38 | 2.15 | 68.23 | 1495 | 74 | 1.88 | 35.80 | 0.93 | 48.28 | 1554 |
| 16 | 1.56 | 79.25 | 2.07 | 67.39 | 1500 | 76 | 1.89 | 34.18 | 0.89 | 47.13 | 1552 |
| 18 | 1.64 | 64.41 | 1.68 | 62.68 | 1504 | 78 | 1.88 | 35.33 | 0.92 | 47.95 | 1551 |
| 20 | 1.69 | 55.95 | 1.46 | 59.33 | 1515 | 80 | 1.90 | 33.44 | 0.87 | 46.58 | 1550 |
| 22 | 1.72 | 52.53 | 1.37 | 57.80 | 1514 | 82 | 1.90 | 33.95 | 0.89 | 46.95 | 1549 |
| 24 | 1.72 | 52.90 | 1.38 | 57.97 | 1510 | 84 | 1.88 | 35.57 | 0.93 | 48.12 | 1556 |
| 26 | 1.71 | 54.27 | 1.41 | 58.59 | 1509 | 86 | 1.90 | 33.54 | 0.87 | 46.65 | 1550 |
| 28 | 1.72 | 52.69 | 1.37 | 57.88 | 1515 | 88 | 1.88 | 35.65 | 0.93 | 48.17 | 1554 |
| 30 | 1.69 | 55.74 | 1.45 | 59.24 | 1514 | 90 | 1.87 | 35.85 | 0.93 | 48.31 | 1554 |
| 32 | 1.73 | 50.62 | 1.32 | 56.89 | 1516 | 92 | 1.86 | 37.04 | 0.97 | 49.13 | 1551 |
| 34 | 1.65 | 62.99 | 1.64 | 62.16 | 1496 | 94 | 1.83 | 40.24 | 1.05 | 51.20 | |
| 36 | 1.67 | 59.27 | 1.55 | 60.71 | 1499 | 96 | 1.79 | 43.64 | 1.14 | 53.23 | |
| 38 | 1.67 | 59.75 | 1.56 | 60.91 | 1494 | 98 | 1.91 | 32.55 | 0.85 | 45.91 | |
| 40 | 1.65 | 62.66 | 1.63 | 62.03 | 1491 | 100 | | | | | |
| 42 | 1.77 | 46.72 | 1.22 | 54.92 | 1532 | 102 | | | | | |
| 44 | 1.77 | 46.31 | 1.21 | 54.70 | 1516 | 104 | 1.91 | 32.54 | 0.85 | 45.90 | 1570 |
| 46 | 1.76 | 47.58 | 1.24 | 55.37 | 1521 | 106 | 1.93 | 31.59 | 0.82 | 45.16 | 1571 |
| 48 | 1.74 | 49.25 | 1.28 | 56.22 | 1516 | 108 | 1.88 | 35.63 | 0.93 | 48.16 | 1565 |
| 50 | 1.74 | 49.49 | 1.29 | 56.34 | 1520 | 110 | 1.91 | 33.05 | 0.86 | 46.28 | 1566 |
| 52 | 1.77 | 45.91 | 1.20 | 54.48 | 1520 | 112 | 1.85 | 37.65 | 0.98 | 49.54 | 1552 |
| 54 | 1.83 | 40.17 | 1.05 | 51.16 | 1556 | 114 | 1.89 | 34.48 | 0.90 | 47.34 | 1560 |
| 56 | 1.86 | 37.37 | 0.97 | 49.35 | 1554 | 116 | 1.88 | 35.14 | 0.92 | 47.82 | 1556 |
| 58 | 1.84 | 38.63 | 1.01 | 50.18 | 1549 | 118 | 1.88 | 35.43 | 0.92 | 48.02 | 1554 |
| | | | | | | 120 | 1.91 | 32.79 | 0.86 | 46.09 | 1552 |

HM 37

HM 37

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.89 | 34.30 | 0.89 | 47.21 | 1556 | 184 | 1.91 | 32.91 | 0.86 | 46.18 | 1560 |
| 124 | 1.90 | 34.12 | 0.89 | 47.08 | 1553 | 186 | 1.91 | 32.63 | 0.85 | 45.97 | 1561 |
| 126 | 1.90 | 33.94 | 0.88 | 46.95 | 1555 | 188 | 1.93 | 31.24 | 0.81 | 44.89 | 1561 |
| 128 | 1.89 | 34.43 | 0.90 | 47.31 | 1559 | 190 | 1.96 | 29.24 | 0.76 | 43.26 | |
| 130 | 1.96 | 28.87 | 0.75 | 42.95 | | 192 | 1.95 | 29.96 | 0.78 | 43.86 | 1560 |
| 132 | 1.88 | 35.16 | 0.92 | 47.83 | 1555 | 194 | 1.93 | 31.03 | 0.81 | 44.72 | 1565 |
| 134 | 1.93 | 31.01 | 0.81 | 44.71 | 1551 | 196 | 1.93 | 31.43 | 0.82 | 45.04 | 1565 |
| 136 | 1.89 | 34.59 | 0.90 | 47.42 | 1555 | 198 | 1.94 | 30.64 | 0.80 | 44.41 | 1567 |
| 138 | 1.89 | 34.33 | 0.90 | 47.24 | 1555 | 200 | 1.94 | 30.70 | 0.80 | 44.46 | 1567 |
| 140 | 1.91 | 33.12 | 0.86 | 46.34 | 1553 | 202 | 1.94 | 30.68 | 0.80 | 44.45 | 1569 |
| 142 | 1.90 | 33.95 | 0.89 | 46.95 | 1554 | 204 | 1.94 | 30.37 | 0.79 | 44.19 | 1568 |
| 144 | 1.92 | 32.47 | 0.85 | 45.84 | 1555 | 206 | 1.96 | 28.81 | 0.75 | 42.90 | 1569 |
| 146 | 1.91 | 32.68 | 0.85 | 46.01 | 1557 | 208 | 1.98 | 27.50 | 0.72 | 41.76 | 1568 |
| 148 | 1.93 | 31.64 | 0.82 | 45.20 | 1557 | 210 | 1.91 | 32.51 | 0.85 | 45.88 | 1572 |
| 150 | 1.92 | 32.44 | 0.85 | 45.82 | 1561 | 212 | 1.95 | 29.99 | 0.78 | 43.89 | 1566 |
| 152 | 1.92 | 32.14 | 0.84 | 45.60 | 1559 | 214 | 1.95 | 29.62 | 0.77 | 43.58 | 1575 |
| 154 | 1.92 | 31.88 | 0.83 | 45.39 | 1559 | 216 | 1.95 | 29.86 | 0.78 | 43.78 | 1579 |
| 156 | 1.94 | 30.89 | 0.81 | 44.61 | 1559 | 218 | 1.95 | 30.17 | 0.79 | 44.03 | |
| 158 | 1.92 | 32.14 | 0.84 | 45.59 | 1557 | 220 | 1.92 | 32.47 | 0.85 | 45.85 | |
| 160 | 1.92 | 31.84 | 0.83 | 45.36 | 1562 | 222 | 1.88 | 35.82 | 0.93 | 48.29 | |
| 162 | 1.91 | 32.85 | 0.86 | 46.14 | 1557 | 224 | 1.97 | 28.58 | 0.75 | 42.70 | |
| 164 | 1.92 | 32.41 | 0.85 | 45.80 | 1558 | 226 | 2.02 | 25.02 | 0.65 | 39.48 | |
| 166 | 1.92 | 32.23 | 0.84 | 45.66 | 1559 | | | | | | |
| 168 | 1.91 | 33.17 | 0.86 | 46.38 | 1562 | | | | | | |
| 170 | 1.93 | 31.58 | 0.82 | 45.16 | 1560 | | | | | | |
| 172 | 1.89 | 34.27 | 0.89 | 47.19 | 1560 | | | | | | |
| 174 | 1.90 | 34.04 | 0.89 | 47.02 | 1562 | | | | | | |
| 176 | 1.94 | 30.44 | 0.79 | 44.25 | 1559 | | | | | | |
| 178 | 1.92 | 31.87 | 0.83 | 45.39 | 1562 | | | | | | |
| 180 | 1.91 | 32.93 | 0.86 | 46.19 | 1563 | | | | | | |
| 182 | 1.92 | 31.89 | 0.83 | 45.40 | 1559 | | | | | | |

HM 38

HM 38

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.87 | 36.15 | 0.94 | 48.52 | 1557 |
| 2 | | | | | | 62 | 1.67 | 59.26 | 1.55 | 60.71 | 1513 |
| 4 | | | | | | 64 | 1.76 | 47.17 | 1.23 | 55.16 | 1525 |
| 6 | | | | | | 66 | 1.74 | 50.39 | 1.31 | 56.78 | 1522 |
| 8 | | | | | | 68 | 1.77 | 46.72 | 1.22 | 54.92 | 1523 |
| 10 | | | | | 1503 | 70 | 1.74 | 49.33 | 1.29 | 56.26 | 1524 |
| 12 | | | | | 1497 | 72 | 1.76 | 46.86 | 1.22 | 54.99 | 1528 |
| 14 | 1.48 | 101.52 | 2.65 | 72.58 | 1491 | 74 | 1.82 | 41.45 | 1.08 | 51.94 | 1546 |
| 16 | 1.48 | 98.85 | 2.58 | 72.05 | 1493 | 76 | 1.84 | 39.07 | 1.02 | 50.46 | 1543 |
| 18 | 1.53 | 86.57 | 2.26 | 69.30 | 1496 | 78 | 1.82 | 41.18 | 1.07 | 51.78 | 1544 |
| 20 | 1.59 | 72.37 | 1.89 | 65.36 | 1505 | 80 | 1.84 | 39.10 | 1.02 | 50.48 | 1548 |
| 22 | 1.63 | 65.12 | 1.70 | 62.94 | 1512 | 82 | 1.85 | 38.16 | 1.00 | 49.88 | 1547 |
| 24 | 1.65 | 62.98 | 1.64 | 62.15 | 1511 | 84 | 1.85 | 38.15 | 0.99 | 49.87 | 1548 |
| 26 | 1.68 | 57.40 | 1.50 | 59.94 | 1509 | 86 | 1.84 | 38.68 | 1.01 | 50.21 | 1550 |
| 28 | 1.65 | 61.89 | 1.61 | 61.74 | 1510 | 88 | 1.84 | 39.10 | 1.02 | 50.48 | 1551 |
| 30 | 1.64 | 64.00 | 1.67 | 62.53 | 1508 | 90 | 1.87 | 36.39 | 0.95 | 48.68 | 1552 |
| 32 | 1.69 | 56.39 | 1.47 | 59.52 | 1519 | 92 | 1.85 | 37.62 | 0.98 | 49.52 | 1553 |
| 34 | 1.65 | 63.12 | 1.65 | 62.20 | 1507 | 94 | 1.79 | 43.93 | 1.15 | 53.39 | |
| 36 | 1.65 | 61.91 | 1.61 | 61.75 | 1502 | 96 | 1.84 | 39.01 | 1.02 | 50.43 | 1547 |
| 38 | 1.66 | 61.28 | 1.60 | 61.51 | 1503 | 98 | 1.91 | 33.14 | 0.86 | 46.35 | |
| 40 | 1.64 | 64.09 | 1.67 | 62.56 | 1499 | 100 | | | | | |
| 42 | 1.60 | 71.98 | 1.88 | 65.24 | 1488 | 102 | | | | | |
| 44 | 1.61 | 69.58 | 1.81 | 64.47 | 1490 | 104 | 1.82 | 41.36 | 1.08 | 51.88 | |
| 46 | 1.85 | 37.71 | 0.98 | 49.57 | 1551 | 106 | 1.79 | 43.98 | 1.15 | 53.42 | |
| 48 | 1.87 | 36.27 | 0.95 | 48.60 | 1550 | 108 | 1.86 | 37.31 | 0.97 | 49.31 | |
| 50 | 1.83 | 40.28 | 1.05 | 51.22 | 1544 | 110 | 1.88 | 35.43 | 0.92 | 48.02 | |
| 52 | 1.78 | 45.00 | 1.17 | 53.99 | 1536 | 112 | 1.92 | 31.91 | 0.83 | 45.42 | |
| 54 | 1.82 | 41.45 | 1.08 | 51.94 | 1547 | 114 | 1.86 | 36.82 | 0.96 | 48.98 | 1427 |
| 56 | 1.93 | 31.14 | 0.81 | 44.81 | 1586 | 116 | 1.85 | 38.42 | 1.00 | 50.05 | 1559 |
| 58 | 1.92 | 31.98 | 0.83 | 45.47 | 1571 | 118 | 1.87 | 36.42 | 0.95 | 48.71 | 1561 |
| | | | | | | 120 | 1.85 | 38.01 | 0.99 | 49.77 | 1559 |

HM 38

HM 38

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.86 | 37.35 | 0.97 | 49.34 | 1557 | 184 | 1.88 | 35.56 | 0.93 | 48.11 | 1558 |
| 124 | 1.85 | 37.89 | 0.99 | 49.70 | 1555 | 186 | 1.87 | 36.24 | 0.95 | 48.59 | 1558 |
| 126 | 1.86 | 37.08 | 0.97 | 49.16 | 1553 | 188 | 1.87 | 36.17 | 0.94 | 48.54 | 1560 |
| 128 | 1.85 | 38.06 | 0.99 | 49.81 | 1552 | 190 | 1.85 | 37.71 | 0.98 | 49.58 | 1559 |
| 130 | 1.87 | 36.69 | 0.96 | 48.89 | 1552 | 192 | 1.86 | 37.11 | 0.97 | 49.17 | 1563 |
| 132 | 1.85 | 38.01 | 0.99 | 49.78 | 1551 | 194 | 1.83 | 40.10 | 1.05 | 51.11 | |
| 134 | 1.85 | 37.86 | 0.99 | 49.68 | 1551 | 196 | 1.84 | 38.93 | 1.02 | 50.37 | |
| 136 | 1.89 | 34.27 | 0.89 | 47.19 | 1551 | 198 | 1.91 | 32.51 | 0.85 | 45.88 | |
| 138 | 1.84 | 38.81 | 1.01 | 50.30 | 1550 | 200 | | | | | |
| 140 | 1.87 | 36.16 | 0.94 | 48.53 | 1554 | 202 | 1.87 | 35.96 | 0.94 | 48.39 | |
| 142 | 1.85 | 37.90 | 0.99 | 49.71 | 1552 | 204 | 1.85 | 38.42 | 1.00 | 50.04 | |
| 144 | 1.86 | 36.98 | 0.96 | 49.09 | 1552 | 206 | 1.84 | 39.10 | 1.02 | 50.48 | |
| 146 | 1.85 | 38.38 | 1.00 | 50.02 | 1550 | 208 | 1.92 | 31.73 | 0.83 | 45.27 | 1566 |
| 148 | 1.83 | 40.11 | 1.05 | 51.12 | 1549 | 210 | 1.94 | 30.34 | 0.79 | 44.17 | 1558 |
| 150 | 1.85 | 38.44 | 1.00 | 50.06 | 1552 | 212 | 1.89 | 34.80 | 0.91 | 47.57 | 1567 |
| 152 | 1.85 | 38.54 | 1.00 | 50.12 | 1552 | 214 | 1.88 | 35.47 | 0.92 | 48.05 | 1566 |
| 154 | 1.88 | 35.40 | 0.92 | 48.00 | 1551 | 216 | 1.90 | 33.76 | 0.88 | 46.81 | 1564 |
| 156 | 1.88 | 35.77 | 0.93 | 48.25 | 1551 | 218 | 1.92 | 31.76 | 0.83 | 45.30 | 1564 |
| 158 | 1.86 | 37.27 | 0.97 | 49.29 | 1552 | 220 | 1.89 | 34.92 | 0.91 | 47.66 | 1564 |
| 160 | 1.85 | 37.97 | 0.99 | 49.75 | 1553 | 222 | 1.88 | 35.38 | 0.92 | 47.98 | 1565 |
| 162 | 1.86 | 36.73 | 0.96 | 48.92 | 1557 | 224 | 1.89 | 34.51 | 0.90 | 47.37 | 1565 |
| 164 | 1.85 | 38.05 | 0.99 | 49.80 | 1555 | 226 | 1.92 | 32.48 | 0.85 | 45.86 | 1567 |
| 166 | 1.85 | 38.24 | 1.00 | 49.93 | 1555 | 228 | 1.88 | 35.66 | 0.93 | 48.18 | 1568 |
| 168 | 1.86 | 37.22 | 0.97 | 49.25 | 1555 | 230 | 1.89 | 34.65 | 0.90 | 47.46 | 1570 |
| 170 | 1.85 | 37.76 | 0.98 | 49.61 | 1556 | 232 | 1.91 | 33.03 | 0.86 | 46.27 | 1570 |
| 172 | 1.88 | 35.64 | 0.93 | 48.16 | 1555 | 234 | 1.81 | 41.61 | 1.08 | 52.04 | |
| 174 | 1.86 | 37.22 | 0.97 | 49.25 | 1556 | 236 | 1.82 | 40.64 | 1.06 | 51.45 | |
| 176 | 1.87 | 36.63 | 0.96 | 48.85 | 1555 | | | | | | |
| 178 | 1.86 | 36.93 | 0.96 | 49.06 | 1561 | | | | | | |
| 180 | 1.88 | 35.05 | 0.91 | 47.75 | 1554 | | | | | | |
| 182 | 1.87 | 36.46 | 0.95 | 48.74 | 1557 | | | | | | |

HM 40

HM 40

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 62 | 1.82 | 40.91 | 1.07 | 51.61 | 1548 |
| 2 | | | | | | 64 | 1.83 | 40.33 | 1.05 | 51.26 | 1550 |
| 4 | | | | | | 66 | 1.82 | 40.89 | 1.07 | 51.60 | 1546 |
| 6 | | | | | | 68 | 1.82 | 40.99 | 1.07 | 51.66 | 1545 |
| 8 | | | | | | 70 | 1.82 | 41.17 | 1.07 | 51.77 | 1542 |
| 10 | 1.55 | 82.55 | 2.15 | 68.28 | 1457 | 72 | 1.83 | 40.16 | 1.05 | 51.15 | 1541 |
| 12 | 1.56 | 78.41 | 2.04 | 67.15 | 1506 | 74 | 1.82 | 41.08 | 1.07 | 51.72 | 1543 |
| 14 | 1.60 | 71.64 | 1.87 | 65.13 | 1501 | 76 | 1.82 | 40.88 | 1.07 | 51.59 | 1542 |
| 16 | 1.71 | 53.41 | 1.39 | 58.20 | 1507 | 78 | 1.80 | 42.54 | 1.11 | 52.59 | 1543 |
| 18 | 1.72 | 51.85 | 1.35 | 57.48 | 1517 | 80 | 1.83 | 39.56 | 1.03 | 50.77 | 1543 |
| 20 | 1.74 | 50.10 | 1.31 | 56.64 | 1518 | 82 | 1.84 | 38.67 | 1.01 | 50.21 | 1543 |
| 22 | 1.76 | 46.89 | 1.22 | 55.01 | 1520 | 84 | 1.84 | 38.74 | 1.01 | 50.25 | 1539 |
| 24 | 1.72 | 52.26 | 1.36 | 57.68 | 1512 | 86 | 1.84 | 39.39 | 1.03 | 50.67 | 1541 |
| 26 | 1.72 | 52.52 | 1.37 | 57.79 | 1511 | 88 | 1.83 | 39.86 | 1.04 | 50.96 | 1544 |
| 28 | 1.72 | 52.10 | 1.36 | 57.60 | 1515 | 90 | 1.83 | 40.18 | 1.05 | 51.17 | 1544 |
| 30 | 1.74 | 49.38 | 1.29 | 56.28 | 1521 | 92 | 1.82 | 40.82 | 1.06 | 51.56 | 1543 |
| 32 | 1.76 | 47.16 | 1.23 | 55.15 | 1523 | 94 | 1.84 | 39.09 | 1.02 | 50.48 | 1538 |
| 34 | 1.69 | 56.92 | 1.48 | 59.74 | 1502 | 96 | 1.83 | 40.43 | 1.05 | 51.32 | 1538 |
| 36 | 1.70 | 55.04 | 1.44 | 58.94 | 1499 | 98 | 1.81 | 41.79 | 1.09 | 52.15 | 1541 |
| 38 | 1.66 | 60.35 | 1.57 | 61.14 | 1499 | 100 | 1.82 | 40.92 | 1.07 | 51.62 | 1540 |
| 40 | 1.71 | 53.24 | 1.39 | 58.13 | 1500 | 102 | 1.82 | 41.27 | 1.08 | 51.83 | 1542 |
| 42 | 1.70 | 54.78 | 1.43 | 58.82 | 1514 | 104 | 1.84 | 38.64 | 1.01 | 50.19 | 1542 |
| 44 | 1.69 | 56.80 | 1.48 | 59.70 | | 106 | 1.83 | 39.55 | 1.03 | 50.77 | 1543 |
| 46 | 1.74 | 49.86 | 1.30 | 56.52 | 1501 | 108 | 1.81 | 41.53 | 1.08 | 51.99 | 1544 |
| 48 | 1.76 | 47.50 | 1.24 | 55.33 | 1555 | 110 | 1.82 | 40.60 | 1.06 | 51.43 | 1543 |
| 50 | | | | | | 112 | 1.85 | 38.51 | 1.00 | 50.10 | 1545 |
| 52 | 1.76 | 47.55 | 1.24 | 55.35 | | 114 | 1.82 | 40.88 | 1.07 | 51.60 | 1545 |
| 54 | 1.72 | 52.30 | 1.36 | 57.69 | | 116 | 1.83 | 40.31 | 1.05 | 51.25 | 1547 |
| 56 | 1.78 | 44.75 | 1.17 | 53.85 | 1527 | 118 | 1.84 | 39.18 | 1.02 | 50.53 | 1546 |
| 58 | 1.80 | 43.00 | 1.12 | 52.86 | | 120 | 1.82 | 40.54 | 1.06 | 51.39 | 1544 |
| 60 | 1.80 | 42.82 | 1.12 | 52.75 | 1548 | 122 | 1.83 | 39.73 | 1.04 | 50.88 | 1544 |

HM 40

HM 40

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 124 | 1.85 | 37.82 | 0.99 | 49.65 | 1546 | 186 | 1.88 | 35.36 | 0.92 | 47.97 | 1566 |
| 126 | 1.83 | 40.18 | 1.05 | 51.16 | 1546 | 188 | 1.86 | 36.73 | 0.96 | 48.92 | 1561 |
| 128 | 1.84 | 39.37 | 1.03 | 50.65 | 1547 | 190 | 1.88 | 35.71 | 0.93 | 48.22 | 1561 |
| 130 | 1.81 | 41.69 | 1.09 | 52.09 | 1536 | 192 | 1.85 | 38.43 | 1.00 | 50.05 | 1560 |
| 132 | 1.84 | 39.18 | 1.02 | 50.54 | 1546 | 194 | 1.88 | 35.25 | 0.92 | 47.89 | 1561 |
| 134 | 1.85 | 37.93 | 0.99 | 49.72 | 1546 | 196 | 1.87 | 36.52 | 0.95 | 48.78 | 1560 |
| 136 | 1.85 | 38.51 | 1.00 | 50.11 | 1548 | 198 | 1.92 | 32.26 | 0.84 | 45.69 | 1552 |
| 138 | 1.86 | 36.84 | 0.96 | 48.99 | 1550 | 200 | 1.86 | 37.46 | 0.98 | 49.41 | 1561 |
| 140 | 1.84 | 38.88 | 1.01 | 50.34 | 1551 | 202 | 1.88 | 35.44 | 0.92 | 48.03 | 1561 |
| 142 | 1.88 | 35.47 | 0.92 | 48.04 | 1553 | 204 | 1.85 | 38.12 | 0.99 | 49.85 | 1564 |
| 144 | 1.78 | 45.25 | 1.18 | 54.12 | | 206 | 1.89 | 34.44 | 0.90 | 47.31 | 1560 |
| 146 | 1.86 | 36.72 | 0.96 | 48.91 | | 208 | 1.86 | 36.78 | 0.96 | 48.95 | 1561 |
| 148 | 1.88 | 35.78 | 0.93 | 48.27 | 1544 | 210 | 1.86 | 36.94 | 0.96 | 49.06 | 1560 |
| 150 | 1.78 | 45.26 | 1.18 | 54.13 | | 212 | 1.87 | 35.84 | 0.93 | 48.31 | 1560 |
| 152 | 1.81 | 41.75 | 1.09 | 52.12 | | 214 | 1.90 | 34.07 | 0.89 | 47.04 | 1557 |
| 154 | 1.80 | 43.42 | 1.13 | 53.10 | | 216 | 1.87 | 36.61 | 0.95 | 48.83 | 1560 |
| 156 | 1.86 | 37.43 | 0.98 | 49.39 | | 218 | 1.87 | 36.01 | 0.94 | 48.43 | 1559 |
| 158 | 1.88 | 34.98 | 0.91 | 47.70 | | 220 | 1.88 | 35.73 | 0.93 | 48.23 | 1563 |
| 160 | 1.87 | 36.10 | 0.94 | 48.49 | 1556 | 222 | 1.89 | 34.66 | 0.90 | 47.47 | 1562 |
| 162 | 1.95 | 29.49 | 0.77 | 43.47 | 1558 | 224 | 1.87 | 35.84 | 0.93 | 48.31 | 1562 |
| 164 | 1.86 | 37.29 | 0.97 | 49.29 | 1565 | 226 | 1.88 | 35.47 | 0.92 | 48.05 | 1564 |
| 166 | 1.86 | 37.28 | 0.97 | 49.29 | 1550 | 228 | 1.87 | 35.96 | 0.94 | 48.39 | 1563 |
| 168 | 1.86 | 36.73 | 0.96 | 48.92 | 1557 | 230 | 1.88 | 35.32 | 0.92 | 47.94 | 1563 |
| 170 | 1.88 | 35.37 | 0.92 | 47.98 | 1558 | 232 | 1.89 | 34.34 | 0.90 | 47.24 | 1561 |
| 172 | 1.88 | 35.65 | 0.93 | 48.18 | 1563 | 234 | 1.90 | 33.91 | 0.88 | 46.93 | 1560 |
| 174 | 1.85 | 37.99 | 0.99 | 49.76 | 1562 | 236 | 1.88 | 35.78 | 0.93 | 48.26 | 1567 |
| 176 | 1.86 | 36.92 | 0.96 | 49.05 | 1561 | 238 | 1.90 | 33.62 | 0.88 | 46.72 | 1570 |
| 178 | 1.91 | 32.52 | 0.85 | 45.88 | 1561 | 240 | 1.90 | 34.09 | 0.89 | 47.06 | 1575 |
| 180 | 1.91 | 33.28 | 0.87 | 46.46 | 1558 | 242 | 1.77 | 46.32 | 1.21 | 54.71 | |
| 182 | 1.87 | 36.26 | 0.95 | 48.60 | 1559 | 244 | 1.83 | 40.05 | 1.04 | 51.09 | 1547 |
| 184 | 1.87 | 36.32 | 0.95 | 48.64 | 1558 | 246 | 1.88 | 35.82 | 0.93 | 48.29 | |

HM 41

HM 41

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.64 | 64.75 | 1.69 | 62.80 | 1484 |
| 2 | | | | | | 62 | 1.76 | 47.36 | 1.23 | 55.25 | 1490 |
| 4 | | | | | | 64 | 1.74 | 49.43 | 1.29 | 56.31 | 1492 |
| 6 | | | | | | 66 | 1.61 | 68.69 | 1.79 | 64.17 | 1482 |
| 8 | 1.60 | 70.73 | 1.84 | 64.84 | | 68 | 1.63 | 66.24 | 1.73 | 63.33 | 1481 |
| 10 | 1.60 | 72.05 | 1.88 | 65.26 | | 70 | 1.72 | 52.24 | 1.36 | 57.66 | |
| 12 | 1.58 | 74.85 | 1.95 | 66.12 | | 72 | 1.59 | 73.10 | 1.91 | 65.59 | 1478 |
| 14 | 1.61 | 69.25 | 1.81 | 64.36 | | 74 | 1.65 | 62.91 | 1.64 | 62.13 | 1485 |
| 16 | 1.59 | 73.10 | 1.91 | 65.59 | | 76 | 1.62 | 67.60 | 1.76 | 63.80 | 1487 |
| 18 | 1.59 | 72.99 | 1.90 | 65.55 | | 78 | 1.66 | 61.47 | 1.60 | 61.58 | 1495 |
| 20 | 1.67 | 59.15 | 1.54 | 60.67 | | 80 | 1.65 | 63.07 | 1.64 | 62.19 | 1488 |
| 22 | 1.61 | 69.08 | 1.80 | 64.30 | | 82 | 1.65 | 63.17 | 1.65 | 62.22 | 1485 |
| 24 | 1.60 | 70.52 | 1.84 | 64.77 | | 84 | 1.64 | 63.62 | 1.66 | 62.39 | 1489 |
| 26 | 1.53 | 85.39 | 2.23 | 69.01 | 1455 | 86 | 1.62 | 67.23 | 1.75 | 63.67 | 1486 |
| 28 | 1.92 | 31.97 | 0.83 | 45.46 | 1480 | 88 | 1.65 | 62.31 | 1.62 | 61.90 | 1490 |
| 30 | 1.68 | 58.22 | 1.52 | 60.29 | 1497 | 90 | 1.63 | 66.63 | 1.74 | 63.47 | 1486 |
| 32 | 1.61 | 69.57 | 1.81 | 64.46 | 1480 | 92 | 1.64 | 63.97 | 1.67 | 62.52 | 1489 |
| 34 | 1.61 | 69.47 | 1.81 | 64.43 | 1482 | 94 | 1.58 | 75.33 | 1.96 | 66.26 | |
| 36 | 1.76 | 47.54 | 1.24 | 55.35 | 1503 | 96 | 1.67 | 58.70 | 1.53 | 60.48 | 1485 |
| 38 | 1.71 | 53.86 | 1.40 | 58.41 | 1504 | 98 | 1.71 | 53.08 | 1.38 | 58.05 | 1531 |
| 40 | 1.68 | 57.99 | 1.51 | 60.19 | 1497 | 100 | | | | | |
| 42 | 1.64 | 63.79 | 1.66 | 62.45 | 1489 | 102 | 1.61 | 69.40 | 1.81 | 64.41 | 1512 |
| 44 | 1.65 | 62.18 | 1.62 | 61.85 | 1486 | 104 | 1.66 | 60.78 | 1.58 | 61.31 | |
| 46 | 1.62 | 68.30 | 1.78 | 64.04 | 1483 | 106 | 1.59 | 72.28 | 1.88 | 65.33 | |
| 48 | 1.62 | 67.75 | 1.77 | 63.85 | 1478 | 108 | 1.68 | 58.50 | 1.53 | 60.40 | 1504 |
| 50 | 1.59 | 73.21 | 1.91 | 65.62 | 1478 | 110 | 1.68 | 57.85 | 1.51 | 60.13 | 1506 |
| 52 | 1.60 | 71.55 | 1.87 | 65.10 | 1479 | 112 | 1.68 | 57.30 | 1.49 | 59.91 | 1508 |
| 54 | 1.64 | 64.68 | 1.69 | 62.78 | 1483 | 114 | 1.65 | 61.95 | 1.62 | 61.76 | 1501 |
| 56 | 1.65 | 62.26 | 1.62 | 61.88 | 1491 | 116 | 1.64 | 63.90 | 1.67 | 62.49 | 1497 |
| 58 | 1.67 | 59.09 | 1.54 | 60.64 | 1500 | 118 | 1.71 | 54.05 | 1.41 | 58.50 | 1509 |
| | | | | | | 120 | 1.68 | 58.15 | 1.52 | 60.26 | 1506 |

HM 41

HM 41

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 122 | 1.67 | 58.98 | 1.54 | 60.60 | 1501 | 184 | 1.67 | 59.45 | 1.55 | 60.79 | 1519 |
| 124 | 1.67 | 58.77 | 1.53 | 60.51 | 1500 | 186 | 1.71 | 53.54 | 1.40 | 58.26 | 1521 |
| 126 | 1.65 | 61.75 | 1.61 | 61.69 | 1499 | 188 | 1.71 | 53.92 | 1.41 | 58.43 | 1522 |
| 128 | 1.65 | 61.72 | 1.61 | 61.68 | 1502 | 190 | 1.70 | 54.83 | 1.43 | 58.84 | 1517 |
| 130 | 1.70 | 54.49 | 1.42 | 58.69 | 1505 | 192 | 1.69 | 56.01 | 1.46 | 59.36 | 1525 |
| 132 | 1.71 | 53.40 | 1.39 | 58.20 | 1512 | 194 | 1.70 | 54.47 | 1.42 | 58.68 | 1536 |
| 134 | 1.70 | 55.59 | 1.45 | 59.18 | 1510 | 196 | 1.64 | 64.82 | 1.69 | 62.83 | |
| 136 | 1.70 | 54.96 | 1.43 | 58.90 | 1514 | 198 | 1.68 | 58.55 | 1.53 | 60.42 | |
| 138 | 1.69 | 56.11 | 1.46 | 59.40 | 1510 | 200 | 1.77 | 46.61 | 1.22 | 54.86 | |
| 140 | 1.65 | 61.94 | 1.61 | 61.76 | 1507 | 202 | | | | | |
| 142 | 1.69 | 56.14 | 1.46 | 59.41 | 1504 | 204 | 1.63 | 65.94 | 1.72 | 63.23 | |
| 144 | 1.64 | 63.98 | 1.67 | 62.52 | 1499 | 206 | 1.61 | 69.07 | 1.80 | 64.30 | |
| 146 | 1.62 | 67.33 | 1.76 | 63.71 | 1493 | 208 | 1.68 | 58.54 | 1.53 | 60.42 | |
| 148 | 1.65 | 62.84 | 1.64 | 62.10 | 1493 | 210 | 1.67 | 59.16 | 1.54 | 60.67 | |
| 150 | 1.68 | 57.60 | 1.50 | 60.03 | 1498 | 212 | 1.69 | 56.91 | 1.48 | 59.74 | |
| 152 | 1.64 | 64.79 | 1.69 | 62.81 | 1497 | 214 | 1.66 | 60.90 | 1.59 | 61.36 | |
| 154 | 1.64 | 64.89 | 1.69 | 62.85 | 1504 | 216 | 1.75 | 48.04 | 1.25 | 55.61 | 1537 |
| 156 | 1.67 | 59.47 | 1.55 | 60.79 | 1507 | 218 | 1.77 | 46.27 | 1.21 | 54.68 | 1531 |
| 158 | 1.71 | 53.50 | 1.40 | 58.25 | 1509 | 220 | 1.77 | 46.42 | 1.21 | 54.76 | 1533 |
| 160 | 1.71 | 53.08 | 1.38 | 58.05 | 1513 | 222 | 1.75 | 48.35 | 1.26 | 55.77 | 1530 |
| 162 | 1.69 | 56.59 | 1.48 | 59.60 | 1509 | 224 | 1.79 | 43.82 | 1.14 | 53.33 | 1542 |
| 164 | 1.65 | 62.92 | 1.64 | 62.13 | 1503 | 226 | 1.78 | 45.65 | 1.19 | 54.35 | 1537 |
| 166 | 1.65 | 61.94 | 1.62 | 61.76 | 1500 | 228 | 1.79 | 43.70 | 1.14 | 53.26 | 1535 |
| 168 | 1.67 | 59.19 | 1.54 | 60.68 | 1514 | 230 | 1.79 | 43.75 | 1.14 | 53.28 | 1539 |
| 170 | 1.69 | 55.86 | 1.46 | 59.29 | 1518 | 232 | 1.76 | 47.30 | 1.23 | 55.22 | 1528 |
| 172 | 1.65 | 62.14 | 1.62 | 61.84 | 1516 | 234 | 1.70 | 55.70 | 1.45 | 59.22 | 1508 |
| 174 | 1.63 | 65.90 | 1.72 | 63.21 | 1514 | 236 | 1.78 | 44.71 | 1.17 | 53.83 | 1577 |
| 176 | 1.59 | 72.32 | 1.89 | 65.35 | 1502 | 238 | 1.70 | 54.55 | 1.42 | 58.72 | 1514 |
| 178 | 1.59 | 74.14 | 1.93 | 65.91 | 1499 | 240 | 1.71 | 53.60 | 1.40 | 58.29 | 1517 |
| 180 | 1.60 | 71.86 | 1.87 | 65.20 | 1501 | 242 | 1.72 | 52.13 | 1.36 | 57.61 | 1518 |
| 182 | 1.64 | 64.77 | 1.69 | 62.81 | 1504 | 244 | 1.71 | 53.31 | 1.39 | 58.16 | 1515 |

HM 41

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.56 | 78.59 | 2.05 | 67.20 | 1512 |
| 248 | 1.76 | 46.98 | 1.23 | 55.06 | 1530 |
| 250 | 1.84 | 38.62 | 1.01 | 50.18 | 1551 |
| 252 | 1.96 | 28.88 | 0.75 | 42.96 | 1559 |
| 254 | 1.72 | 51.79 | 1.35 | 57.45 | 1506 |
| 256 | 1.72 | 52.29 | 1.36 | 57.69 | 1510 |
| 258 | 1.66 | 60.13 | 1.57 | 61.06 | 1500 |
| 260 | 1.78 | 45.46 | 1.19 | 54.24 | 1518 |
| 262 | 1.85 | 37.94 | 0.99 | 49.73 | 1542 |
| 264 | 1.76 | 47.21 | 1.23 | 55.18 | 1541 |
| 266 | 1.81 | 41.82 | 1.09 | 52.17 | 1545 |
| 268 | 1.79 | 43.97 | 1.15 | 53.41 | 1541 |
| 270 | 1.88 | 35.80 | 0.93 | 48.28 | 1570 |
| 272 | 1.78 | 44.98 | 1.17 | 53.97 | 1537 |
| 274 | 1.73 | 50.63 | 1.32 | 56.90 | 1522 |
| 276 | 1.73 | 51.43 | 1.34 | 57.28 | 1521 |
| 278 | 1.69 | 55.95 | 1.46 | 59.33 | 1517 |
| 280 | 1.57 | 78.08 | 2.04 | 67.06 | 1484 |
| 282 | 1.57 | 77.93 | 2.03 | 67.02 | |
| 284 | 1.69 | 56.55 | 1.47 | 59.59 | |
| 286 | 1.72 | 52.32 | 1.36 | 57.70 | 1520 |
| 288 | 1.77 | 45.80 | 1.19 | 54.42 | 1535 |
| 290 | 1.74 | 49.63 | 1.29 | 56.41 | 1532 |
| 292 | 1.78 | 45.65 | 1.19 | 54.35 | 1535 |
| 294 | 1.76 | 47.99 | 1.25 | 55.58 | 1543 |
| 296 | 1.71 | 54.11 | 1.41 | 58.52 | |
| 298 | 1.72 | 52.00 | 1.36 | 57.55 | |
| 300 | 1.74 | 49.42 | 1.29 | 56.31 | |

HM 43

HM 43

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.78 | 45.04 | 1.17 | 54.01 | 1532 |
| 2 | | | | | | 62 | 1.78 | 44.97 | 1.17 | 53.97 | 1530 |
| 4 | | | | | | 64 | 1.78 | 45.28 | 1.18 | 54.14 | 1533 |
| 6 | 1.43 | 115.35 | 3.01 | 75.05 | | 66 | 1.79 | 43.69 | 1.14 | 53.25 | 1533 |
| 8 | 1.50 | 94.64 | 2.47 | 71.16 | | 68 | 1.79 | 43.97 | 1.15 | 53.41 | 1533 |
| 10 | 1.51 | 92.15 | 2.40 | 70.61 | 1500 | 70 | 1.81 | 42.36 | 1.10 | 52.48 | 1536 |
| 12 | 1.62 | 68.35 | 1.78 | 64.06 | 1502 | 72 | 1.79 | 44.53 | 1.16 | 53.73 | 1535 |
| 14 | 1.63 | 66.39 | 1.73 | 63.38 | 1509 | 74 | 1.78 | 45.50 | 1.19 | 54.26 | 1533 |
| 16 | 1.62 | 67.59 | 1.76 | 63.80 | 1508 | 76 | 1.79 | 44.17 | 1.15 | 53.52 | 1533 |
| 18 | 1.71 | 54.01 | 1.41 | 58.48 | 1516 | 78 | 1.78 | 45.43 | 1.18 | 54.23 | 1535 |
| 20 | 1.70 | 54.94 | 1.43 | 58.89 | 1516 | 80 | 1.79 | 44.20 | 1.15 | 53.54 | 1534 |
| 22 | 1.69 | 56.06 | 1.46 | 59.38 | 1516 | 82 | 1.78 | 45.19 | 1.18 | 54.09 | 1537 |
| 24 | 1.73 | 50.58 | 1.32 | 56.87 | 1524 | 84 | 1.79 | 44.16 | 1.15 | 53.52 | 1538 |
| 26 | 1.73 | 51.16 | 1.33 | 57.15 | 1522 | 86 | 1.79 | 44.52 | 1.16 | 53.72 | 1536 |
| 28 | 1.70 | 54.66 | 1.43 | 58.76 | 1518 | 88 | 1.79 | 44.51 | 1.16 | 53.72 | 1536 |
| 30 | 1.73 | 51.28 | 1.34 | 57.21 | 1521 | 90 | 1.78 | 45.51 | 1.19 | 54.27 | 1538 |
| 32 | 1.72 | 52.92 | 1.38 | 57.98 | 1513 | 92 | 1.80 | 42.53 | 1.11 | 52.58 | 1537 |
| 34 | 1.73 | 50.94 | 1.33 | 57.05 | 1516 | 94 | 1.78 | 45.69 | 1.19 | 54.37 | 1539 |
| 36 | 1.72 | 52.26 | 1.36 | 57.67 | 1519 | 96 | 1.73 | 51.62 | 1.35 | 57.38 | |
| 38 | 1.75 | 48.98 | 1.28 | 56.09 | 1523 | 98 | 1.77 | 45.88 | 1.20 | 54.47 | |
| 40 | 1.73 | 50.97 | 1.33 | 57.06 | 1523 | 100 | 1.82 | 40.64 | 1.06 | 51.45 | |
| 42 | 1.75 | 48.52 | 1.27 | 55.85 | 1532 | 102 | | | | | |
| 44 | 1.73 | 51.59 | 1.35 | 57.36 | 1526 | 104 | 1.74 | 50.06 | 1.31 | 56.62 | |
| 46 | 1.77 | 46.31 | 1.21 | 54.70 | 1528 | 106 | 1.75 | 48.08 | 1.25 | 55.63 | |
| 48 | 1.75 | 48.74 | 1.27 | 55.96 | 1528 | 108 | 1.80 | 43.12 | 1.12 | 52.93 | |
| 50 | 1.77 | 46.45 | 1.21 | 54.77 | 1531 | 110 | 1.82 | 41.39 | 1.08 | 51.90 | |
| 52 | 1.78 | 44.72 | 1.17 | 53.83 | 1529 | 112 | 1.80 | 43.01 | 1.12 | 52.86 | |
| 54 | 1.78 | 45.10 | 1.18 | 54.04 | 1528 | 114 | 1.79 | 44.42 | 1.16 | 53.66 | 1526 |
| 56 | 1.78 | 45.55 | 1.19 | 54.29 | 1531 | 116 | 1.81 | 41.69 | 1.09 | 52.09 | 1549 |
| 58 | 1.77 | 46.68 | 1.22 | 54.90 | 1531 | 118 | 1.79 | 43.96 | 1.15 | 53.40 | 1533 |
| | | | | | | 120 | 1.80 | 42.68 | 1.11 | 52.67 | 1544 |

HM 43

HM 43

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.81 | 41.91 | 1.09 | 52.22 | 1544 | 184 | 1.80 | 42.83 | 1.12 | 52.76 | 1543 |
| 124 | 1.80 | 42.63 | 1.11 | 52.64 | 1510 | 186 | 1.85 | 38.07 | 0.99 | 49.82 | 1545 |
| 126 | 1.84 | 39.06 | 1.02 | 50.46 | 1545 | 188 | 1.82 | 41.34 | 1.08 | 51.88 | 1536 |
| 128 | 1.82 | 41.44 | 1.08 | 51.93 | 1541 | 190 | 1.82 | 40.61 | 1.06 | 51.43 | 1543 |
| 130 | 1.84 | 39.03 | 1.02 | 50.44 | 1541 | 192 | 1.83 | 40.41 | 1.05 | 51.31 | 1542 |
| 132 | 1.84 | 39.23 | 1.02 | 50.56 | 1542 | 194 | 1.80 | 43.21 | 1.13 | 52.98 | 1544 |
| 134 | 1.82 | 41.24 | 1.08 | 51.81 | 1543 | 196 | 1.73 | 50.56 | 1.32 | 56.87 | 1539 |
| 136 | 1.83 | 39.75 | 1.04 | 50.89 | 1542 | 198 | | | | | |
| 138 | 1.82 | 40.78 | 1.06 | 51.54 | 1543 | 200 | | | | | |
| 140 | 1.80 | 43.35 | 1.13 | 53.06 | 1539 | 202 | 1.79 | 44.44 | 1.16 | 53.68 | |
| 142 | 1.74 | 49.54 | 1.29 | 56.36 | 1543 | 204 | | | | | |
| 144 | 1.74 | 50.26 | 1.31 | 56.72 | 1543 | 206 | 1.87 | 35.89 | 0.94 | 48.34 | |
| 146 | 1.78 | 45.28 | 1.18 | 54.14 | 1544 | 208 | 1.84 | 39.43 | 1.03 | 50.70 | |
| 148 | 1.80 | 42.57 | 1.11 | 52.61 | 1542 | 210 | 1.91 | 32.63 | 0.85 | 45.97 | 1569 |
| 150 | 1.81 | 42.17 | 1.10 | 52.37 | 1540 | 212 | 1.90 | 33.85 | 0.88 | 46.88 | 1567 |
| 152 | 1.82 | 40.56 | 1.06 | 51.40 | 1540 | 214 | 1.92 | 31.95 | 0.83 | 45.45 | 1566 |
| 154 | 1.82 | 40.77 | 1.06 | 51.53 | 1539 | 216 | 1.92 | 32.48 | 0.85 | 45.85 | 1567 |
| 156 | 1.83 | 39.76 | 1.04 | 50.90 | 1538 | 218 | 1.90 | 33.97 | 0.89 | 46.97 | 1565 |
| 158 | 1.82 | 40.53 | 1.06 | 51.38 | 1539 | 220 | 1.89 | 34.45 | 0.90 | 47.32 | 1566 |
| 160 | 1.81 | 41.89 | 1.09 | 52.21 | 1540 | 222 | 1.90 | 34.10 | 0.89 | 47.07 | 1566 |
| 162 | 1.81 | 41.80 | 1.09 | 52.15 | 1541 | 224 | 1.91 | 33.12 | 0.86 | 46.34 | 1562 |
| 164 | 1.84 | 39.33 | 1.03 | 50.63 | 1541 | 226 | 1.90 | 34.02 | 0.89 | 47.01 | 1564 |
| 166 | 1.83 | 40.18 | 1.05 | 51.16 | 1541 | 228 | 1.91 | 32.94 | 0.86 | 46.21 | 1565 |
| 168 | 1.82 | 40.99 | 1.07 | 51.66 | 1541 | 230 | 1.90 | 33.51 | 0.87 | 46.63 | 1567 |
| 170 | 1.80 | 43.37 | 1.13 | 53.07 | 1541 | 232 | 1.91 | 33.22 | 0.87 | 46.41 | 1565 |
| 172 | 1.81 | 42.22 | 1.10 | 52.40 | 1543 | 234 | 1.90 | 33.62 | 0.88 | 46.71 | 1567 |
| 174 | 1.82 | 40.61 | 1.06 | 51.43 | 1542 | 236 | 1.90 | 33.83 | 0.88 | 46.87 | 1569 |
| 176 | 1.81 | 42.02 | 1.10 | 52.28 | 1542 | 238 | 1.89 | 34.41 | 0.90 | 47.29 | 1568 |
| 178 | 1.83 | 39.49 | 1.03 | 50.73 | 1542 | 240 | 1.91 | 33.06 | 0.86 | 46.30 | 1566 |
| 180 | 1.85 | 38.24 | 1.00 | 49.93 | 1542 | 242 | 1.88 | 35.23 | 0.92 | 47.88 | 1567 |
| 182 | 1.83 | 39.72 | 1.04 | 50.88 | 1542 | 244 | 1.89 | 34.26 | 0.89 | 47.18 | 1567 |

HM 43

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.90 | 33.43 | 0.87 | 46.57 | 1565 |
| 248 | 1.92 | 31.76 | 0.83 | 45.30 | 1566 |
| 250 | 1.93 | 31.38 | 0.82 | 45.00 | 1569 |
| 252 | 1.89 | 34.32 | 0.89 | 47.23 | 1569 |
| 254 | 1.90 | 33.36 | 0.87 | 46.52 | 1570 |
| 256 | 1.93 | 31.70 | 0.83 | 45.25 | 1572 |
| 258 | 1.86 | 37.14 | 0.97 | 49.20 | |
| 260 | 1.89 | 34.79 | 0.91 | 47.56 | |
| 262 | 1.93 | 31.21 | 0.81 | 44.87 | |

HM 44

HM 44

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.56 | 78.42 | 2.04 | 67.16 | 1483 |
| 2 | | | | | | 62 | 1.60 | 71.61 | 1.87 | 65.12 | 1484 |
| 4 | | | | | | 64 | 1.60 | 70.34 | 1.83 | 64.72 | 1490 |
| 6 | | | | | | 66 | 1.62 | 68.28 | 1.78 | 64.03 | 1487 |
| 8 | 1.54 | 85.13 | 2.22 | 68.94 | 1505 | 68 | 1.65 | 62.49 | 1.63 | 61.97 | 1495 |
| 10 | 1.56 | 80.30 | 2.09 | 67.68 | 1503 | 70 | 1.74 | 50.03 | 1.30 | 56.61 | 1507 |
| 12 | 1.57 | 77.28 | 2.02 | 66.83 | 1503 | 72 | 1.60 | 71.85 | 1.87 | 65.20 | 1490 |
| 14 | 1.55 | 82.73 | 2.16 | 68.32 | 1499 | 74 | 1.62 | 66.79 | 1.74 | 63.52 | 1495 |
| 16 | 1.63 | 66.60 | 1.74 | 63.46 | 1503 | 76 | 1.74 | 49.87 | 1.30 | 56.53 | 1528 |
| 18 | 1.61 | 69.07 | 1.80 | 64.30 | 1503 | 78 | 1.80 | 42.88 | 1.12 | 52.79 | 1538 |
| 20 | 1.65 | 62.65 | 1.63 | 62.03 | 1503 | 80 | 1.78 | 45.46 | 1.19 | 54.24 | 1537 |
| 22 | 1.67 | 59.74 | 1.56 | 60.90 | 1507 | 82 | 1.77 | 45.72 | 1.19 | 54.38 | 1538 |
| 24 | 1.64 | 64.74 | 1.69 | 62.80 | 1503 | 84 | 1.81 | 41.92 | 1.09 | 52.22 | 1545 |
| 26 | 1.67 | 59.52 | 1.55 | 60.81 | 1506 | 86 | 1.85 | 37.98 | 0.99 | 49.76 | 1586 |
| 28 | 1.67 | 59.45 | 1.55 | 60.79 | 1508 | 88 | 1.90 | 33.53 | 0.87 | 46.64 | 1579 |
| 30 | 1.70 | 55.24 | 1.44 | 59.02 | 1509 | 90 | 1.90 | 33.77 | 0.88 | 46.82 | 1573 |
| 32 | 1.62 | 68.43 | 1.78 | 64.08 | 1496 | 92 | 1.92 | 32.18 | 0.84 | 45.62 | 1576 |
| 34 | 1.64 | 64.93 | 1.69 | 62.87 | 1502 | 94 | 1.85 | 37.72 | 0.98 | 49.58 | |
| 36 | 1.65 | 62.09 | 1.62 | 61.82 | 1506 | 96 | 1.84 | 38.62 | 1.01 | 50.18 | |
| 38 | 1.60 | 70.34 | 1.83 | 64.72 | 1494 | 98 | 1.90 | 33.93 | 0.88 | 46.94 | 1540 |
| 40 | 1.60 | 70.86 | 1.85 | 64.88 | 1491 | 100 | | | | | |
| 42 | 1.60 | 72.13 | 1.88 | 65.29 | 1486 | 102 | 1.86 | 37.56 | 0.98 | 49.48 | 1550 |
| 44 | 1.59 | 74.01 | 1.93 | 65.87 | 1484 | 104 | 1.84 | 39.33 | 1.03 | 50.63 | |
| 46 | 1.58 | 74.77 | 1.95 | 66.10 | 1488 | 106 | 1.90 | 33.79 | 0.88 | 46.84 | 1571 |
| 48 | 1.68 | 57.97 | 1.51 | 60.18 | 1505 | 108 | 1.89 | 34.16 | 0.89 | 47.11 | 1568 |
| 50 | 1.69 | 56.72 | 1.48 | 59.66 | 1507 | 110 | 1.89 | 34.57 | 0.90 | 47.41 | 1565 |
| 52 | 1.64 | 63.40 | 1.65 | 62.31 | 1497 | 112 | 1.89 | 30.87 | 0.80 | 44.60 | 1559 |
| 54 | 1.65 | 63.11 | 1.65 | 62.20 | 1498 | 114 | 1.94 | 30.87 | 0.80 | 44.60 | 1565 |
| 56 | 1.59 | 72.37 | 1.89 | 65.36 | 1489 | 116 | 1.89 | 34.64 | 0.90 | 47.46 | 1552 |
| 58 | 1.61 | 69.25 | 1.81 | 64.36 | 1491 | 118 | 1.85 | 38.43 | 1.00 | 50.05 | 1564 |
| | | | | | | 120 | 1.89 | 34.67 | 0.90 | 47.48 | |

HM 44

HM 44

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.91 | 32.72 | 0.85 | 46.04 | 1566 | 184 | 1.90 | 33.74 | 0.88 | 46.80 | 1567 |
| 124 | 1.86 | 36.76 | 0.96 | 48.94 | 1556 | 186 | 1.91 | 32.54 | 0.85 | 45.90 | 1568 |
| 126 | 1.87 | 36.17 | 0.94 | 48.53 | 1558 | 188 | 1.93 | 31.42 | 0.82 | 45.03 | 1571 |
| 128 | 1.86 | 36.83 | 0.96 | 48.99 | 1559 | 190 | 1.89 | 34.21 | 0.89 | 47.14 | 1573 |
| 130 | 1.90 | 33.68 | 0.88 | 46.76 | 1557 | 192 | 1.92 | 32.40 | 0.84 | 45.79 | 1573 |
| 132 | 1.88 | 35.45 | 0.92 | 48.03 | 1557 | 194 | 1.91 | 32.91 | 0.86 | 46.18 | 1573 |
| 134 | 1.87 | 35.88 | 0.94 | 48.34 | 1556 | 196 | 1.86 | 37.10 | 0.97 | 49.17 | 1576 |
| 136 | 1.90 | 34.00 | 0.89 | 46.99 | 1557 | 198 | 1.87 | 36.40 | 0.95 | 48.69 | |
| 138 | 1.88 | 35.81 | 0.93 | 48.29 | 1559 | 200 | 1.93 | 31.07 | 0.81 | 44.76 | |
| 140 | 1.87 | 36.03 | 0.94 | 48.44 | 1558 | 202 | | | | | |
| 142 | 1.86 | 36.76 | 0.96 | 48.94 | 1559 | 204 | 1.90 | 33.49 | 0.87 | 46.62 | |
| 144 | 1.88 | 35.12 | 0.92 | 47.80 | 1555 | 206 | 1.91 | 33.28 | 0.87 | 46.46 | |
| 146 | 1.88 | 35.61 | 0.93 | 48.15 | 1557 | 208 | 1.94 | 30.55 | 0.80 | 44.34 | 1579 |
| 148 | 1.88 | 35.71 | 0.93 | 48.22 | 1558 | 210 | 1.95 | 29.83 | 0.78 | 43.75 | 1577 |
| 150 | 1.87 | 36.22 | 0.94 | 48.57 | 1557 | 212 | 1.96 | 28.87 | 0.75 | 42.95 | 1574 |
| 152 | 1.89 | 34.33 | 0.90 | 47.23 | 1558 | 214 | 1.96 | 28.84 | 0.75 | 42.92 | 1576 |
| 154 | 1.88 | 35.44 | 0.92 | 48.03 | 1558 | 216 | 1.96 | 29.37 | 0.77 | 43.37 | 1579 |
| 156 | 1.88 | 35.39 | 0.92 | 47.99 | 1558 | 218 | 1.98 | 28.00 | 0.73 | 42.20 | 1573 |
| 158 | 1.92 | 32.31 | 0.84 | 45.72 | 1552 | 220 | 1.95 | 30.05 | 0.78 | 43.94 | 1576 |
| 160 | 1.90 | 34.05 | 0.89 | 47.03 | 1555 | 222 | 1.95 | 29.95 | 0.78 | 43.85 | 1576 |
| 162 | 1.89 | 34.66 | 0.90 | 47.47 | 1559 | 224 | 1.97 | 28.27 | 0.74 | 42.43 | 1578 |
| 164 | 1.87 | 36.34 | 0.95 | 48.65 | 1559 | 226 | 1.98 | 27.87 | 0.73 | 42.09 | 1574 |
| 166 | 1.87 | 36.19 | 0.94 | 48.55 | 1561 | 228 | 1.97 | 28.63 | 0.75 | 42.74 | 1574 |
| 168 | 1.91 | 32.50 | 0.85 | 45.87 | 1558 | 230 | 2.01 | 25.72 | 0.67 | 40.14 | 1572 |
| 170 | 1.89 | 34.76 | 0.91 | 47.54 | 1562 | 232 | 2.03 | 24.70 | 0.64 | 39.17 | 1570 |
| 172 | 1.88 | 35.73 | 0.93 | 48.23 | 1562 | 234 | 1.74 | 49.96 | 1.30 | 56.57 | 1573 |
| 174 | 1.95 | 29.71 | 0.77 | 43.65 | 1557 | 236 | 1.70 | 55.46 | 1.45 | 59.12 | |
| 176 | 1.89 | 34.76 | 0.91 | 47.55 | 1565 | 238 | 1.71 | 54.23 | 1.41 | 58.58 | |
| 178 | 1.91 | 33.18 | 0.87 | 46.38 | 1566 | 240 | 1.66 | 61.60 | 1.61 | 61.63 | |
| 180 | 1.92 | 31.72 | 0.83 | 45.27 | 1566 | 242 | | | | | |
| 182 | 1.92 | 32.30 | 0.84 | 45.72 | 1568 | 244 | 1.72 | 52.32 | 1.36 | 57.70 | |

HM 46

HM 46

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.77 | 46.81 | 1.22 | 54.97 | 1536 |
| 2 | | | | | | 62 | 1.77 | 46.76 | 1.22 | 54.94 | 1537 |
| 4 | | | | | | 64 | 1.77 | 46.07 | 1.20 | 54.57 | 1536 |
| 6 | | | | | | 66 | 1.82 | 41.33 | 1.08 | 51.87 | 1537 |
| 8 | | | | | | 68 | 1.83 | 40.07 | 1.04 | 51.10 | 1536 |
| 10 | 1.49 | 97.87 | 2.55 | 71.85 | 1494 | 70 | 1.80 | 42.78 | 1.12 | 52.73 | 1542 |
| 12 | 1.46 | 105.52 | 2.75 | 73.34 | 1490 | 72 | 1.82 | 41.33 | 1.08 | 51.87 | 1542 |
| 14 | 1.47 | 103.21 | 2.69 | 72.91 | 1490 | 74 | 1.82 | 40.76 | 1.06 | 51.52 | 1540 |
| 16 | 1.50 | 93.27 | 2.43 | 70.86 | 1494 | 76 | 1.82 | 40.63 | 1.06 | 51.44 | 1540 |
| 18 | 1.51 | 91.65 | 2.39 | 70.50 | 1498 | 78 | 1.82 | 40.63 | 1.06 | 51.44 | 1542 |
| 20 | 1.54 | 83.87 | 2.19 | 68.62 | 1491 | 80 | 1.84 | 38.90 | 1.01 | 50.35 | 1543 |
| 22 | 1.47 | 104.66 | 2.73 | 73.18 | 1487 | 82 | 1.82 | 41.03 | 1.07 | 51.68 | 1543 |
| 24 | 1.53 | 85.53 | 2.23 | 69.04 | 1488 | 84 | 1.83 | 40.01 | 1.04 | 51.06 | 1543 |
| 26 | 1.55 | 80.93 | 2.11 | 67.85 | 1489 | 86 | 1.82 | 40.77 | 1.06 | 51.53 | 1546 |
| 28 | 1.61 | 70.21 | 1.83 | 64.67 | 1496 | 88 | 1.83 | 40.34 | 1.05 | 51.27 | 1546 |
| 30 | 1.66 | 60.21 | 1.57 | 61.09 | 1506 | 90 | 1.85 | 38.16 | 1.00 | 49.88 | 1546 |
| 32 | 1.66 | 61.04 | 1.59 | 61.41 | 1508 | 92 | 1.84 | 39.44 | 1.03 | 50.70 | 1548 |
| 34 | 1.67 | 59.96 | 1.56 | 60.99 | 1506 | 94 | 1.83 | 39.74 | 1.04 | 50.89 | 1549 |
| 36 | 1.63 | 65.42 | 1.71 | 63.04 | 1499 | 96 | 1.78 | 44.69 | 1.17 | 53.81 | 1539 |
| 38 | 1.62 | 67.97 | 1.77 | 63.93 | 1497 | 98 | 1.84 | 39.19 | 1.02 | 50.54 | 1539 |
| 40 | 1.64 | 64.12 | 1.67 | 62.57 | 1499 | 100 | 1.88 | 35.78 | 0.93 | 48.26 | |
| 42 | 1.67 | 59.57 | 1.55 | 60.83 | 1507 | 102 | 1.71 | 54.27 | 1.42 | 58.59 | |
| 44 | 1.70 | 54.45 | 1.42 | 58.68 | 1512 | 104 | 1.59 | 72.49 | 1.89 | 65.40 | |
| 46 | 1.69 | 56.67 | 1.48 | 59.64 | 1509 | 106 | 1.57 | 76.66 | 2.00 | 66.65 | |
| 48 | 1.71 | 54.05 | 1.41 | 58.49 | 1512 | 108 | 1.65 | 61.88 | 1.61 | 61.74 | |
| 50 | 1.71 | 54.34 | 1.42 | 58.63 | 1517 | 110 | 1.64 | 63.95 | 1.67 | 62.51 | 1538 |
| 52 | 1.71 | 53.24 | 1.39 | 58.13 | 1517 | 112 | 1.55 | 81.26 | 2.12 | 67.94 | 1559 |
| 54 | 1.76 | 47.39 | 1.24 | 55.27 | 1532 | 114 | 1.45 | 108.76 | 2.84 | 73.93 | 1557 |
| 56 | 1.77 | 46.20 | 1.20 | 54.64 | 1534 | 116 | 1.54 | 84.99 | 2.22 | 68.91 | 1554 |
| 58 | 1.79 | 43.74 | 1.14 | 53.28 | 1543 | 118 | 1.49 | 98.39 | 2.57 | 71.95 | 1556 |
| | 1.74 | 49.46 | 1.29 | 56.32 | 1529 | 120 | 1.54 | 82.94 | 2.16 | 68.38 | 1555 |

HM 46

HM 46

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.62 | 68.31 | 1.78 | 64.04 | 1560 | 184 | 1.86 | 37.05 | 0.97 | 49.14 | 1555 |
| 124 | 1.75 | 48.11 | 1.25 | 55.64 | 1555 | 186 | 1.86 | 37.59 | 0.98 | 49.50 | 1556 |
| 126 | 1.81 | 42.21 | 1.10 | 52.40 | 1556 | 188 | 1.86 | 37.23 | 0.97 | 49.26 | 1556 |
| 128 | 1.85 | 37.90 | 0.99 | 49.70 | 1553 | 190 | 1.84 | 39.22 | 1.02 | 50.56 | 1558 |
| 130 | 1.84 | 39.09 | 1.02 | 50.47 | 1552 | 192 | 1.86 | 37.39 | 0.97 | 49.36 | 1559 |
| 132 | 1.88 | 35.11 | 0.92 | 47.80 | 1554 | 194 | 1.78 | 45.06 | 1.17 | 54.02 | |
| 134 | 1.86 | 37.54 | 0.98 | 49.47 | 1544 | 196 | 1.83 | 39.63 | 1.03 | 50.82 | |
| 136 | 1.85 | 38.43 | 1.00 | 50.05 | 1552 | 198 | 1.81 | 41.60 | 1.08 | 52.03 | |
| 138 | 1.83 | 39.60 | 1.03 | 50.80 | 1551 | 200 | | | | | |
| 140 | 1.85 | 38.20 | 1.00 | 49.90 | 1553 | 202 | 1.84 | 38.85 | 1.01 | 50.32 | |
| 142 | 1.83 | 39.55 | 1.03 | 50.77 | 1552 | 204 | 1.82 | 40.77 | 1.06 | 51.53 | |
| 144 | 1.84 | 39.16 | 1.02 | 50.52 | 1551 | 206 | 1.84 | 39.02 | 1.02 | 50.43 | |
| 146 | 1.84 | 38.79 | 1.01 | 50.28 | 1551 | 208 | 1.89 | 34.27 | 0.89 | 47.19 | 1561 |
| 148 | 1.86 | 37.06 | 0.97 | 49.14 | 1548 | 210 | 1.88 | 35.33 | 0.92 | 47.95 | 1563 |
| 150 | 1.83 | 40.21 | 1.05 | 51.18 | 1545 | 212 | 1.89 | 34.24 | 0.89 | 47.17 | 1562 |
| 152 | 1.84 | 39.26 | 1.02 | 50.59 | 1546 | 214 | 1.88 | 35.14 | 0.92 | 47.81 | 1560 |
| 154 | 1.85 | 38.46 | 1.00 | 50.07 | 1546 | 216 | 1.91 | 33.25 | 0.87 | 46.44 | 1561 |
| 156 | 1.84 | 38.82 | 1.01 | 50.31 | 1544 | 218 | 1.88 | 34.97 | 0.91 | 47.69 | 1561 |
| 158 | 1.84 | 39.49 | 1.03 | 50.73 | 1543 | 220 | 1.88 | 35.26 | 0.92 | 47.90 | 1556 |
| 160 | 1.85 | 38.19 | 1.00 | 49.89 | 1546 | 222 | 1.89 | 34.57 | 0.90 | 47.41 | 1558 |
| 162 | 1.83 | 39.66 | 1.03 | 50.84 | 1552 | 224 | 1.88 | 35.03 | 0.91 | 47.73 | 1562 |
| 164 | 1.86 | 36.72 | 0.96 | 48.91 | 1545 | | | | | | |
| 166 | 1.86 | 37.06 | 0.97 | 49.14 | 1547 | | | | | | |
| 168 | 1.84 | 38.92 | 1.01 | 50.37 | 1550 | | | | | | |
| 170 | 1.83 | 39.91 | 1.04 | 51.00 | 1551 | | | | | | |
| 172 | 1.83 | 40.03 | 1.04 | 51.07 | 1551 | | | | | | |
| 174 | 1.83 | 39.81 | 1.04 | 50.93 | 1549 | | | | | | |
| 176 | 1.88 | 35.60 | 0.93 | 48.14 | 1547 | | | | | | |
| 178 | 1.86 | 37.08 | 0.97 | 49.16 | 1553 | | | | | | |
| 180 | 1.84 | 38.95 | 1.02 | 50.38 | 1553 | | | | | | |
| 182 | 1.87 | 36.17 | 0.94 | 48.54 | 1556 | | | | | | |

HM 48

HM 48

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 66 | 1.66 | 60.34 | 1.57 | 61.14 | 1488 |
| 2 | | | | | | 68 | 1.69 | 55.83 | 1.46 | 59.28 | 1502 |
| 4 | | | | | | 70 | 1.61 | 69.18 | 1.80 | 64.33 | 1485 |
| 6 | | | | | | 72 | 1.69 | 56.66 | 1.48 | 59.63 | 1494 |
| 8 | | | | | | 74 | 1.60 | 70.72 | 1.84 | 64.84 | 1481 |
| 10 | | | | | | 76 | 1.60 | 70.68 | 1.84 | 64.82 | 1481 |
| 12 | 1.53 | 86.81 | 2.26 | 69.36 | | 78 | 1.62 | 68.18 | 1.78 | 64.00 | 1483 |
| 14 | 1.55 | 80.71 | 2.10 | 67.79 | | 80 | 1.64 | 64.80 | 1.69 | 62.82 | 1484 |
| 16 | 1.51 | 90.31 | 2.35 | 70.19 | | 82 | 1.65 | 62.77 | 1.64 | 62.07 | 1484 |
| 18 | 1.49 | 96.30 | 2.51 | 71.52 | | 84 | 1.71 | 53.67 | 1.40 | 58.32 | 1499 |
| 20 | 1.59 | 72.33 | 1.89 | 65.35 | | 86 | 1.70 | 54.44 | 1.42 | 58.67 | 1501 |
| 22 | 1.62 | 66.78 | 1.74 | 63.52 | | 88 | 1.63 | 66.42 | 1.73 | 63.40 | 1488 |
| 24 | 1.65 | 62.63 | 1.63 | 62.02 | 1414 | 90 | 1.70 | 54.57 | 1.42 | 58.73 | 1505 |
| 26 | 1.63 | 64.97 | 1.69 | 62.88 | | 92 | 1.75 | 48.36 | 1.26 | 55.77 | 1514 |
| 28 | 1.63 | 66.32 | 1.73 | 63.36 | 1432 | 94 | 1.73 | 50.75 | 1.32 | 56.96 | 1512 |
| 30 | 1.70 | 55.32 | 1.44 | 59.06 | 1510 | 96 | 1.68 | 58.14 | 1.52 | 60.25 | 1539 |
| 32 | 1.73 | 51.38 | 1.34 | 57.26 | 1518 | 98 | 1.71 | 54.01 | 1.41 | 58.48 | 1563 |
| 34 | 1.71 | 53.07 | 1.38 | 58.05 | 1509 | 100 | 1.74 | 49.61 | 1.29 | 56.40 | |
| 36 | 1.69 | 56.55 | 1.47 | 59.59 | 1499 | 102 | | | | | |
| 38 | 1.64 | 63.67 | 1.66 | 62.41 | 1497 | 104 | 1.78 | 45.00 | 1.17 | 53.99 | |
| 40 | 1.77 | 46.71 | 1.22 | 54.91 | 1520 | 106 | 1.72 | 51.79 | 1.35 | 57.46 | |
| 42 | 1.62 | 67.79 | 1.77 | 63.87 | 1488 | 108 | 1.79 | 44.59 | 1.16 | 53.76 | 1532 |
| 44 | 1.62 | 67.92 | 1.77 | 63.91 | 1489 | 110 | 1.80 | 42.87 | 1.12 | 52.78 | 1533 |
| 46 | 1.68 | 57.79 | 1.51 | 60.11 | 1498 | 112 | 1.83 | 40.21 | 1.05 | 51.18 | 1531 |
| 48 | 1.68 | 57.58 | 1.50 | 60.02 | 1504 | 114 | 1.79 | 44.38 | 1.16 | 53.64 | 1533 |
| 50 | 1.66 | 60.79 | 1.59 | 61.32 | 1491 | 116 | 1.82 | 40.85 | 1.07 | 51.58 | 1537 |
| 52 | 1.61 | 69.47 | 1.81 | 64.43 | 1481 | 118 | 1.88 | 35.81 | 0.93 | 48.29 | 1537 |
| 54 | 1.63 | 66.52 | 1.73 | 63.43 | 1482 | 120 | 1.92 | 32.25 | 0.84 | 45.68 | 1543 |
| 56 | 1.62 | 68.24 | 1.78 | 64.02 | 1481 | 122 | 1.99 | 27.32 | 0.71 | 41.60 | |
| 58 | 1.59 | 72.40 | 1.89 | 65.37 | 1479 | 124 | 1.84 | 39.30 | 1.02 | 50.61 | 1542 |
| 60 | 1.62 | 66.73 | 1.74 | 63.50 | 1483 | 126 | 1.81 | 41.46 | 1.08 | 51.95 | 1540 |
| 62 | 1.74 | 50.14 | 1.31 | 56.66 | 1506 | 128 | 1.84 | 39.24 | 1.02 | 50.57 | 1539 |
| 64 | 1.70 | 54.46 | 1.42 | 58.68 | 1501 | 130 | 1.85 | 38.47 | 1.00 | 50.08 | 1539 |

HM 48

HM 48

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 132 | 1.85 | 37.85 | 0.99 | 49.67 | 1536 | 194 | 1.89 | 34.61 | 0.90 | 47.44 | 1566 |
| 134 | 1.82 | 40.74 | 1.06 | 51.51 | 1542 | 196 | 1.82 | 41.10 | 1.07 | 51.73 | |
| 136 | 1.82 | 40.75 | 1.06 | 51.52 | 1541 | 198 | 1.87 | 36.02 | 0.94 | 48.43 | 1552 |
| 138 | 1.84 | 39.15 | 1.02 | 50.52 | 1541 | 200 | 1.91 | 33.10 | 0.86 | 46.32 | |
| 140 | 1.83 | 40.25 | 1.05 | 51.21 | 1542 | 202 | | | | | |
| 142 | 1.88 | 35.69 | 0.93 | 48.20 | 1538 | 204 | 1.85 | 38.13 | 0.99 | 49.85 | |
| 144 | 1.84 | 38.61 | 1.01 | 50.17 | 1542 | 206 | 1.83 | 39.92 | 1.04 | 51.00 | |
| 146 | 1.89 | 34.52 | 0.90 | 47.37 | 1535 | 208 | 1.90 | 33.79 | 0.88 | 46.84 | 1561 |
| 148 | 1.83 | 40.21 | 1.05 | 51.18 | 1543 | 210 | 1.96 | 28.79 | 0.75 | 42.88 | 1580 |
| 150 | 1.85 | 38.44 | 1.00 | 50.06 | 1547 | 212 | 1.91 | 33.08 | 0.86 | 46.31 | 1561 |
| 152 | 1.84 | 38.55 | 1.01 | 50.13 | 1543 | 214 | 1.94 | 30.57 | 0.80 | 44.35 | 1565 |
| 154 | 1.86 | 37.10 | 0.97 | 49.17 | 1548 | 216 | 1.91 | 32.77 | 0.85 | 46.07 | 1568 |
| 156 | 1.87 | 35.87 | 0.94 | 48.33 | 1549 | 218 | 1.93 | 31.50 | 0.82 | 45.10 | 1566 |
| 158 | 1.84 | 38.69 | 1.01 | 50.22 | 1548 | 220 | 1.93 | 31.59 | 0.82 | 45.17 | 1567 |
| 160 | 1.86 | 37.18 | 0.97 | 49.22 | 1545 | 222 | 1.93 | 31.69 | 0.83 | 45.24 | 1569 |
| 162 | 1.87 | 36.46 | 0.95 | 48.74 | 1549 | 224 | 1.92 | 31.93 | 0.83 | 45.43 | 1568 |
| 164 | 1.88 | 34.99 | 0.91 | 47.71 | 1553 | 226 | 1.95 | 29.69 | 0.77 | 43.64 | 1568 |
| 166 | 1.89 | 34.91 | 0.91 | 47.65 | 1553 | 228 | 1.93 | 31.15 | 0.81 | 44.82 | 1566 |
| 168 | 1.87 | 36.41 | 0.95 | 48.70 | 1555 | 230 | 1.94 | 30.57 | 0.80 | 44.35 | 1567 |
| 170 | 1.88 | 35.32 | 0.92 | 47.94 | 1557 | 232 | 1.93 | 31.59 | 0.82 | 45.17 | 1568 |
| 172 | 1.88 | 35.48 | 0.93 | 48.05 | 1556 | 234 | 1.93 | 30.95 | 0.81 | 44.66 | 1568 |
| 174 | 1.88 | 35.44 | 0.92 | 48.03 | 1555 | 236 | 1.89 | 34.43 | 0.90 | 47.31 | 1563 |
| 176 | 1.90 | 34.07 | 0.89 | 47.04 | 1552 | 238 | 1.92 | 32.17 | 0.84 | 45.62 | 1566 |
| 178 | 1.87 | 36.26 | 0.95 | 48.60 | 1556 | 240 | 1.91 | 32.69 | 0.85 | 46.01 | 1569 |
| 180 | 1.90 | 34.09 | 0.89 | 47.06 | 1559 | 242 | 1.93 | 31.14 | 0.81 | 44.81 | 1569 |
| 182 | 1.87 | 36.55 | 0.95 | 48.80 | 1557 | 244 | 1.93 | 31.69 | 0.83 | 45.24 | 1578 |
| 184 | 1.89 | 34.59 | 0.90 | 47.42 | 1558 | 246 | 1.95 | 29.71 | 0.77 | 43.65 | 1576 |
| 186 | 1.86 | 37.59 | 0.98 | 49.50 | 1559 | 248 | 1.78 | 45.53 | 1.19 | 54.28 | |
| 188 | 1.87 | 36.15 | 0.94 | 48.52 | 1559 | 250 | 1.83 | 39.97 | 1.04 | 51.03 | |
| 190 | 1.91 | 32.60 | 0.85 | 45.94 | 1560 | 252 | 1.85 | 37.84 | 0.99 | 49.66 | |
| 192 | 1.86 | 36.79 | 0.96 | 48.96 | 1562 | | | | | | |

HM 49

HM 49

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.63 | 65.02 | 1.70 | 62.90 | 1493 |
| 2 | | | | | | 62 | 1.62 | 67.15 | 1.75 | 63.65 | 1489 |
| 4 | | | | | | 64 | 1.72 | 52.98 | 1.38 | 58.01 | 1509 |
| 6 | | | | | | 66 | 1.69 | 56.32 | 1.47 | 59.49 | 1500 |
| 8 | | | | | | 68 | 1.65 | 61.88 | 1.61 | 61.74 | 1495 |
| 10 | 1.51 | 91.33 | 2.38 | 70.43 | 1500 | 70 | 1.62 | 67.82 | 1.77 | 63.88 | 1488 |
| 12 | 1.51 | 91.04 | 2.37 | 70.36 | 1492 | 72 | 1.60 | 71.01 | 1.85 | 64.93 | 1483 |
| 14 | 1.47 | 103.10 | 2.69 | 72.89 | 1483 | 74 | 1.63 | 65.07 | 1.70 | 62.92 | 1491 |
| 16 | 1.45 | 108.97 | 2.84 | 73.97 | 1478 | 76 | 1.62 | 67.91 | 1.77 | 63.91 | 1483 |
| 18 | 1.46 | 106.39 | 2.77 | 73.50 | 1478 | 78 | 1.59 | 73.98 | 1.93 | 65.86 | 1481 |
| 20 | 1.47 | 103.85 | 2.71 | 73.03 | 1478 | 80 | 1.59 | 72.65 | 1.89 | 65.45 | 1482 |
| 22 | 1.53 | 86.21 | 2.25 | 69.21 | 1482 | 82 | 1.62 | 67.83 | 1.77 | 63.88 | 1484 |
| 24 | 1.56 | 79.91 | 2.08 | 67.57 | 1486 | 84 | 1.68 | 58.00 | 1.51 | 60.20 | 1492 |
| 26 | 1.59 | 74.01 | 1.93 | 65.87 | 1490 | 86 | 1.72 | 52.58 | 1.37 | 57.82 | 1509 |
| 28 | 1.65 | 63.27 | 1.65 | 62.26 | 1497 | 88 | 1.68 | 57.25 | 1.49 | 59.88 | 1501 |
| 30 | 1.65 | 62.96 | 1.64 | 62.15 | 1494 | 90 | 1.64 | 64.36 | 1.68 | 62.66 | 1487 |
| 32 | 1.67 | 59.59 | 1.55 | 60.84 | 1496 | 92 | 1.70 | 55.30 | 1.44 | 59.05 | 1497 |
| 34 | 1.64 | 64.41 | 1.68 | 62.68 | 1492 | 94 | 1.71 | 53.09 | 1.38 | 58.06 | 1503 |
| 36 | 1.60 | 71.05 | 1.85 | 64.94 | 1486 | 96 | 1.55 | 80.91 | 2.11 | 67.84 | |
| 38 | 1.60 | 71.07 | 1.85 | 64.95 | 1485 | 98 | 1.65 | 62.61 | 1.63 | 62.01 | 1525 |
| 40 | 1.66 | 61.03 | 1.59 | 61.41 | 1492 | 100 | 1.70 | 54.93 | 1.43 | 58.88 | 1525 |
| 42 | 1.66 | 61.01 | 1.59 | 61.40 | 1498 | 102 | | | | | |
| 44 | 1.63 | 65.38 | 1.70 | 63.03 | 1491 | 104 | | | | | |
| 46 | 1.59 | 73.17 | 1.91 | 65.61 | 1488 | 106 | 1.51 | 91.40 | 2.38 | 70.44 | |
| 48 | 1.65 | 62.62 | 1.63 | 62.02 | 1490 | 108 | 1.59 | 72.70 | 1.90 | 65.47 | |
| 50 | 1.77 | 46.73 | 1.22 | 54.92 | 1528 | 110 | 1.62 | 67.48 | 1.76 | 63.76 | |
| 52 | 1.60 | 71.87 | 1.87 | 65.21 | 1494 | 112 | 1.60 | 72.19 | 1.88 | 65.31 | |
| 54 | 1.80 | 42.57 | 1.11 | 52.61 | 1535 | 114 | 1.62 | 68.11 | 1.78 | 63.98 | |
| 56 | 1.77 | 46.53 | 1.21 | 54.82 | 1535 | 116 | 1.64 | 64.53 | 1.68 | 62.72 | 1493 |
| 58 | 1.58 | 75.44 | 1.97 | 66.30 | 1481 | 118 | 1.67 | 59.10 | 1.54 | 60.64 | |
| | | | | | | 120 | 1.66 | 60.68 | 1.58 | 61.27 | 1500 |

HM 49

HM 49

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.74 | 50.13 | 1.31 | 56.66 | 1510 | 184 | 1.71 | 54.02 | 1.41 | 58.48 | 1499 |
| 124 | 1.68 | 57.28 | 1.49 | 59.89 | 1495 | 186 | 1.70 | 55.04 | 1.44 | 58.93 | 1496 |
| 126 | 1.62 | 67.95 | 1.77 | 63.92 | 1482 | 188 | 1.72 | 52.55 | 1.37 | 57.81 | 1500 |
| 128 | 1.65 | 62.45 | 1.63 | 61.95 | 1486 | 190 | 1.69 | 56.64 | 1.48 | 59.63 | 1497 |
| 130 | 1.68 | 58.04 | 1.51 | 60.21 | 1495 | 192 | 1.68 | 57.29 | 1.49 | 59.90 | 1494 |
| 132 | 1.78 | 45.65 | 1.19 | 54.35 | 1523 | 194 | 1.69 | 56.98 | 1.49 | 59.77 | 1498 |
| 134 | 1.61 | 69.00 | 1.80 | 64.27 | 1482 | 196 | 1.73 | 51.57 | 1.34 | 57.35 | 1506 |
| 136 | 1.67 | 58.65 | 1.53 | 60.46 | 1491 | 198 | 1.68 | 58.55 | 1.53 | 60.42 | 1520 |
| 138 | 1.63 | 65.94 | 1.72 | 63.22 | 1482 | 200 | 1.72 | 52.21 | 1.36 | 57.65 | 1529 |
| 140 | 1.67 | 59.64 | 1.55 | 60.86 | 1484 | 202 | 1.60 | 72.05 | 1.88 | 65.26 | |
| 142 | 1.63 | 64.99 | 1.69 | 62.89 | 1484 | 204 | 1.67 | 58.86 | 1.53 | 60.55 | |
| 144 | 1.69 | 56.66 | 1.48 | 59.63 | 1485 | 206 | 1.70 | 55.08 | 1.44 | 58.95 | |
| 146 | 1.62 | 66.97 | 1.75 | 63.59 | 1485 | 208 | 1.68 | 58.42 | 1.52 | 60.37 | |
| 148 | 1.59 | 73.06 | 1.91 | 65.58 | 1475 | 210 | 1.67 | 58.93 | 1.54 | 60.58 | |
| 150 | 1.62 | 67.09 | 1.75 | 63.63 | 1481 | 212 | 1.66 | 61.65 | 1.61 | 61.65 | |
| 152 | 1.68 | 57.66 | 1.50 | 60.06 | 1491 | 214 | 1.68 | 57.38 | 1.50 | 59.94 | |
| 154 | 1.65 | 62.93 | 1.64 | 62.13 | 1486 | 216 | 1.68 | 57.50 | 1.50 | 59.99 | |
| 156 | 1.63 | 65.06 | 1.70 | 62.91 | 1484 | 218 | 1.69 | 55.86 | 1.46 | 59.29 | |
| 158 | 1.67 | 58.82 | 1.53 | 60.53 | 1488 | 220 | 1.71 | 53.17 | 1.39 | 58.09 | 1514 |
| 160 | 1.63 | 66.32 | 1.73 | 63.36 | 1484 | 222 | 1.73 | 50.47 | 1.32 | 56.82 | 1521 |
| 162 | 1.63 | 65.08 | 1.70 | 62.92 | 1481 | 224 | 1.73 | 51.67 | 1.35 | 57.40 | 1516 |
| 164 | 1.67 | 59.66 | 1.56 | 60.87 | 1486 | 226 | 1.73 | 51.57 | 1.34 | 57.35 | 1513 |
| 166 | 1.67 | 59.17 | 1.54 | 60.67 | 1489 | 228 | 1.70 | 54.95 | 1.43 | 58.90 | 1503 |
| 168 | 1.71 | 53.89 | 1.41 | 58.42 | 1498 | 230 | 1.66 | 61.18 | 1.60 | 61.47 | 1497 |
| 170 | 1.67 | 59.01 | 1.54 | 60.61 | 1494 | 232 | 1.67 | 60.00 | 1.56 | 61.01 | 1497 |
| 172 | 1.69 | 56.96 | 1.49 | 59.76 | 1495 | 234 | 1.64 | 64.58 | 1.68 | 62.74 | 1492 |
| 174 | 1.70 | 54.76 | 1.43 | 58.81 | 1491 | 236 | 1.62 | 67.12 | 1.75 | 63.64 | 1487 |
| 176 | 1.67 | 59.81 | 1.56 | 60.93 | 1488 | 238 | 1.62 | 68.02 | 1.77 | 63.94 | 1485 |
| 178 | 1.66 | 60.61 | 1.58 | 61.24 | 1491 | 240 | 1.67 | 59.94 | 1.56 | 60.98 | 1491 |
| 180 | 1.72 | 52.45 | 1.37 | 57.76 | 1499 | 242 | 1.66 | 60.48 | 1.58 | 61.20 | 1493 |
| 182 | 1.69 | 56.07 | 1.46 | 59.38 | 1495 | 244 | 1.66 | 61.68 | 1.61 | 61.66 | 1494 |

HM 49

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.70 | 55.68 | 1.45 | 59.21 | 1497 |
| 248 | 1.72 | 52.79 | 1.38 | 57.92 | 1505 |
| 250 | 1.73 | 51.68 | 1.35 | 57.40 | 1508 |
| 252 | 1.71 | 54.32 | 1.42 | 58.61 | 1511 |
| 254 | 1.70 | 55.29 | 1.44 | 59.04 | 1504 |
| 256 | 1.68 | 57.16 | 1.49 | 59.85 | 1498 |
| 258 | 1.65 | 62.52 | 1.63 | 61.98 | 1491 |
| 260 | 1.72 | 52.05 | 1.36 | 57.57 | 1505 |
| 262 | 1.72 | 51.76 | 1.35 | 57.44 | 1510 |
| 264 | 1.71 | 53.92 | 1.41 | 58.44 | 1508 |
| 266 | 1.63 | 65.11 | 1.70 | 62.93 | 1499 |
| 268 | 1.65 | 61.96 | 1.62 | 61.77 | 1494 |
| 270 | 1.63 | 65.30 | 1.70 | 63.00 | 1484 |
| 272 | 1.62 | 67.42 | 1.76 | 63.74 | 1486 |
| 274 | 1.72 | 52.66 | 1.37 | 57.86 | 1502 |
| 276 | 1.70 | 55.63 | 1.45 | 59.19 | 1511 |
| 278 | 1.72 | 52.15 | 1.36 | 57.62 | 1510 |
| 280 | 1.74 | 50.35 | 1.31 | 56.76 | 1517 |
| 282 | 1.74 | 49.83 | 1.30 | 56.51 | 1517 |
| 284 | 1.75 | 49.12 | 1.28 | 56.15 | 1523 |
| 286 | 1.78 | 45.26 | 1.18 | 54.13 | 1524 |
| 288 | 1.73 | 50.80 | 1.32 | 56.98 | 1520 |
| 290 | 1.65 | 62.42 | 1.63 | 61.94 | |
| 292 | 1.64 | 64.85 | 1.69 | 62.84 | |

HM 50

HM 50

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|----------------------|--|----------------------|------------|-----------------|-------------|----------------------|--|----------------------|------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.73 | 50.63 | 1.32 | 56.90 | 1524 |
| 2 | | | | | | 62 | 1.80 | 42.81 | 1.12 | 52.75 | 1541 |
| 4 | | | | | | 64 | 1.60 | 70.68 | 1.84 | 64.83 | 1489 |
| 6 | | | | | | 66 | 1.63 | 65.82 | 1.72 | 63.18 | 1490 |
| 8 | | | | | | 68 | 1.61 | 68.71 | 1.79 | 64.18 | 1489 |
| 10 | | | | | | 70 | 1.62 | 67.33 | 1.76 | 63.71 | 1494 |
| 12 | | | | | | 72 | 1.69 | 55.91 | 1.46 | 59.32 | 1504 |
| 14 | 1.48 | 98.77 | 2.58 | 72.03 | 1498 | 74 | 1.66 | 61.33 | 1.60 | 61.53 | 1498 |
| 16 | 1.50 | 94.86 | 2.47 | 71.21 | 1488 | 76 | 1.66 | 61.45 | 1.60 | 61.57 | 1493 |
| 18 | 1.48 | 99.27 | 2.59 | 72.13 | 1484 | 78 | 1.67 | 59.29 | 1.55 | 60.72 | 1496 |
| 20 | 1.49 | 96.12 | 2.51 | 71.48 | 1486 | 80 | 1.74 | 50.39 | 1.31 | 56.78 | |
| 22 | 1.50 | 95.18 | 2.48 | 71.28 | 1489 | 82 | 1.60 | 70.32 | 1.83 | 64.71 | 1484 |
| 24 | 1.53 | 87.10 | 2.27 | 69.43 | 1489 | 84 | 1.58 | 74.88 | 1.95 | 66.13 | 1479 |
| 26 | 1.50 | 94.73 | 2.47 | 71.18 | 1479 | 86 | 1.59 | 73.48 | 1.92 | 65.70 | 1482 |
| 28 | 1.53 | 86.38 | 2.25 | 69.25 | 1481 | 88 | 1.58 | 74.21 | 1.94 | 65.93 | 1484 |
| 30 | 1.57 | 76.43 | 1.99 | 66.59 | 1484 | 90 | 1.60 | 70.65 | 1.84 | 64.81 | 1489 |
| 32 | 1.59 | 73.22 | 1.91 | 65.63 | 1489 | 92 | 1.67 | 59.69 | 1.56 | 60.88 | 1499 |
| 34 | 1.67 | 59.91 | 1.56 | 60.97 | 1495 | 94 | 1.68 | 57.17 | 1.49 | 59.85 | 1504 |
| 36 | 1.65 | 62.08 | 1.62 | 61.81 | 1496 | 96 | 1.63 | 66.39 | 1.73 | 63.38 | |
| 38 | 1.66 | 60.67 | 1.58 | 61.27 | 1498 | 98 | 1.62 | 67.14 | 1.75 | 63.64 | 1517 |
| 40 | 1.60 | 70.75 | 1.84 | 64.85 | 1490 | 100 | 1.75 | 48.77 | 1.27 | 55.98 | |
| 42 | 1.60 | 71.20 | 1.86 | 64.99 | 1484 | 102 | | | | | |
| 44 | 1.60 | 71.13 | 1.85 | 64.97 | 1487 | 104 | 1.52 | 88.36 | 2.30 | 69.73 | |
| 46 | 1.63 | 65.25 | 1.70 | 62.98 | 1494 | 106 | 1.56 | 79.04 | 2.06 | 67.33 | |
| 48 | 1.65 | 63.08 | 1.64 | 62.19 | 1495 | 108 | 1.67 | 58.73 | 1.53 | 60.49 | |
| 50 | 1.59 | 73.74 | 1.92 | 65.78 | 1486 | 110 | 1.65 | 62.22 | 1.62 | 61.87 | |
| 52 | 1.64 | 64.31 | 1.68 | 62.64 | 1490 | 112 | 1.62 | 66.86 | 1.74 | 63.55 | |
| 54 | 1.62 | 68.19 | 1.78 | 64.00 | 1493 | 114 | 1.59 | 73.12 | 1.91 | 65.60 | |
| 56 | 1.82 | 41.10 | 1.07 | 51.73 | 1542 | 116 | 1.61 | 69.02 | 1.80 | 64.28 | |
| 58 | 1.74 | 49.60 | 1.29 | 56.39 | 1491 | 118 | 1.61 | 69.96 | 1.82 | 64.59 | |
| | | | | | | 120 | 1.61 | 70.25 | 1.83 | 64.68 | |

HM 50

HM 50

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.64 | 64.82 | 1.69 | 62.83 | 1476 | 184 | 1.67 | 58.72 | 1.53 | 60.49 | 1489 |
| 124 | 1.67 | 59.20 | 1.54 | 60.68 | 1490 | 186 | 1.70 | 54.68 | 1.43 | 58.77 | 1497 |
| 126 | 1.67 | 59.14 | 1.54 | 60.66 | 1509 | 188 | 1.69 | 56.08 | 1.46 | 59.39 | 1493 |
| 128 | 1.73 | 50.83 | 1.33 | 56.99 | 1505 | 190 | 1.67 | 59.81 | 1.56 | 60.93 | 1489 |
| 130 | 1.72 | 51.85 | 1.35 | 57.48 | 1486 | 192 | 1.67 | 59.75 | 1.56 | 60.91 | 1492 |
| 132 | 1.62 | 67.43 | 1.76 | 63.74 | 1489 | 194 | 1.69 | 56.26 | 1.47 | 59.46 | 1497 |
| 134 | 1.65 | 62.50 | 1.63 | 61.97 | 1488 | 196 | 1.64 | 64.69 | 1.69 | 62.78 | |
| 136 | 1.65 | 62.37 | 1.63 | 61.92 | 1486 | 198 | 1.70 | 54.85 | 1.43 | 58.85 | |
| 138 | 1.66 | 60.20 | 1.57 | 61.08 | 1486 | 200 | 1.73 | 50.73 | 1.32 | 56.95 | 1485 |
| 140 | 1.65 | 61.94 | 1.61 | 61.76 | 1487 | 202 | | | | | |
| 142 | 1.66 | 60.80 | 1.59 | 61.32 | 1484 | 204 | | | | | |
| 144 | 1.67 | 59.85 | 1.56 | 60.95 | 1487 | 206 | 1.56 | 78.70 | 2.05 | 67.23 | |
| 146 | 1.65 | 62.81 | 1.64 | 62.09 | 1485 | 208 | 1.65 | 62.72 | 1.64 | 62.06 | |
| 148 | 1.65 | 62.49 | 1.63 | 61.97 | 1492 | 210 | 1.66 | 60.30 | 1.57 | 61.12 | |
| 150 | 1.65 | 62.84 | 1.64 | 62.10 | 1489 | 212 | 1.74 | 50.37 | 1.31 | 56.77 | |
| 152 | 1.64 | 63.69 | 1.66 | 62.42 | 1490 | 214 | 1.72 | 52.94 | 1.38 | 57.99 | |
| 154 | 1.70 | 54.91 | 1.43 | 58.88 | 1489 | 216 | 1.70 | 54.92 | 1.43 | 58.88 | |
| 156 | 1.66 | 60.45 | 1.58 | 61.18 | 1489 | 218 | 1.69 | 56.68 | 1.48 | 59.64 | |
| 158 | 1.69 | 56.60 | 1.48 | 59.61 | 1489 | 220 | 1.69 | 56.08 | 1.46 | 59.38 | |
| 160 | 1.69 | 56.98 | 1.49 | 59.77 | 1490 | 222 | 1.69 | 56.80 | 1.48 | 59.69 | 1480 |
| 162 | 1.69 | 56.80 | 1.48 | 59.69 | 1486 | 224 | 1.72 | 52.89 | 1.38 | 57.97 | 1497 |
| 164 | 1.68 | 58.55 | 1.53 | 60.42 | 1488 | 226 | 1.70 | 54.45 | 1.42 | 58.67 | 1496 |
| 166 | 1.67 | 59.86 | 1.56 | 60.95 | 1487 | 228 | 1.69 | 56.68 | 1.48 | 59.64 | 1495 |
| 168 | 1.67 | 59.34 | 1.55 | 60.74 | 1492 | 230 | 1.71 | 53.01 | 1.38 | 58.02 | 1495 |
| 170 | 1.68 | 57.96 | 1.51 | 60.18 | 1492 | 232 | 1.72 | 52.65 | 1.37 | 57.86 | 1490 |
| 172 | 1.67 | 59.36 | 1.55 | 60.75 | 1489 | 234 | 1.69 | 56.70 | 1.48 | 59.65 | 1489 |
| 174 | 1.70 | 55.52 | 1.45 | 59.15 | 1490 | 236 | 1.71 | 53.70 | 1.40 | 58.34 | 1494 |
| 176 | 1.67 | 59.77 | 1.56 | 60.91 | 1487 | 238 | 1.68 | 57.45 | 1.50 | 59.97 | 1488 |
| 178 | 1.67 | 59.19 | 1.54 | 60.68 | 1490 | 240 | 1.65 | 62.48 | 1.63 | 61.96 | 1488 |
| 180 | 1.67 | 59.49 | 1.55 | 60.80 | 1487 | 242 | 1.71 | 54.26 | 1.41 | 58.59 | 1493 |
| 182 | 1.66 | 61.05 | 1.59 | 61.42 | 1487 | 244 | 1.69 | 56.85 | 1.48 | 59.72 | 1491 |

HM 50

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.70 | 55.14 | 1.44 | 58.98 | 1491 |
| 248 | 1.71 | 53.82 | 1.40 | 58.39 | 1491 |
| 250 | 1.69 | 55.86 | 1.46 | 59.29 | 1491 |
| 252 | 1.71 | 53.38 | 1.39 | 58.19 | 1492 |
| 254 | 1.71 | 54.27 | 1.41 | 58.59 | 1493 |
| 256 | 1.72 | 52.81 | 1.38 | 57.93 | 1495 |
| 258 | 1.71 | 53.09 | 1.38 | 58.06 | 1494 |
| 260 | 1.71 | 53.27 | 1.39 | 58.14 | 1493 |
| 262 | 1.70 | 55.53 | 1.45 | 59.15 | 1494 |
| 264 | 1.69 | 56.88 | 1.48 | 59.73 | 1494 |
| 266 | 1.70 | 55.22 | 1.44 | 59.01 | 1493 |
| 268 | 1.68 | 57.41 | 1.50 | 59.95 | 1492 |
| 270 | 1.70 | 55.63 | 1.45 | 59.19 | 1473 |
| 272 | 1.74 | 49.80 | 1.30 | 56.49 | 1502 |
| 274 | 1.73 | 50.64 | 1.32 | 56.90 | 1506 |
| 276 | 1.74 | 49.91 | 1.30 | 56.55 | 1507 |
| 278 | 1.71 | 53.05 | 1.38 | 58.04 | 1508 |
| 280 | 1.64 | 64.21 | 1.67 | 62.61 | |
| 282 | 1.71 | 53.67 | 1.40 | 58.32 | 1530 |
| 284 | 1.75 | 48.59 | 1.27 | 55.89 | 1529 |

HM 51

HM 51

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.92 | 32.49 | 0.85 | 45.86 | 1541 |
| 2 | | | | | | 62 | 1.89 | 34.56 | 0.90 | 47.40 | 1539 |
| 4 | | | | | | 64 | 1.89 | 34.74 | 0.91 | 47.53 | 1539 |
| 6 | | | | | | 66 | 1.89 | 34.36 | 0.90 | 47.25 | 1542 |
| 8 | | | | | 1495 | 68 | 1.89 | 34.45 | 0.90 | 47.32 | 1542 |
| 10 | 1.68 | 57.43 | 1.50 | 59.96 | 1497 | 70 | 1.88 | 35.45 | 0.92 | 48.03 | 1543 |
| 12 | 1.72 | 52.10 | 1.36 | 57.60 | 1497 | 72 | 1.89 | 34.45 | 0.90 | 47.32 | 1544 |
| 14 | 1.75 | 49.05 | 1.28 | 56.12 | 1498 | 74 | 1.89 | 34.86 | 0.91 | 47.62 | 1543 |
| 16 | 1.71 | 53.35 | 1.39 | 58.18 | 1495 | 76 | 1.89 | 34.35 | 0.90 | 47.25 | 1544 |
| 18 | 1.67 | 59.72 | 1.56 | 60.89 | 1490 | 78 | 1.90 | 33.39 | 0.87 | 46.54 | 1544 |
| 20 | 1.74 | 49.98 | 1.30 | 56.58 | 1499 | 80 | 1.91 | 32.85 | 0.86 | 46.14 | 1545 |
| 22 | 1.74 | 50.06 | 1.31 | 56.62 | 1498 | 82 | 1.89 | 34.80 | 0.91 | 47.57 | 1544 |
| 24 | 1.70 | 55.17 | 1.44 | 58.99 | 1492 | 84 | 1.90 | 33.66 | 0.88 | 46.74 | 1544 |
| 26 | 1.72 | 52.35 | 1.37 | 57.72 | 1499 | 86 | 1.91 | 32.91 | 0.86 | 46.18 | 1545 |
| 28 | 1.74 | 49.63 | 1.29 | 56.41 | 1502 | 88 | 1.90 | 33.86 | 0.88 | 46.89 | 1549 |
| 30 | 1.75 | 49.08 | 1.28 | 56.13 | 1504 | 90 | 1.90 | 33.70 | 0.88 | 46.78 | 1549 |
| 32 | 1.78 | 45.55 | 1.19 | 54.29 | 1512 | 92 | 1.91 | 32.98 | 0.86 | 46.23 | 1549 |
| 34 | 1.76 | 47.36 | 1.23 | 55.25 | 1508 | 94 | | | | | |
| 36 | 1.78 | 45.28 | 1.18 | 54.14 | 1511 | 96 | | | | | |
| 38 | 1.81 | 41.60 | 1.08 | 52.03 | 1520 | 98 | | | | | |
| 40 | 1.82 | 41.44 | 1.08 | 51.93 | 1523 | 100 | 1.77 | 46.52 | 1.21 | 54.81 | |
| 42 | 1.87 | 36.11 | 0.94 | 48.50 | 1544 | 102 | 1.74 | 49.31 | 1.29 | 56.25 | |
| 44 | 1.88 | 35.42 | 0.92 | 48.02 | 1538 | 104 | 1.75 | 48.02 | 1.25 | 55.59 | |
| 46 | 1.89 | 34.66 | 0.90 | 47.47 | 1540 | 106 | 1.83 | 40.44 | 1.05 | 51.32 | 1544 |
| 48 | 1.91 | 32.71 | 0.85 | 46.03 | 1538 | 108 | 1.85 | 38.47 | 1.00 | 50.08 | 1540 |
| 50 | 1.89 | 34.29 | 0.89 | 47.21 | 1540 | 110 | 1.84 | 38.80 | 1.01 | 50.29 | 1544 |
| 52 | 1.89 | 34.24 | 0.89 | 47.17 | 1541 | 112 | 1.84 | 39.02 | 1.02 | 50.43 | 1542 |
| 54 | 1.89 | 34.51 | 0.90 | 47.36 | 1541 | 114 | 1.85 | 38.50 | 1.00 | 50.10 | 1542 |
| 56 | 1.89 | 34.48 | 0.90 | 47.34 | 1539 | 116 | 1.83 | 39.66 | 1.03 | 50.84 | 1543 |
| 58 | 1.89 | 34.35 | 0.90 | 47.25 | 1540 | 118 | 1.83 | 39.97 | 1.04 | 51.03 | 1543 |
| | | | | | | 120 | 1.83 | 40.16 | 1.05 | 51.15 | 1543 |

HM 51

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.83 | 40.04 | 1.04 | 51.07 | 1544 |
| 124 | 1.83 | 40.11 | 1.05 | 51.12 | 1545 |
| 126 | 1.87 | 36.44 | 0.95 | 48.72 | 1546 |
| 128 | 1.84 | 38.97 | 1.02 | 50.40 | 1547 |
| 130 | 1.81 | 41.51 | 1.08 | 51.98 | 1550 |
| 132 | 1.73 | 50.90 | 1.33 | 57.03 | |
| 134 | 1.83 | 40.22 | 1.05 | 51.19 | 1529 |
| 136 | 1.87 | 36.12 | 0.94 | 48.50 | |

HM 52

HM 52

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 62 | | | | | 1495 |
| 2 | | | | | | 64 | | | | | 1494 |
| 4 | | | | | | 66 | | | | | 1496 |
| 6 | | | | | 1513 | 68 | | | | | 1501 |
| 8 | 1.68 | 58.57 | 1.53 | 60.43 | | 70 | | | | | 1508 |
| 10 | 1.66 | 60.99 | 1.59 | 61.39 | 1587 | 72 | | | | | 1507 |
| 12 | 1.67 | 59.71 | 1.56 | 60.89 | | 74 | | | | | 1504 |
| 14 | | | | | | 76 | | | | | 1498 |
| 16 | | | | | | 78 | | | | | 1488 |
| 18 | | | | | 1428 | 80 | | | | | 1491 |
| 20 | | | | | 1479 | 82 | | | | | 1495 |
| 22 | | | | | 1496 | 84 | | | | | 1498 |
| 24 | | | | | 1486 | 86 | | | | | 1492 |
| 26 | | | | | 1492 | 88 | | | | | 1492 |
| 28 | | | | | 1494 | 90 | | | | | 1496 |
| 30 | | | | | 1501 | 92 | | | | | 1516 |
| 32 | | | | | 1510 | 94 | | | | | 1522 |
| 34 | | | | | 1500 | 96 | | | | | |
| 36 | | | | | 1492 | 98 | | | | | |
| 38 | | | | | 1494 | 100 | | | | | 1400 |
| 40 | | | | | 1502 | 102 | | | | | 1499 |
| 42 | | | | | 1495 | 104 | | | | | |
| 44 | | | | | 1489 | 106 | 1.86 | 37.21 | 0.97 | 49.24 | |
| 46 | | | | | 1494 | 108 | 1.74 | 49.38 | 1.29 | 56.29 | 1414 |
| 48 | | | | | 1500 | 110 | 1.77 | 46.71 | 1.22 | 54.91 | |
| 50 | | | | | 1499 | 112 | 1.84 | 38.58 | 1.01 | 50.15 | |
| 52 | | | | | 1552 | 114 | 1.70 | 54.55 | 1.42 | 58.72 | |
| 54 | | | | | 1556 | 116 | 1.69 | 55.81 | 1.46 | 59.27 | |
| 56 | | | | | 1550 | 118 | 1.69 | 56.73 | 1.48 | 59.67 | 1486 |
| 58 | | | | | 1502 | 120 | 1.70 | 54.42 | 1.42 | 58.66 | 1487 |
| 60 | | | | | 1534 | 122 | 1.69 | 55.81 | 1.46 | 59.27 | 1487 |
| | | | | | 1556 | 124 | 1.72 | 52.94 | 1.38 | 57.99 | 1489 |

HM 52

HM 52

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 126 | 1.72 | 51.84 | 1.35 | 57.48 | 1492 | 192 | 1.75 | 48.73 | 1.27 | 55.96 | 1497 |
| 128 | 1.72 | 52.88 | 1.38 | 57.96 | 1491 | 194 | 1.74 | 49.95 | 1.30 | 56.57 | 1496 |
| 130 | 1.77 | 46.46 | 1.21 | 54.78 | 1499 | 196 | | | | | |
| 132 | 1.77 | 46.47 | 1.21 | 54.79 | 1506 | 198 | | | | | |
| 134 | 1.82 | 40.74 | 1.06 | 51.51 | 1517 | 200 | | | | | |
| 136 | 1.76 | 47.44 | 1.24 | 55.30 | 1503 | 202 | | | | | |
| 138 | 1.70 | 54.66 | 1.43 | 58.77 | 1489 | 204 | | | | | |
| 140 | 1.71 | 54.08 | 1.41 | 58.51 | 1490 | 206 | | | | | |
| 142 | 1.76 | 47.99 | 1.25 | 55.58 | 1500 | 208 | 1.49 | 96.18 | 2.51 | 71.49 | |
| 144 | 1.79 | 44.16 | 1.15 | 53.52 | 1508 | 210 | 1.52 | 88.01 | 2.29 | 69.65 | |
| 146 | 1.81 | 41.55 | 1.08 | 52.00 | 1531 | 212 | 1.58 | 75.91 | 1.98 | 66.44 | |
| 148 | 1.68 | 57.40 | 1.50 | 59.95 | 1486 | 214 | 1.60 | 71.58 | 1.87 | 65.11 | |
| 150 | 1.76 | 46.85 | 1.22 | 54.99 | 1498 | 216 | 1.62 | 68.20 | 1.78 | 64.01 | |
| 152 | 1.70 | 55.14 | 1.44 | 58.98 | 1489 | 218 | 1.65 | 63.12 | 1.65 | 62.21 | |
| 154 | 1.71 | 54.14 | 1.41 | 58.53 | 1487 | 220 | 1.69 | 55.93 | 1.46 | 59.32 | |
| 156 | 1.72 | 51.76 | 1.35 | 57.44 | 1489 | 222 | 1.72 | 52.91 | 1.38 | 57.97 | |
| 158 | 1.73 | 51.27 | 1.34 | 57.21 | 1490 | 224 | 1.67 | 58.74 | 1.53 | 60.50 | |
| 160 | 1.87 | 36.12 | 0.94 | 48.50 | 1502 | 226 | 1.69 | 57.09 | 1.49 | 59.82 | |
| 162 | 1.69 | 56.54 | 1.47 | 59.58 | 1484 | 228 | 1.69 | 56.15 | 1.46 | 59.42 | |
| 164 | 1.67 | 58.74 | 1.53 | 60.50 | 1482 | 230 | 1.69 | 56.90 | 1.48 | 59.74 | |
| 166 | 1.67 | 58.62 | 1.53 | 60.45 | 1483 | 232 | 1.72 | 52.64 | 1.37 | 57.85 | |
| 168 | 1.73 | 50.61 | 1.32 | 56.89 | 1492 | 234 | 1.71 | 54.08 | 1.41 | 58.51 | |
| 170 | 1.74 | 50.07 | 1.31 | 56.62 | 1494 | 236 | 1.73 | 51.27 | 1.34 | 57.21 | 1501 |
| 172 | 1.72 | 51.90 | 1.35 | 57.51 | 1493 | 238 | 1.71 | 53.28 | 1.39 | 58.15 | 1501 |
| 174 | 1.68 | 58.47 | 1.52 | 60.39 | 1486 | 240 | 1.70 | 55.40 | 1.44 | 59.09 | 1497 |
| 176 | 1.71 | 53.75 | 1.40 | 58.36 | 1489 | 242 | 1.69 | 57.09 | 1.49 | 59.82 | 1495 |
| 178 | 1.72 | 52.01 | 1.36 | 57.56 | 1492 | 244 | 1.72 | 52.68 | 1.37 | 57.87 | 1503 |
| 180 | 1.69 | 56.45 | 1.47 | 59.55 | 1488 | 246 | 1.73 | 51.04 | 1.33 | 57.10 | 1507 |
| 182 | 1.71 | 53.70 | 1.40 | 58.34 | 1490 | 248 | 1.74 | 50.38 | 1.31 | 56.78 | 1515 |
| 184 | 1.80 | 43.28 | 1.13 | 53.02 | 1504 | 250 | 1.75 | 49.08 | 1.28 | 56.13 | 1513 |
| 186 | 1.75 | 48.43 | 1.26 | 55.80 | 1500 | | | | | | |
| 188 | 1.77 | 46.72 | 1.22 | 54.92 | 1502 | | | | | | |
| 190 | 1.76 | 47.64 | 1.24 | 55.40 | 1499 | | | | | | |

HM 53

HM 53

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.60 | 71.47 | 1.86 | 65.08 | 1488 |
| 2 | | | | | | 62 | 1.59 | 73.16 | 1.91 | 65.61 | 1488 |
| 4 | | | | | | 64 | 1.61 | 69.33 | 1.81 | 64.38 | 1492 |
| 6 | | | | | | 66 | 1.62 | 66.92 | 1.74 | 63.57 | 1493 |
| 8 | | | | | | 68 | 1.61 | 69.28 | 1.81 | 64.37 | 1493 |
| 10 | | | | | | 70 | 1.60 | 71.25 | 1.86 | 65.01 | 1487 |
| 12 | | | | | | 72 | 1.60 | 71.15 | 1.86 | 64.98 | 1491 |
| 14 | | | | | | 74 | 1.64 | 63.57 | 1.66 | 62.37 | 1495 |
| 16 | | | | | | 76 | 1.56 | 79.91 | 2.08 | 67.57 | 1485 |
| 18 | | | | | | 78 | 1.77 | 45.73 | 1.19 | 54.39 | 1552 |
| 20 | | | | | | 80 | 1.82 | 41.40 | 1.08 | 51.91 | 1557 |
| 22 | 1.48 | 99.39 | 2.59 | 72.16 | 1495 | 82 | 1.84 | 38.56 | 1.01 | 50.13 | 1560 |
| 24 | 1.50 | 94.87 | 2.47 | 71.21 | 1491 | 84 | 1.84 | 38.79 | 1.01 | 50.28 | 1559 |
| 26 | 1.48 | 99.86 | 2.60 | 72.25 | 1491 | 86 | 1.80 | 42.55 | 1.11 | 52.60 | 1550 |
| 28 | 1.49 | 97.38 | 2.54 | 71.74 | 1487 | 88 | 1.54 | 84.12 | 2.19 | 68.69 | 1494 |
| 30 | 1.48 | 99.32 | 2.59 | 72.14 | 1487 | 90 | 1.77 | 46.77 | 1.22 | 54.95 | 1531 |
| 32 | 1.49 | 98.19 | 2.56 | 71.91 | 1488 | 92 | 1.85 | 38.23 | 1.00 | 49.92 | 1557 |
| 34 | 1.49 | 96.84 | 2.52 | 71.63 | 1487 | 94 | 1.57 | 76.44 | 1.99 | 66.59 | 1489 |
| 36 | 1.50 | 94.10 | 2.45 | 71.05 | 1489 | 96 | 1.57 | 76.49 | 1.99 | 66.60 | |
| 38 | 1.51 | 92.01 | 2.40 | 70.58 | 1487 | 98 | 1.63 | 66.18 | 1.73 | 63.31 | |
| 40 | 1.49 | 95.78 | 2.50 | 71.41 | 1481 | 100 | 1.72 | 52.08 | 1.36 | 57.59 | |
| 42 | 1.50 | 94.99 | 2.48 | 71.24 | 1481 | 102 | | | | | |
| 44 | 1.53 | 85.68 | 2.23 | 69.08 | 1484 | 104 | 1.59 | 73.72 | 1.92 | 65.78 | |
| 46 | 1.56 | 80.19 | 2.09 | 67.65 | 1491 | 106 | 1.91 | 33.27 | 0.87 | 46.45 | |
| 48 | 1.58 | 75.14 | 1.96 | 66.21 | 1490 | 108 | 1.76 | 47.43 | 1.24 | 55.29 | 1509 |
| 50 | 1.56 | 78.42 | 2.04 | 67.16 | 1489 | 110 | 1.75 | 48.33 | 1.26 | 55.75 | 1499 |
| 52 | 1.60 | 71.71 | 1.87 | 65.15 | 1494 | 112 | 1.68 | 57.98 | 1.51 | 60.19 | 1488 |
| 54 | 1.65 | 62.24 | 1.62 | 61.87 | 1504 | 114 | 1.67 | 59.71 | 1.56 | 60.89 | 1487 |
| 56 | 1.64 | 64.58 | 1.68 | 62.74 | 1502 | 116 | 1.67 | 59.57 | 1.55 | 60.83 | 1484 |
| 58 | 1.62 | 67.32 | 1.76 | 63.71 | 1494 | 118 | 1.67 | 58.93 | 1.54 | 60.58 | 1486 |
| | | | | | | 120 | 1.66 | 60.22 | 1.57 | 61.09 | 1483 |

HM 53

HM 53

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.66 | 60.71 | 1.58 | 61.28 | 1483 | 184 | 1.75 | 48.72 | 1.27 | 55.96 | 1502 |
| 124 | 1.67 | 59.98 | 1.56 | 61.00 | 1484 | 186 | 1.74 | 49.90 | 1.30 | 56.54 | 1502 |
| 126 | 1.65 | 62.51 | 1.63 | 61.98 | 1485 | 188 | 1.80 | 42.64 | 1.11 | 52.65 | 1517 |
| 128 | 1.69 | 56.03 | 1.46 | 59.36 | 1490 | 190 | 1.82 | 40.89 | 1.07 | 51.60 | 1525 |
| 130 | 1.75 | 48.28 | 1.26 | 55.73 | 1504 | 192 | 1.97 | 28.08 | 0.73 | 42.27 | 1560 |
| 132 | 1.76 | 47.66 | 1.24 | 55.41 | 1508 | 194 | 1.95 | 29.47 | 0.77 | 43.45 | 1563 |
| 134 | 1.74 | 49.77 | 1.30 | 56.48 | 1502 | 196 | 2.11 | 19.75 | 0.51 | 33.99 | |
| 136 | 1.69 | 56.69 | 1.48 | 59.65 | 1494 | 198 | 2.16 | 17.19 | 0.45 | 30.95 | |
| 138 | 1.68 | 58.12 | 1.52 | 60.24 | 1488 | 200 | 2.23 | 14.01 | 0.37 | 26.75 | |
| 140 | 1.75 | 48.55 | 1.27 | 55.87 | 1502 | | | | | | |
| 142 | 1.76 | 47.48 | 1.24 | 55.32 | 1503 | | | | | | |
| 144 | 1.71 | 54.13 | 1.41 | 58.53 | 1494 | | | | | | |
| 146 | 1.68 | 58.29 | 1.52 | 60.31 | 1487 | | | | | | |
| 148 | 1.73 | 51.29 | 1.34 | 57.22 | 1494 | | | | | | |
| 150 | 1.71 | 54.25 | 1.41 | 58.58 | 1490 | | | | | | |
| 152 | 1.65 | 61.89 | 1.61 | 61.74 | 1484 | | | | | | |
| 154 | 1.65 | 62.71 | 1.64 | 62.05 | 1483 | | | | | | |
| 156 | 1.69 | 56.48 | 1.47 | 59.56 | 1485 | | | | | | |
| 158 | 1.68 | 57.85 | 1.51 | 60.13 | 1485 | | | | | | |
| 160 | 1.67 | 59.01 | 1.54 | 60.61 | 1484 | | | | | | |
| 162 | 1.69 | 56.67 | 1.48 | 59.64 | 1486 | | | | | | |
| 164 | 1.71 | 54.00 | 1.41 | 58.47 | 1489 | | | | | | |
| 166 | 1.70 | 54.87 | 1.43 | 58.86 | 1489 | | | | | | |
| 168 | 1.71 | 54.33 | 1.42 | 58.62 | 1491 | | | | | | |
| 170 | 1.72 | 51.76 | 1.35 | 57.44 | 1496 | | | | | | |
| 172 | 1.77 | 46.62 | 1.22 | 54.86 | 1505 | | | | | | |
| 174 | 1.83 | 40.11 | 1.05 | 51.12 | 1518 | | | | | | |
| 176 | 1.75 | 48.46 | 1.26 | 55.82 | 1503 | | | | | | |
| 178 | 1.70 | 54.87 | 1.43 | 58.86 | 1489 | | | | | | |
| 180 | 1.68 | 57.79 | 1.51 | 60.11 | 1485 | | | | | | |
| 182 | 1.68 | 57.30 | 1.49 | 59.91 | 1490 | | | | | | |

HM 54

HM 54

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 64 | 1.65 | 62.59 | 1.63 | 62.01 | 1493 |
| 2 | | | | | | 66 | 1.60 | 71.16 | 1.86 | 64.98 | 1484 |
| 4 | | | | | | 68 | 1.59 | 72.79 | 1.90 | 65.49 | 1486 |
| 6 | | | | | | 70 | 1.59 | 72.66 | 1.89 | 65.45 | 1489 |
| 8 | | | | | | 72 | 1.66 | 60.75 | 1.58 | 61.30 | 1524 |
| 10 | | | | | | 74 | 1.82 | 41.14 | 1.07 | 51.76 | 1530 |
| 12 | | | | | | 76 | 1.72 | 51.77 | 1.35 | 57.45 | 1479 |
| 14 | 1.45 | 111.48 | | | | 78 | 1.61 | 68.50 | 1.79 | 64.11 | 1488 |
| 16 | 1.45 | 110.23 | 2.91 | 74.40 | 1494 | 80 | 1.61 | 69.70 | 1.82 | 64.51 | 1488 |
| 18 | 1.49 | 95.74 | 2.87 | 74.19 | 1484 | 82 | 1.68 | 58.08 | 1.51 | 60.23 | 1503 |
| 20 | 1.46 | 105.83 | 2.50 | 71.40 | 1484 | 84 | 1.65 | 63.12 | 1.65 | 62.20 | 1495 |
| 22 | 1.47 | 103.22 | 2.76 | 73.40 | 1484 | 86 | 1.67 | 59.74 | 1.56 | 60.90 | 1495 |
| 24 | 1.45 | 110.24 | 2.69 | 72.91 | 1486 | 88 | 1.64 | 64.64 | 1.69 | 62.76 | 1489 |
| 26 | 1.43 | 118.42 | 2.87 | 74.19 | 1483 | 90 | 1.61 | 69.96 | 1.82 | 64.59 | 1483 |
| 28 | 1.41 | 126.21 | 3.09 | 75.54 | 1479 | 92 | 1.60 | 70.80 | 1.85 | 64.86 | 1485 |
| 30 | 1.42 | 119.52 | 3.29 | 76.69 | 1477 | 94 | 1.61 | 68.68 | 1.79 | 64.17 | 1484 |
| 32 | 1.42 | 120.09 | 3.12 | 75.71 | 1477 | 96 | | | | | |
| 34 | 1.43 | 115.67 | 3.13 | 75.79 | 1477 | 98 | 1.66 | 60.51 | 1.58 | 61.21 | 1508 |
| 36 | 1.41 | 126.32 | 3.02 | 75.10 | 1477 | 100 | 1.71 | 53.58 | 1.40 | 58.28 | 1539 |
| 38 | 1.43 | 117.70 | 3.29 | 76.71 | 1476 | 102 | 1.67 | 58.69 | 1.53 | 60.48 | 1532 |
| 40 | 1.47 | 102.30 | 3.07 | 75.42 | 1475 | 104 | 1.65 | 61.72 | 1.61 | 61.67 | |
| 42 | 1.54 | 83.04 | 2.67 | 72.73 | 1475 | 106 | 1.65 | 61.80 | 1.61 | 61.71 | |
| 44 | 1.54 | 83.30 | 2.17 | 68.41 | 1481 | 108 | 1.62 | 67.06 | 1.75 | 63.62 | 1489 |
| 46 | 1.57 | 77.53 | 2.17 | 68.47 | 1481 | 110 | 1.68 | 57.77 | 1.51 | 60.10 | 1495 |
| 48 | 1.61 | 70.19 | 2.02 | 66.90 | 1483 | 112 | 1.67 | 59.95 | 1.56 | 60.99 | 1502 |
| 50 | 1.65 | 62.95 | 1.83 | 64.67 | 1491 | 114 | 1.59 | 72.71 | 1.90 | 65.47 | 1486 |
| 52 | 1.62 | 66.83 | 1.64 | 62.14 | 1493 | 116 | 1.66 | 60.29 | 1.57 | 61.12 | 1496 |
| 54 | 1.60 | 70.75 | 1.74 | 63.54 | 1493 | 118 | 1.75 | 48.86 | 1.27 | 56.02 | 1496 |
| 56 | 1.57 | 77.49 | 1.84 | 64.85 | 1487 | 120 | 1.61 | 68.97 | 1.80 | 64.26 | 1483 |
| 58 | 1.55 | 82.04 | 2.02 | 66.89 | 1479 | 122 | 1.59 | 72.84 | 1.90 | 65.51 | 1482 |
| 60 | 1.58 | 75.95 | 2.14 | 68.14 | 1476 | 124 | 1.61 | 69.27 | 1.81 | 64.36 | 1483 |
| 62 | 1.66 | 60.78 | 1.98 | 66.45 | 1483 | 126 | 1.61 | 68.54 | 1.79 | 64.12 | 1484 |
| | | | 1.58 | 61.31 | 1496 | 128 | 1.63 | 65.58 | 1.71 | 63.10 | 1485 |

HM 54

HM 54

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 130 | 1.63 | 66.58 | 1.74 | 63.45 | 1485 | 196 | 1.87 | 35.93 | 0.94 | 48.37 | 1608 |
| 132 | | | | | 1538 | 198 | 1.92 | 31.84 | 0.83 | 45.36 | 1623 |
| 134 | 1.64 | 64.36 | 1.68 | 62.66 | 1493 | 200 | | | | | |
| 136 | 1.72 | 52.26 | 1.36 | 57.68 | 1511 | 202 | | | | | |
| 138 | 1.68 | 57.17 | 1.49 | 59.85 | 1499 | 204 | | | | | |
| 140 | 1.61 | 69.60 | 1.81 | 64.47 | 1485 | 206 | 1.94 | 30.82 | 0.80 | 44.55 | 1528 |
| 142 | 1.66 | 60.40 | 1.57 | 61.16 | 1494 | 208 | 1.98 | 27.76 | 0.72 | 41.99 | 1527 |
| 144 | 1.71 | 53.79 | 1.40 | 58.38 | 1504 | 210 | 1.92 | 32.01 | 0.83 | 45.49 | 1573 |
| 146 | 1.79 | 43.69 | 1.14 | 53.25 | 1525 | 212 | 1.95 | 30.00 | 0.78 | 43.89 | 1571 |
| 148 | 1.83 | 40.37 | 1.05 | 51.28 | 1530 | 214 | 1.93 | 30.99 | 0.81 | 44.69 | 1569 |
| 150 | 1.80 | 42.55 | 1.11 | 52.59 | 1528 | 216 | 1.94 | 30.43 | 0.79 | 44.24 | 1569 |
| 152 | 1.91 | 33.23 | 0.87 | 46.42 | 1566 | 218 | 1.95 | 29.53 | 0.77 | 43.50 | 1569 |
| 154 | 1.90 | 33.56 | 0.88 | 46.67 | 1563 | 220 | 1.93 | 31.71 | 0.83 | 45.26 | 1570 |
| 156 | 1.89 | 34.42 | 0.90 | 47.30 | 1563 | 222 | 1.91 | 32.52 | 0.85 | 45.89 | 1571 |
| 158 | 1.89 | 34.18 | 0.89 | 47.12 | 1562 | 224 | 1.89 | 34.28 | 0.89 | 47.19 | 1567 |
| 160 | 1.94 | 30.93 | 0.81 | 44.65 | 1561 | 226 | 1.91 | 32.92 | 0.86 | 46.19 | 1523 |
| 162 | 1.88 | 35.59 | 0.93 | 48.13 | 1567 | 228 | 1.91 | 33.05 | 0.86 | 46.29 | 1570 |
| 164 | 1.90 | 33.89 | 0.88 | 46.91 | 1563 | 230 | 1.92 | 31.98 | 0.83 | 45.47 | 1571 |
| 166 | 1.89 | 34.67 | 0.90 | 47.48 | 1561 | 232 | 1.92 | 32.34 | 0.84 | 45.75 | 1570 |
| 168 | 1.91 | 33.27 | 0.87 | 46.45 | 1565 | 234 | 1.90 | 33.54 | 0.87 | 46.65 | 1568 |
| 170 | 1.93 | 31.56 | 0.82 | 45.15 | 1564 | 236 | 1.93 | 31.28 | 0.82 | 44.92 | 1573 |
| 172 | 1.90 | 33.77 | 0.88 | 46.83 | 1564 | 238 | 1.94 | 30.89 | 0.81 | 44.61 | 1573 |
| 174 | 1.91 | 32.99 | 0.86 | 46.24 | 1563 | 240 | 1.92 | 31.96 | 0.83 | 45.45 | 1552 |
| 176 | 1.90 | 33.51 | 0.87 | 46.63 | 1564 | 242 | 1.97 | 28.37 | 0.74 | 42.52 | 1571 |
| 178 | 1.94 | 30.89 | 0.81 | 44.61 | 1565 | 244 | 1.94 | 30.44 | 0.79 | 44.25 | 1518 |
| 180 | 1.90 | 34.07 | 0.89 | 47.04 | 1565 | 246 | 1.95 | 29.96 | 0.78 | 43.86 | 1521 |
| 182 | 1.91 | 32.72 | 0.85 | 46.04 | 1567 | 248 | 2.01 | 25.92 | 0.68 | 40.33 | 1543 |
| 184 | 1.91 | 32.56 | 0.85 | 45.91 | 1568 | 250 | 2.03 | 24.70 | 0.64 | 39.17 | 1557 |
| 186 | 1.95 | 29.57 | 0.77 | 43.54 | 1560 | 252 | 2.03 | 24.35 | 0.63 | 38.84 | 1562 |
| 188 | 1.91 | 33.04 | 0.86 | 46.28 | 1570 | 254 | 1.93 | 31.42 | 0.82 | 45.03 | |
| 190 | 1.91 | 33.07 | 0.86 | 46.30 | 1571 | 256 | 1.94 | 30.30 | 0.79 | 44.13 | 1573 |
| 192 | 1.91 | 33.12 | 0.86 | 46.34 | 1571 | | | | | | |
| 194 | 1.87 | 36.31 | 0.95 | 48.63 | | | | | | | |

Hm 56

Hm 56

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.68 | 58.48 | 1.52 | 60.39 | 1486 |
| 2 | | | | | | 62 | 1.77 | 46.59 | 1.21 | 54.85 | 1507 |
| 4 | 1.77 | 46.82 | 1.22 | 54.97 | | 64 | 1.72 | 51.80 | 1.35 | 57.46 | 1498 |
| 6 | 1.77 | 45.74 | 1.19 | 54.39 | | 66 | 1.68 | 57.56 | 1.50 | 60.01 | 1486 |
| 8 | 1.71 | 53.51 | 1.40 | 58.25 | 1512 | 68 | 1.72 | 52.50 | 1.37 | 57.78 | 1490 |
| 10 | 1.67 | 59.63 | 1.55 | 60.86 | 1446 | 70 | 1.72 | 52.08 | 1.36 | 57.59 | 1491 |
| 12 | 1.65 | 62.96 | 1.64 | 62.15 | | 72 | 1.66 | 60.70 | 1.58 | 61.28 | 1482 |
| 14 | 1.64 | 63.78 | 1.66 | 62.45 | 1594 | 74 | 1.67 | 59.78 | 1.56 | 60.92 | 1483 |
| 16 | 1.64 | 64.42 | 1.68 | 62.68 | 1494 | 76 | 1.67 | 59.65 | 1.56 | 60.87 | 1485 |
| 18 | 1.62 | 68.05 | 1.77 | 63.96 | 1493 | 78 | 1.69 | 56.39 | 1.47 | 59.52 | 1487 |
| 20 | 1.71 | 54.26 | 1.41 | 58.59 | 1503 | 80 | 1.69 | 56.86 | 1.48 | 59.72 | 1488 |
| 22 | 1.85 | 38.23 | 1.00 | 49.92 | 1551 | 82 | 1.70 | 55.44 | 1.45 | 59.11 | 1489 |
| 24 | 1.65 | 61.93 | 1.61 | 61.76 | 1486 | 84 | 1.71 | 54.04 | 1.41 | 58.49 | 1489 |
| 26 | 1.69 | 57.09 | 1.49 | 59.82 | 1490 | 86 | 1.75 | 48.14 | 1.26 | 55.66 | 1495 |
| 28 | 1.67 | 59.32 | 1.55 | 60.74 | 1488 | 88 | 1.76 | 47.86 | 1.25 | 55.52 | 1502 |
| 30 | 1.74 | 49.66 | 1.29 | 56.42 | 1503 | 90 | 1.82 | 40.96 | 1.07 | 51.64 | 1519 |
| 32 | 1.73 | 50.86 | 1.33 | 57.01 | 1499 | 92 | 1.75 | 49.12 | 1.28 | 56.15 | 1504 |
| 34 | 1.73 | 51.17 | 1.33 | 57.16 | 1500 | 94 | 1.69 | 56.38 | 1.47 | 59.52 | 1489 |
| 36 | 1.75 | 48.11 | 1.25 | 55.64 | 1494 | 96 | | | | | |
| 38 | 1.71 | 53.58 | 1.40 | 58.28 | 1488 | 98 | | | | | |
| 40 | 1.67 | 59.50 | 1.55 | 60.81 | 1485 | 100 | | | | | |
| 42 | 1.68 | 58.10 | 1.51 | 60.24 | 1486 | 102 | | | | | |
| 44 | 1.68 | 57.42 | 1.50 | 59.96 | 1484 | 104 | 1.56 | 79.76 | 2.08 | 67.53 | |
| 46 | 1.68 | 58.40 | 1.52 | 60.36 | 1484 | 106 | 1.62 | 67.08 | 1.75 | 63.62 | |
| 48 | 1.68 | 58.44 | 1.52 | 60.38 | 1482 | 108 | 1.65 | 62.10 | 1.62 | 61.82 | 1497 |
| 50 | 1.67 | 58.63 | 1.53 | 60.45 | 1484 | 110 | 1.63 | 66.46 | 1.73 | 63.41 | 1495 |
| 52 | 1.70 | 54.91 | 1.43 | 58.88 | 1487 | 112 | 1.74 | 49.81 | 1.30 | 56.50 | 1504 |
| 54 | 1.77 | 46.04 | 1.20 | 54.55 | 1504 | 114 | 1.59 | 72.72 | 1.90 | 65.47 | 1482 |
| 56 | 1.76 | 47.30 | 1.23 | 55.22 | 1507 | 116 | 1.59 | 72.32 | 1.89 | 65.35 | 1484 |
| 58 | 1.74 | 49.54 | 1.29 | 56.36 | 1501 | 118 | 1.65 | 63.28 | 1.65 | 62.26 | 1493 |
| | | | | | | 120 | 1.65 | 62.22 | 1.62 | 61.87 | 1491 |

Hm 56

Hm 56

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 122 | 1.64 | 64.27 | 1.68 | 62.63 | 1493 | 184 | 1.63 | 65.18 | 1.70 | 62.95 | 1495 |
| 124 | 1.61 | 70.29 | 1.83 | 64.70 | 1486 | 186 | 1.65 | 62.53 | 1.63 | 61.98 | 1501 |
| 126 | 1.67 | 59.28 | 1.55 | 60.72 | 1495 | 188 | 1.70 | 54.82 | 1.43 | 58.84 | 1510 |
| 128 | 1.61 | 68.48 | 1.79 | 64.10 | 1488 | 190 | 1.69 | 56.23 | 1.47 | 59.45 | 1513 |
| 130 | 1.60 | 70.48 | 1.84 | 64.76 | 1485 | 192 | 1.71 | 54.19 | 1.41 | 58.56 | 1516 |
| 132 | 1.68 | 57.87 | 1.51 | 60.14 | 1496 | 194 | 1.63 | 65.26 | 1.70 | 62.99 | |
| 134 | 1.67 | 60.09 | 1.57 | 61.04 | 1495 | 196 | 1.69 | 56.78 | 1.48 | 59.68 | 1456 |
| 136 | 1.74 | 49.26 | 1.28 | 56.23 | 1509 | 198 | 1.69 | 57.02 | 1.49 | 59.79 | |
| 138 | 1.66 | 60.80 | 1.59 | 61.32 | 1501 | 200 | | | | | |
| 140 | 1.66 | 61.00 | 1.59 | 61.40 | 1493 | 202 | 1.86 | 37.34 | 0.97 | 49.33 | |
| 142 | 1.64 | 63.41 | 1.65 | 62.31 | 1491 | 204 | 1.87 | 36.47 | 0.95 | 48.74 | |
| 144 | 1.64 | 63.38 | 1.65 | 62.30 | 1490 | 206 | 1.74 | 49.76 | 1.30 | 56.47 | |
| 146 | 1.66 | 60.86 | 1.59 | 61.34 | 1495 | 208 | 1.70 | 54.46 | 1.42 | 58.68 | |
| 148 | 1.66 | 60.94 | 1.59 | 61.37 | 1494 | 210 | 1.72 | 52.56 | 1.37 | 57.81 | |
| 150 | 1.67 | 59.06 | 1.54 | 60.63 | 1499 | 212 | 1.73 | 50.71 | 1.32 | 56.94 | |
| 152 | 1.69 | 55.81 | 1.46 | 59.27 | 1499 | 214 | 1.76 | 47.07 | 1.23 | 55.10 | |
| 154 | 1.70 | 54.58 | 1.42 | 58.73 | 1501 | 216 | 1.76 | 47.31 | 1.23 | 55.23 | |
| 156 | 1.67 | 59.28 | 1.55 | 60.72 | 1500 | 218 | 1.75 | 48.99 | 1.28 | 56.09 | |
| 158 | 1.67 | 59.97 | 1.56 | 60.99 | 1499 | 220 | 1.85 | 37.89 | 0.99 | 49.69 | 1509 |
| 160 | 1.65 | 62.36 | 1.63 | 61.92 | 1489 | 222 | 1.84 | 39.05 | 1.02 | 50.45 | 1509 |
| 162 | 1.67 | 59.63 | 1.55 | 60.86 | 1494 | 224 | 1.82 | 41.17 | 1.07 | 51.77 | 1508 |
| 164 | 1.70 | 54.57 | 1.42 | 58.73 | 1504 | 226 | 1.79 | 43.95 | 1.15 | 53.40 | 1474 |
| 166 | 1.70 | 54.87 | 1.43 | 58.86 | 1506 | 228 | 1.75 | 48.26 | 1.26 | 55.72 | 1473 |
| 168 | 1.68 | 57.93 | 1.51 | 60.17 | 1501 | 230 | 1.75 | 48.66 | 1.27 | 55.93 | 1486 |
| 170 | 1.65 | 63.20 | 1.65 | 62.23 | 1493 | 232 | 1.81 | 42.39 | 1.11 | 52.50 | 1507 |
| 172 | 1.67 | 59.78 | 1.56 | 60.92 | 1497 | 234 | 1.82 | 40.79 | 1.06 | 51.54 | 1500 |
| 174 | 1.73 | 51.03 | 1.33 | 57.09 | 1500 | 236 | 1.81 | 41.89 | 1.09 | 52.20 | 1500 |
| 176 | 1.67 | 59.33 | 1.55 | 60.74 | 1504 | 238 | 1.79 | 43.85 | 1.14 | 53.34 | 1500 |
| 178 | 1.66 | 60.19 | 1.57 | 61.08 | 1500 | 240 | 1.75 | 48.30 | 1.26 | 55.74 | 1483 |
| 180 | 1.63 | 65.55 | 1.71 | 63.09 | 1497 | 242 | 1.71 | 53.61 | 1.40 | 58.30 | 1472 |
| 182 | 1.64 | 63.32 | 1.65 | 62.28 | 1495 | 244 | 1.71 | 54.14 | 1.41 | 58.53 | 1482 |

Hm 56

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.72 | 52.39 | 1.37 | 57.74 | 1483 |
| 248 | 1.79 | 44.59 | 1.16 | 53.76 | 1500 |
| 250 | 1.81 | 41.80 | 1.09 | 52.15 | 1510 |
| 252 | 1.81 | 41.52 | 1.08 | 51.98 | 1507 |
| 254 | 1.83 | 40.09 | 1.05 | 51.10 | 1511 |
| 256 | 1.79 | 44.36 | 1.16 | 53.63 | 1510 |
| 258 | 1.80 | 43.17 | 1.13 | 52.96 | 1510 |
| 260 | 1.84 | 39.26 | 1.02 | 50.59 | 1516 |
| 262 | 1.79 | 44.22 | 1.15 | 53.55 | 1508 |
| 264 | 1.82 | 41.39 | 1.08 | 51.90 | 1511 |
| 266 | 1.80 | 43.34 | 1.13 | 53.05 | 1507 |
| 268 | 1.77 | 45.74 | 1.19 | 54.39 | 1501 |
| 270 | 1.75 | 48.31 | 1.26 | 55.74 | 1498 |
| 272 | 1.72 | 51.88 | 1.35 | 57.50 | 1489 |
| 274 | 1.76 | 47.52 | 1.24 | 55.34 | 1498 |
| 276 | 1.75 | 48.08 | 1.25 | 55.63 | 1501 |
| 278 | 1.82 | 40.79 | 1.06 | 51.54 | 1527 |
| 280 | 1.80 | 42.97 | 1.12 | 52.84 | 1511 |
| 282 | 1.78 | 44.86 | 1.17 | 53.91 | 1505 |
| 284 | 1.86 | 37.28 | 0.97 | 49.29 | |

HM 58

HM 58

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|----------------------|--|----------------------|------------|-----------------|-------------|----------------------|--|----------------------|------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.54 | 83.30 | 2.17 | 68.47 | 1486 |
| 2 | | | | | | 62 | 1.60 | 70.98 | 1.85 | 64.92 | 1490 |
| 4 | | | | | | 64 | 1.58 | 75.86 | 1.98 | 66.42 | 1486 |
| 6 | | | | | | 66 | 1.57 | 76.87 | 2.00 | 66.72 | 1484 |
| 8 | | | | | | 68 | 1.53 | 85.83 | 2.24 | 69.12 | 1478 |
| 10 | | | | | | 70 | 1.56 | 78.39 | 2.04 | 67.15 | 1479 |
| 12 | | | | | | 72 | 1.55 | 82.43 | 2.15 | 68.25 | 1478 |
| 14 | | | | | | 74 | 1.57 | 77.50 | 2.02 | 66.89 | 1486 |
| 16 | | | | | | 76 | 1.62 | 66.93 | 1.75 | 63.57 | 1495 |
| 18 | 1.52 | 87.85 | 2.29 | 69.61 | 1506 | 78 | 1.62 | 67.95 | 1.77 | 63.92 | 1497 |
| 20 | 1.52 | 88.73 | 2.31 | 69.82 | 1496 | 80 | 1.64 | 64.15 | 1.67 | 62.58 | 1502 |
| 22 | 1.51 | 91.50 | 2.39 | 70.46 | 1489 | 82 | 1.68 | 58.17 | 1.52 | 60.27 | 1506 |
| 24 | 1.49 | 95.75 | 2.50 | 71.40 | 1488 | 84 | 1.72 | 51.95 | 1.35 | 57.53 | 1515 |
| 26 | 1.56 | 78.67 | 2.05 | 67.23 | 1490 | 86 | 1.74 | 50.21 | 1.31 | 56.70 | 1519 |
| 28 | 1.55 | 81.79 | 2.13 | 68.08 | 1488 | 88 | 1.75 | 48.33 | 1.26 | 55.76 | 1526 |
| 30 | 1.53 | 85.79 | 2.24 | 69.11 | 1487 | 90 | 1.77 | 46.00 | 1.20 | 54.53 | 1526 |
| 32 | 1.58 | 75.21 | 1.96 | 66.23 | 1484 | 92 | 1.78 | 45.45 | 1.18 | 54.23 | 1528 |
| 34 | 1.57 | 76.32 | 1.99 | 66.56 | 1489 | 94 | 1.75 | 48.85 | 1.27 | 56.02 | 1532 |
| 36 | 1.58 | 74.58 | 1.94 | 66.04 | 1492 | 96 | 1.74 | 49.88 | 1.30 | 56.53 | |
| 38 | 1.56 | 78.56 | 2.05 | 67.20 | 1490 | 98 | 1.79 | 43.97 | 1.15 | 53.41 | |
| 40 | 1.56 | 79.83 | 2.08 | 67.55 | 1489 | 100 | | | | | |
| 42 | 1.55 | 81.04 | 2.11 | 67.88 | 1490 | 102 | | | | | |
| 44 | 1.54 | 84.60 | 2.21 | 68.81 | 1488 | 104 | | | | | |
| 46 | 1.52 | 89.56 | 2.34 | 70.02 | 1485 | 106 | | | | | |
| 48 | 1.55 | 82.77 | 2.16 | 68.34 | 1484 | 108 | 1.81 | 42.45 | 1.11 | 52.53 | 1529 |
| 50 | 1.53 | 85.38 | 2.23 | 69.00 | 1481 | 110 | 1.80 | 43.03 | 1.12 | 52.87 | 1538 |
| 52 | 1.53 | 86.49 | 2.26 | 69.28 | 1479 | 112 | 1.80 | 43.43 | 1.13 | 53.11 | 1539 |
| 54 | 1.50 | 94.45 | 2.46 | 71.12 | 1477 | 114 | 1.83 | 40.16 | 1.05 | 51.15 | 1535 |
| 56 | 1.51 | 92.59 | 2.41 | 70.71 | 1477 | 116 | 1.81 | 41.94 | 1.09 | 52.24 | 1535 |
| 58 | 1.53 | 87.23 | 2.27 | 69.46 | 1479 | 118 | 1.81 | 41.79 | 1.09 | 52.14 | 1535 |
| | | | | | | 120 | 1.80 | 43.04 | 1.12 | 52.88 | 1534 |

HM 58

HM 58

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.81 | 42.29 | 1.10 | 52.44 | 1535 | 184 | 1.78 | 44.61 | 1.16 | 53.77 | 1536 |
| 124 | 1.79 | 43.99 | 1.15 | 53.42 | 1532 | 186 | 1.82 | 41.29 | 1.08 | 51.84 | 1535 |
| 126 | 1.80 | 43.15 | 1.13 | 52.94 | 1533 | 188 | 1.80 | 42.51 | 1.11 | 52.57 | 1536 |
| 128 | 1.78 | 44.96 | 1.17 | 53.97 | 1533 | 190 | 1.81 | 42.15 | 1.10 | 52.36 | 1536 |
| 130 | 1.81 | 41.99 | 1.09 | 52.26 | 1532 | 192 | 1.79 | 44.11 | 1.15 | 53.49 | 1538 |
| 132 | 1.82 | 40.94 | 1.07 | 51.63 | 1530 | 194 | 1.80 | 43.07 | 1.12 | 52.90 | 1539 |
| 134 | 1.79 | 43.70 | 1.14 | 53.26 | 1530 | 196 | 1.81 | 42.28 | 1.10 | 52.43 | |
| 136 | 1.79 | 43.97 | 1.15 | 53.41 | 1531 | 198 | 1.74 | 50.02 | 1.30 | 56.60 | |
| 138 | 1.81 | 42.47 | 1.11 | 52.55 | 1531 | 200 | 1.77 | 46.07 | 1.20 | 54.57 | |
| 140 | 1.77 | 45.97 | 1.20 | 54.52 | 1531 | 202 | 1.79 | 43.87 | 1.14 | 53.36 | |
| 142 | 1.77 | 45.76 | 1.19 | 54.40 | 1529 | 204 | 1.74 | 49.65 | 1.29 | 56.42 | |
| 144 | 1.79 | 44.18 | 1.15 | 53.53 | 1530 | 206 | 1.79 | 44.37 | 1.16 | 53.64 | |
| 146 | 1.80 | 43.43 | 1.13 | 53.11 | 1530 | 208 | 1.85 | 37.99 | 0.99 | 49.76 | |
| 148 | 1.82 | 41.17 | 1.07 | 51.77 | 1532 | 210 | 1.83 | 40.13 | 1.05 | 51.13 | |
| 150 | 1.81 | 41.97 | 1.09 | 52.25 | 1530 | 212 | 1.86 | 37.36 | 0.97 | 49.34 | 1539 |
| 152 | 1.78 | 44.66 | 1.16 | 53.80 | 1530 | 214 | 1.86 | 36.77 | 0.96 | 48.95 | 1534 |
| 154 | 1.79 | 44.58 | 1.16 | 53.75 | 1530 | 216 | 1.81 | 41.75 | 1.09 | 52.12 | 1535 |
| 156 | 1.79 | 44.26 | 1.15 | 53.58 | 1532 | 218 | 1.84 | 39.25 | 1.02 | 50.58 | 1536 |
| 158 | 1.78 | 45.15 | 1.18 | 54.07 | 1532 | 220 | 1.82 | 40.63 | 1.06 | 51.44 | 1552 |
| 160 | 1.79 | 43.59 | 1.14 | 53.20 | 1533 | 222 | 1.81 | 41.73 | 1.09 | 52.11 | 1540 |
| 162 | 1.79 | 44.54 | 1.16 | 53.73 | 1533 | 224 | 1.80 | 43.10 | 1.12 | 52.92 | 1538 |
| 164 | 1.80 | 43.36 | 1.13 | 53.07 | 1533 | 226 | 1.86 | 37.39 | 0.97 | 49.36 | 1538 |
| 166 | 1.79 | 43.78 | 1.14 | 53.31 | 1533 | 228 | 1.83 | 39.78 | 1.04 | 50.91 | 1537 |
| 168 | 1.80 | 43.10 | 1.12 | 52.91 | 1532 | 230 | 1.83 | 40.40 | 1.05 | 51.30 | 1530 |
| 170 | 1.81 | 42.19 | 1.10 | 52.38 | 1533 | 232 | 1.83 | 40.31 | 1.05 | 51.24 | 1539 |
| 172 | 1.82 | 40.76 | 1.06 | 51.52 | 1535 | 234 | 1.82 | 40.61 | 1.06 | 51.43 | 1539 |
| 174 | 1.82 | 41.21 | 1.07 | 51.79 | 1537 | 236 | 1.81 | 41.99 | 1.09 | 52.26 | 1540 |
| 176 | 1.81 | 42.14 | 1.10 | 52.35 | 1536 | 238 | 1.82 | 41.17 | 1.07 | 51.77 | 1539 |
| 178 | 1.81 | 42.27 | 1.10 | 52.43 | 1537 | 240 | 1.81 | 41.66 | 1.09 | 52.07 | 1539 |
| 180 | 1.81 | 42.34 | 1.10 | 52.47 | 1536 | 242 | 1.83 | 40.15 | 1.05 | 51.14 | 1533 |
| 182 | 1.79 | 43.89 | 1.14 | 53.37 | 1535 | 244 | 1.84 | 39.36 | 1.03 | 50.65 | 1541 |

HM 58

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.82 | 41.11 | 1.07 | 51.73 | 1541 |
| 248 | 1.83 | 40.18 | 1.05 | 51.16 | 1544 |
| 250 | 1.83 | 39.78 | 1.04 | 50.91 | 1542 |
| 252 | 1.85 | 38.08 | 0.99 | 49.82 | 1541 |
| 254 | 1.83 | 39.68 | 1.03 | 50.85 | 1546 |
| 256 | 1.90 | 33.37 | 0.87 | 46.53 | 1567 |
| 258 | 1.82 | 41.07 | 1.07 | 51.71 | 1537 |
| 260 | 1.83 | 40.13 | 1.05 | 51.13 | |
| 262 | 1.82 | 40.54 | 1.06 | 51.39 | |
| 264 | 1.84 | 39.13 | 1.02 | 50.50 | 1551 |
| 266 | 1.84 | 39.26 | 1.02 | 50.58 | 1557 |
| 268 | 1.80 | 42.74 | 1.11 | 52.70 | |
| 270 | 1.78 | 44.89 | 1.17 | 53.93 | 1521 |
| 272 | 1.85 | 37.97 | 0.99 | 49.75 | 1580 |
| 274 | | | | | 1526 |

HM 59

HM 59

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.55 | 82.28 | 2.15 | 68.21 | 1482 |
| 2 | | | | | | 62 | 1.60 | 72.20 | 1.88 | 65.31 | 1488 |
| 4 | | | | | | 64 | 1.59 | 72.70 | 1.90 | 65.47 | 1487 |
| 6 | | | | | | 66 | 1.60 | 70.55 | 1.84 | 64.78 | 1487 |
| 8 | | | | | | 68 | 1.56 | 78.58 | 2.05 | 67.20 | 1485 |
| 10 | | | | | | 70 | 1.56 | 79.55 | 2.07 | 67.47 | 1485 |
| 12 | | | | | | 72 | 1.54 | 83.85 | 2.19 | 68.62 | 1480 |
| 14 | | | | | | 74 | 1.60 | 70.99 | 1.85 | 64.92 | 1488 |
| 16 | 1.57 | 77.86 | 2.03 | 67.00 | 1512 | 76 | 1.55 | 81.29 | 2.12 | 67.95 | 1477 |
| 18 | 1.57 | 77.54 | 2.02 | 66.91 | 1503 | 78 | 1.51 | 90.27 | 2.35 | 70.18 | 1475 |
| 20 | 1.56 | 79.50 | 2.07 | 67.46 | 1497 | 80 | 1.54 | 83.86 | 2.19 | 68.62 | 1477 |
| 22 | 1.64 | 64.17 | 1.67 | 62.59 | 1491 | 82 | 1.55 | 81.91 | 2.14 | 68.11 | 1478 |
| 24 | 1.64 | 63.79 | 1.66 | 62.45 | 1493 | 84 | 1.55 | 80.69 | 2.10 | 67.78 | 1477 |
| 26 | 1.67 | 58.82 | 1.53 | 60.53 | 1491 | 86 | 1.53 | 85.35 | 2.23 | 69.00 | 1478 |
| 28 | 1.57 | 77.44 | 2.02 | 66.88 | 1484 | 88 | 1.53 | 85.95 | 2.24 | 69.15 | 1478 |
| 30 | 1.65 | 62.35 | 1.63 | 61.92 | 1490 | 90 | 1.62 | 66.97 | 1.75 | 63.59 | 1495 |
| 32 | 1.61 | 68.86 | 1.80 | 64.23 | 1485 | 92 | 1.66 | 60.18 | 1.57 | 61.08 | 1509 |
| 34 | 1.59 | 72.30 | 1.89 | 65.34 | 1483 | 94 | 1.69 | 55.73 | 1.45 | 59.24 | |
| 36 | 1.59 | 74.03 | 1.93 | 65.87 | 1483 | 96 | | | | | |
| 38 | 1.57 | 76.90 | 2.01 | 66.72 | 1483 | 98 | | | | | 1527 |
| 40 | 1.56 | 80.46 | 2.10 | 67.72 | 1480 | 100 | | | | | |
| 42 | 1.54 | 84.07 | 2.19 | 68.67 | 1478 | 102 | | | | | |
| 44 | 1.50 | 95.55 | 2.49 | 71.36 | 1473 | 104 | | | | | |
| 46 | 1.49 | 96.94 | 2.53 | 71.65 | 1474 | 106 | | | | | |
| 48 | 1.51 | 92.02 | 2.40 | 70.58 | 1473 | 108 | 1.71 | 53.05 | 1.38 | 58.04 | |
| 50 | 1.46 | 106.65 | 2.78 | 73.55 | 1474 | 110 | 1.77 | 46.78 | 1.22 | 54.95 | 1521 |
| 52 | 1.50 | 94.46 | 2.46 | 71.12 | 1475 | 112 | 1.84 | 38.77 | 1.01 | 50.27 | 1534 |
| 54 | 1.51 | 90.52 | 2.36 | 70.24 | 1474 | 114 | 1.84 | 38.87 | 1.01 | 50.33 | 1539 |
| 56 | 1.49 | 96.09 | 2.51 | 71.47 | 1476 | 116 | 1.83 | 39.66 | 1.03 | 50.84 | 1540 |
| 58 | 1.58 | 75.76 | 1.98 | 66.39 | 1483 | 118 | 1.86 | 37.31 | 0.97 | 49.31 | 1540 |
| | | | | | | 120 | 1.87 | 36.33 | 0.95 | 48.65 | 1541 |

HM 59

HM 59

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 122 | 1.93 | 31.36 | 0.82 | 44.99 | 1532 | 184 | 1.87 | 36.58 | 0.95 | 48.82 | 1551 |
| 124 | 1.85 | 37.71 | 0.98 | 49.58 | 1544 | 186 | 1.88 | 35.43 | 0.92 | 48.02 | 1552 |
| 126 | 1.91 | 33.22 | 0.87 | 46.41 | 1535 | 188 | 1.98 | 27.40 | 0.71 | 41.67 | 1545 |
| 128 | 1.85 | 37.95 | 0.99 | 49.74 | 1546 | 190 | 1.88 | 35.77 | 0.93 | 48.26 | 1554 |
| 130 | 1.85 | 37.67 | 0.98 | 49.55 | 1543 | 192 | 1.88 | 35.47 | 0.92 | 48.05 | 1557 |
| 132 | 1.88 | 35.66 | 0.93 | 48.18 | 1543 | 194 | 1.85 | 37.74 | 0.98 | 49.60 | 1558 |
| 134 | 1.85 | 37.89 | 0.99 | 49.70 | 1541 | 196 | 1.82 | 40.93 | 1.07 | 51.63 | |
| 136 | 1.83 | 39.59 | 1.03 | 50.79 | 1544 | 198 | 1.81 | 41.79 | 1.09 | 52.14 | 1569 |
| 138 | 1.84 | 39.05 | 1.02 | 50.45 | 1544 | 200 | 1.88 | 35.12 | 0.92 | 47.80 | |
| 140 | 1.85 | 38.20 | 1.00 | 49.90 | 1545 | 202 | | | | | |
| 142 | 1.84 | 38.60 | 1.01 | 50.16 | 1545 | 204 | 1.84 | 38.58 | 1.01 | 50.15 | |
| 144 | 1.86 | 37.38 | 0.97 | 49.36 | 1544 | 206 | 1.81 | 42.37 | 1.10 | 52.49 | |
| 146 | 1.84 | 38.61 | 1.01 | 50.16 | 1546 | 208 | 1.88 | 35.37 | 0.92 | 47.98 | |
| 148 | 1.88 | 35.71 | 0.93 | 48.22 | 1545 | 210 | 1.90 | 33.73 | 0.88 | 46.80 | 1568 |
| 150 | 1.87 | 36.32 | 0.95 | 48.64 | 1545 | 212 | 1.92 | 32.14 | 0.84 | 45.59 | 1566 |
| 152 | 1.87 | 36.52 | 0.95 | 48.77 | 1546 | 214 | 1.91 | 32.57 | 0.85 | 45.92 | 1565 |
| 154 | 1.86 | 37.56 | 0.98 | 49.48 | 1546 | 216 | 1.92 | 32.44 | 0.85 | 45.82 | 1564 |
| 156 | 1.86 | 37.26 | 0.97 | 49.28 | 1547 | 218 | 1.90 | 34.03 | 0.89 | 47.02 | 1561 |
| 158 | 1.87 | 35.99 | 0.94 | 48.41 | 1549 | 220 | 1.90 | 33.62 | 0.88 | 46.71 | 1556 |
| 160 | 1.87 | 36.62 | 0.95 | 48.84 | 1550 | 222 | 1.90 | 33.37 | 0.87 | 46.52 | 1561 |
| 162 | 1.86 | 37.17 | 0.97 | 49.22 | 1549 | 224 | 1.91 | 33.28 | 0.87 | 46.46 | 1559 |
| 164 | 1.88 | 35.06 | 0.91 | 47.76 | 1548 | 226 | 1.88 | 35.23 | 0.92 | 47.88 | 1559 |
| 166 | 1.86 | 37.53 | 0.98 | 49.46 | 1550 | 228 | 1.91 | 32.96 | 0.86 | 46.22 | 1555 |
| 168 | 1.89 | 34.64 | 0.90 | 47.46 | 1548 | 230 | 1.90 | 34.12 | 0.89 | 47.08 | 1560 |
| 170 | 1.85 | 37.79 | 0.99 | 49.63 | 1549 | 232 | 1.90 | 33.46 | 0.87 | 46.59 | 1558 |
| 172 | 1.88 | 35.15 | 0.92 | 47.82 | 1550 | 234 | 1.89 | 34.44 | 0.90 | 47.31 | 1559 |
| 174 | 1.87 | 36.16 | 0.94 | 48.53 | 1548 | 236 | 1.92 | 32.07 | 0.84 | 45.54 | 1558 |
| 176 | 1.90 | 33.82 | 0.88 | 46.86 | 1547 | 238 | 1.91 | 33.19 | 0.87 | 46.39 | 1562 |
| 178 | 1.87 | 36.04 | 0.94 | 48.44 | 1551 | 240 | 1.88 | 35.18 | 0.92 | 47.84 | 1559 |
| 180 | 1.88 | 35.71 | 0.93 | 48.21 | 1554 | 242 | 1.88 | 35.23 | 0.92 | 47.88 | 1560 |
| 182 | 1.85 | 38.39 | 1.00 | 50.02 | 1552 | 244 | 1.88 | 35.20 | 0.92 | 47.86 | 1558 |

HM 59

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.88 | 35.26 | 0.92 | 47.90 | 1557 |
| 248 | 1.91 | 32.86 | 0.86 | 46.14 | 1559 |
| 250 | 1.89 | 34.76 | 0.91 | 47.55 | 1561 |
| 252 | 1.92 | 31.80 | 0.83 | 45.33 | 1559 |
| 254 | 1.89 | 34.48 | 0.90 | 47.34 | 1564 |
| 256 | | | | | 1554 |
| 258 | 1.88 | 35.32 | 0.92 | 47.95 | 1559 |
| 260 | 1.92 | 32.32 | 0.84 | 45.73 | 1563 |
| 262 | 1.88 | 35.02 | 0.91 | 47.73 | 1561 |
| 264 | 1.91 | 33.14 | 0.86 | 46.36 | 1560 |
| 266 | 1.88 | 35.24 | 0.92 | 47.89 | 1563 |
| 268 | 1.89 | 34.28 | 0.89 | 47.19 | 1564 |
| 270 | 1.90 | 33.47 | 0.87 | 46.60 | 1566 |
| 272 | 1.90 | 33.57 | 0.88 | 46.67 | 1565 |
| 274 | 1.89 | 34.79 | 0.91 | 47.56 | 1563 |
| 276 | 1.95 | 29.93 | 0.78 | 43.84 | 1565 |
| 278 | 1.87 | 36.44 | 0.95 | 48.72 | 1564 |
| 280 | 1.91 | 32.84 | 0.86 | 46.13 | 1564 |
| 282 | 1.91 | 33.04 | 0.86 | 46.28 | 1573 |
| 284 | 1.88 | 35.63 | 0.93 | 48.16 | |
| 286 | 1.85 | 38.38 | 1.00 | 50.02 | |
| 288 | 1.90 | 33.65 | 0.88 | 46.74 | |

HM 60

HM 60

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.62 | 67.98 | 1.77 | 63.93 | 1498 |
| 2 | | | | | | 62 | 1.59 | 73.29 | 1.91 | 65.65 | 1496 |
| 4 | | | | | | 64 | 1.58 | 75.48 | 1.97 | 66.31 | 1496 |
| 6 | 1.48 | 99.20 | 2.59 | 72.12 | | 66 | 1.60 | 70.42 | 1.84 | 64.74 | 1495 |
| 8 | 1.63 | 65.54 | 1.71 | 63.09 | 1499 | 68 | 1.61 | 69.75 | 1.82 | 64.52 | 1496 |
| 10 | 1.59 | 74.07 | 1.93 | 65.89 | 1495 | 70 | 1.62 | 67.02 | 1.75 | 63.60 | 1495 |
| 12 | 1.63 | 65.32 | 1.70 | 63.01 | 1499 | 72 | 1.62 | 67.18 | 1.75 | 63.66 | 1495 |
| 14 | 1.67 | 59.31 | 1.55 | 60.73 | 1502 | 74 | 1.64 | 64.73 | 1.69 | 62.80 | 1497 |
| 16 | 1.65 | 63.25 | 1.65 | 62.25 | 1499 | 76 | 1.64 | 63.98 | 1.67 | 62.52 | 1498 |
| 18 | 1.61 | 69.52 | 1.81 | 64.45 | 1503 | 78 | 1.65 | 62.31 | 1.62 | 61.90 | 1498 |
| 20 | 1.61 | 69.48 | 1.81 | 64.43 | 1503 | 80 | 1.65 | 62.28 | 1.62 | 61.89 | 1497 |
| 22 | 1.62 | 67.73 | 1.77 | 63.85 | 1501 | 82 | 1.61 | 68.64 | 1.79 | 64.15 | 1495 |
| 24 | 1.60 | 71.37 | 1.86 | 65.05 | 1500 | 84 | 1.60 | 70.37 | 1.83 | 64.72 | 1496 |
| 26 | 1.59 | 72.21 | 1.88 | 65.31 | 1494 | 86 | 1.62 | 67.97 | 1.77 | 63.93 | 1494 |
| 28 | 1.60 | 71.77 | 1.87 | 65.17 | 1497 | 88 | 1.58 | 74.36 | 1.94 | 65.97 | 1491 |
| 30 | 1.61 | 69.57 | 1.81 | 64.46 | 1499 | 90 | 1.59 | 73.07 | 1.91 | 65.58 | 1491 |
| 32 | 1.61 | 68.84 | 1.79 | 64.22 | 1498 | 92 | 1.62 | 68.40 | 1.78 | 64.07 | 1493 |
| 34 | 1.60 | 71.75 | 1.87 | 65.17 | 1495 | 94 | 1.56 | 80.20 | 2.09 | 67.65 | |
| 36 | 1.59 | 72.21 | 1.88 | 65.31 | 1495 | 96 | 1.58 | 74.27 | 1.94 | 65.95 | |
| 38 | 1.54 | 84.00 | 2.19 | 68.65 | 1490 | 98 | 1.66 | 61.04 | 1.59 | 61.41 | |
| 40 | 1.60 | 70.92 | 1.85 | 64.90 | 1494 | 100 | | | | | |
| 42 | 1.61 | 70.15 | 1.83 | 64.65 | 1493 | 102 | | | | | |
| 44 | 1.59 | 74.02 | 1.93 | 65.87 | 1494 | 104 | 1.58 | 75.71 | 1.97 | 66.38 | |
| 46 | 1.58 | 75.59 | 1.97 | 66.34 | 1491 | 106 | 1.53 | 85.48 | 2.23 | 69.03 | |
| 48 | 1.60 | 70.49 | 1.84 | 64.77 | 1496 | 108 | 1.60 | 71.27 | 1.86 | 65.02 | 1495 |
| 50 | 1.60 | 70.60 | 1.84 | 64.80 | 1497 | 110 | 1.64 | 64.84 | 1.69 | 62.83 | 1499 |
| 52 | 1.61 | 69.25 | 1.81 | 64.36 | 1502 | 112 | 1.62 | 68.07 | 1.77 | 63.96 | 1495 |
| 54 | 1.61 | 70.22 | 1.83 | 64.68 | 1501 | 114 | 1.60 | 71.22 | 1.86 | 65.00 | 1491 |
| 56 | 1.63 | 65.34 | 1.70 | 63.01 | 1500 | 116 | 1.58 | 75.97 | 1.98 | 66.45 | 1490 |
| 58 | 1.60 | 70.62 | 1.84 | 64.81 | 1497 | 118 | 1.60 | 71.86 | 1.87 | 65.20 | 1493 |
| | | | | | | 120 | 1.60 | 70.40 | 1.84 | 64.73 | 1496 |

HM 60

HM 60

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.61 | 68.69 | 1.79 | 64.17 | 1498 | 184 | 1.73 | 51.21 | 1.34 | 57.18 | 1514 |
| 124 | 1.65 | 62.84 | 1.64 | 62.10 | 1501 | 186 | 1.70 | 55.71 | 1.45 | 59.23 | 1515 |
| 126 | 1.69 | 56.39 | 1.47 | 59.52 | 1506 | 188 | 1.74 | 49.97 | 1.30 | 56.58 | 1522 |
| 128 | 1.78 | 45.37 | 1.18 | 54.19 | 1510 | 190 | 1.83 | 40.41 | 1.05 | 51.31 | 1542 |
| 130 | 1.72 | 52.27 | 1.36 | 57.68 | 1511 | 192 | 1.83 | 40.13 | 1.05 | 51.13 | 1540 |
| 132 | 1.70 | 54.47 | 1.42 | 58.68 | 1506 | 194 | 1.85 | 38.22 | 1.00 | 49.91 | 1542 |
| 134 | 1.69 | 56.85 | 1.48 | 59.72 | 1502 | 196 | 1.77 | 45.89 | 1.20 | 54.48 | |
| 136 | 1.71 | 53.91 | 1.41 | 58.43 | 1503 | 198 | 1.82 | 41.31 | 1.08 | 51.86 | 1528 |
| 138 | 1.71 | 53.48 | 1.39 | 58.23 | 1503 | 200 | 1.87 | 36.11 | 0.94 | 48.50 | 1536 |
| 140 | 1.68 | 57.85 | 1.51 | 60.14 | 1499 | 202 | 1.79 | 43.55 | 1.14 | 53.18 | |
| 142 | 1.67 | 58.76 | 1.53 | 60.51 | 1497 | 204 | 1.79 | 43.96 | 1.15 | 53.41 | |
| 144 | 1.63 | 65.05 | 1.70 | 62.91 | 1491 | 206 | 1.77 | 46.67 | 1.22 | 54.89 | |
| 146 | 1.63 | 66.22 | 1.73 | 63.32 | 1490 | 208 | 1.86 | 37.59 | 0.98 | 49.50 | |
| 148 | 1.64 | 63.34 | 1.65 | 62.29 | 1491 | 210 | 1.85 | 38.13 | 0.99 | 49.86 | |
| 150 | 1.65 | 62.46 | 1.63 | 61.96 | 1491 | 212 | 1.87 | 36.12 | 0.94 | 48.50 | |
| 152 | 1.64 | 63.54 | 1.66 | 62.36 | 1489 | 214 | 1.88 | 35.04 | 0.91 | 47.74 | 1553 |
| 154 | 1.62 | 67.35 | 1.76 | 63.72 | 1488 | 216 | 1.85 | 38.21 | 1.00 | 49.91 | 1552 |
| 156 | 1.62 | 67.02 | 1.75 | 63.60 | 1486 | 218 | 1.86 | 37.53 | 0.98 | 49.46 | 1550 |
| 158 | 1.62 | 67.10 | 1.75 | 63.63 | 1486 | 220 | 1.86 | 36.84 | 0.96 | 48.99 | 1549 |
| 160 | 1.61 | 69.00 | 1.80 | 64.27 | 1484 | 222 | 1.85 | 37.62 | 0.98 | 49.52 | 1547 |
| 162 | 1.60 | 71.19 | 1.86 | 64.99 | 1484 | 224 | 1.86 | 37.19 | 0.97 | 49.23 | 1548 |
| 164 | 1.58 | 74.42 | 1.94 | 65.99 | 1483 | 226 | 1.86 | 37.19 | 0.97 | 49.23 | 1548 |
| 166 | 1.60 | 72.02 | 1.88 | 65.25 | 1483 | 228 | 1.86 | 37.59 | 0.98 | 49.50 | 1550 |
| 168 | 1.61 | 68.71 | 1.79 | 64.18 | 1485 | 230 | 1.86 | 36.79 | 0.96 | 48.96 | 1550 |
| 170 | 1.62 | 66.72 | 1.74 | 63.50 | 1485 | 232 | 1.85 | 37.74 | 0.98 | 49.60 | 1550 |
| 172 | 1.61 | 69.55 | 1.81 | 64.46 | 1482 | 234 | 1.87 | 36.58 | 0.95 | 48.82 | 1548 |
| 174 | 1.58 | 74.40 | 1.94 | 65.99 | 1483 | 236 | 1.86 | 37.44 | 0.98 | 49.40 | 1551 |
| 176 | 1.60 | 71.26 | 1.86 | 65.01 | 1483 | 238 | 1.86 | 37.03 | 0.97 | 49.12 | 1549 |
| 178 | 1.63 | 66.67 | 1.74 | 63.48 | 1483 | 240 | 1.87 | 36.30 | 0.95 | 48.63 | 1550 |
| 180 | 1.62 | 67.01 | 1.75 | 63.60 | 1490 | 242 | 1.91 | 33.26 | 0.87 | 46.44 | 1553 |
| 182 | 1.68 | 57.79 | 1.51 | 60.11 | 1508 | 244 | 1.88 | 34.97 | 0.91 | 47.69 | 1550 |

HM 60

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.87 | 35.83 | 0.93 | 48.30 | 1554 |
| 248 | 1.86 | 36.74 | 0.96 | 48.93 | 1552 |
| 250 | 1.84 | 38.82 | 1.01 | 50.30 | 1552 |
| 252 | 1.85 | 37.62 | 0.98 | 49.52 | 1553 |
| 254 | 1.86 | 36.96 | 0.96 | 49.08 | 1553 |
| 256 | 1.86 | 37.12 | 0.97 | 49.18 | 1550 |
| 258 | 1.86 | 37.31 | 0.97 | 49.31 | 1550 |
| 260 | 1.85 | 37.76 | 0.98 | 49.61 | 1549 |
| 262 | 1.86 | 37.15 | 0.97 | 49.21 | 1549 |
| 264 | 1.85 | 37.86 | 0.99 | 49.68 | 1548 |
| 266 | 1.86 | 36.76 | 0.96 | 48.94 | 1550 |
| 268 | 1.83 | 39.94 | 1.04 | 51.02 | 1550 |
| 270 | 1.86 | 37.08 | 0.97 | 49.16 | 1547 |
| 272 | 1.87 | 36.26 | 0.95 | 48.60 | 1551 |
| 274 | 1.87 | 36.59 | 0.95 | 48.82 | 1551 |
| 276 | 1.85 | 37.63 | 0.98 | 49.52 | 1552 |
| 278 | 1.87 | 36.35 | 0.95 | 48.66 | 1549 |
| 280 | 1.87 | 36.52 | 0.95 | 48.78 | 1548 |
| 282 | 1.88 | 35.65 | 0.93 | 48.17 | 1549 |
| 284 | 1.86 | 37.38 | 0.97 | 49.36 | 1548 |
| 286 | 1.86 | 36.87 | 0.96 | 49.02 | 1552 |
| 288 | 1.86 | 37.06 | 0.97 | 49.14 | 1555 |
| 290 | 1.89 | 34.51 | 0.90 | 47.36 | 1554 |
| 292 | 1.78 | 44.74 | 1.17 | 53.85 | |
| 294 | 1.83 | 39.52 | 1.03 | 50.75 | |
| 296 | 1.88 | 35.69 | 0.93 | 48.20 | |

HM 63

HM 63

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 62 | 1.59 | 72.90 | 1.90 | 65.53 | 1490 |
| 2 | | | | | | 64 | 1.60 | 70.94 | 1.85 | 64.91 | 1491 |
| 4 | | | | | | 66 | 1.61 | 69.06 | 1.80 | 64.29 | 1493 |
| 6 | | | | | | 68 | 1.60 | 71.86 | 1.87 | 65.20 | 1496 |
| 8 | 1.74 | 49.99 | 1.30 | 56.59 | 1535 | 70 | 1.60 | 71.19 | 1.86 | 64.99 | 1491 |
| 10 | 1.74 | 50.19 | 1.31 | 56.69 | 1520 | 72 | 1.60 | 71.03 | 1.85 | 64.94 | 1494 |
| 12 | 1.72 | 52.09 | 1.36 | 57.60 | 1510 | 74 | 1.63 | 65.76 | 1.71 | 63.16 | 1497 |
| 14 | 1.69 | 56.78 | 1.48 | 59.69 | 1505 | 76 | 1.67 | 59.16 | 1.54 | 60.67 | 1505 |
| 16 | 1.68 | 57.28 | 1.49 | 59.89 | 1501 | 78 | 1.70 | 55.28 | 1.44 | 59.04 | 1509 |
| 18 | 1.67 | 59.99 | 1.56 | 61.00 | 1498 | 80 | 1.75 | 48.80 | 1.27 | 55.99 | 1519 |
| 20 | 1.65 | 62.81 | 1.64 | 62.09 | 1496 | 82 | 1.71 | 53.40 | 1.39 | 58.20 | 1511 |
| 22 | 1.63 | 65.10 | 1.70 | 62.93 | 1495 | 84 | 1.70 | 55.27 | 1.44 | 59.03 | 1507 |
| 24 | 1.58 | 75.01 | 1.96 | 66.17 | 1495 | 86 | 1.71 | 53.76 | 1.40 | 58.36 | 1502 |
| 26 | 1.59 | 73.77 | 1.92 | 65.80 | 1493 | 88 | 1.68 | 58.32 | 1.52 | 60.33 | 1496 |
| 28 | 1.61 | 70.04 | 1.83 | 64.62 | 1495 | 90 | 1.65 | 62.92 | 1.64 | 62.13 | 1492 |
| 30 | 1.61 | 68.99 | 1.80 | 64.27 | 1499 | 92 | 1.66 | 60.89 | 1.59 | 61.35 | 1493 |
| 32 | 1.61 | 68.56 | 1.79 | 64.13 | 1498 | 94 | 1.59 | 72.50 | 1.89 | 65.40 | |
| 34 | 1.61 | 70.14 | 1.83 | 64.65 | 1496 | 96 | 1.58 | 75.75 | 1.98 | 66.39 | |
| 36 | 1.61 | 69.42 | 1.81 | 64.41 | 1495 | 98 | | | | | 1509 |
| 38 | 1.61 | 69.14 | 1.80 | 64.32 | 1492 | 100 | | | | | 1507 |
| 40 | 1.61 | 69.68 | 1.82 | 64.50 | 1492 | 102 | | | | | |
| 42 | 1.60 | 70.96 | 1.85 | 64.91 | 1490 | 104 | | | | | |
| 44 | 1.58 | 75.36 | 1.97 | 66.27 | 1490 | 106 | 1.51 | 92.56 | 2.41 | 70.70 | |
| 46 | 1.57 | 76.80 | 2.00 | 66.70 | 1488 | 108 | 1.56 | 79.02 | 2.06 | 67.32 | 1487 |
| 48 | 1.57 | 78.31 | 2.04 | 67.13 | 1487 | 110 | 1.57 | 76.50 | 1.99 | 66.61 | 1485 |
| 50 | 1.56 | 78.58 | 2.05 | 67.20 | 1488 | 112 | 1.58 | 75.60 | 1.97 | 66.34 | 1484 |
| 52 | 1.58 | 74.64 | 1.95 | 66.06 | 1488 | 114 | 1.57 | 77.38 | 2.02 | 66.86 | 1484 |
| 54 | 1.58 | 75.30 | 1.96 | 66.26 | 1489 | 116 | 1.56 | 79.69 | 2.08 | 67.51 | 1483 |
| 56 | 1.62 | 67.36 | 1.76 | 63.72 | 1497 | 118 | 1.59 | 72.36 | 1.89 | 65.36 | 1486 |
| 58 | 1.60 | 71.86 | 1.87 | 65.20 | 1493 | 120 | 1.66 | 60.34 | 1.57 | 61.14 | 1501 |
| 60 | 1.61 | 69.38 | 1.81 | 64.40 | 1492 | 122 | 1.79 | 43.96 | 1.15 | 53.41 | 1537 |
| | | | | | | 124 | 1.79 | 44.54 | 1.16 | 53.74 | 1547 |

HM 63

HM 63

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 126 | 1.78 | 45.26 | 1.18 | 54.13 | 1553 | 190 | 1.98 | 27.42 | 0.71 | 41.69 | 1598 |
| 128 | 1.77 | 45.82 | 1.19 | 54.44 | 1551 | 192 | 1.93 | 31.52 | 0.82 | 45.11 | 1582 |
| 130 | 1.75 | 48.63 | 1.27 | 55.91 | 1546 | 194 | 1.85 | 38.43 | 1.00 | 50.05 | |
| 132 | 1.85 | 37.75 | 0.98 | 49.61 | 1564 | 196 | 1.82 | 40.82 | 1.06 | 51.56 | |
| 134 | 1.78 | 44.63 | 1.16 | 53.78 | 1550 | 198 | 1.91 | 32.85 | 0.86 | 46.13 | |
| 136 | 1.87 | 36.25 | 0.95 | 48.59 | 1568 | 200 | | | | | |
| 138 | 1.83 | 39.78 | 1.04 | 50.91 | 1561 | 202 | | | | | |
| 140 | 1.82 | 40.59 | 1.06 | 51.42 | 1553 | 204 | 1.87 | 36.66 | 0.96 | 48.87 | |
| 142 | 1.89 | 34.77 | 0.91 | 47.55 | 1571 | 206 | 1.83 | 39.60 | 1.03 | 50.80 | |
| 144 | 1.94 | 30.62 | 0.80 | 44.40 | 1580 | 208 | 1.92 | 32.03 | 0.84 | 45.51 | 1559 |
| 146 | 1.94 | 30.33 | 0.79 | 44.16 | 1583 | 210 | 1.89 | 34.36 | 0.90 | 47.25 | 1568 |
| 148 | 1.90 | 33.66 | 0.88 | 46.74 | 1578 | 212 | 1.95 | 29.98 | 0.78 | 43.87 | 1563 |
| 150 | 1.93 | 31.03 | 0.81 | 44.72 | 1579 | 214 | 1.92 | 32.05 | 0.84 | 45.52 | 1563 |
| 152 | 1.93 | 31.56 | 0.82 | 45.14 | 1582 | 216 | 1.90 | 33.31 | 0.87 | 46.48 | 1563 |
| 154 | 1.89 | 34.43 | 0.90 | 47.30 | 1578 | 218 | 1.92 | 31.96 | 0.83 | 45.45 | 1560 |
| 156 | 1.64 | 64.03 | 1.67 | 62.54 | 1505 | 220 | 1.89 | 34.87 | 0.91 | 47.62 | 1561 |
| 158 | 1.73 | 51.25 | 1.34 | 57.20 | 1520 | 222 | 1.93 | 31.44 | 0.82 | 45.05 | 1562 |
| 160 | 1.84 | 38.96 | 1.02 | 50.39 | 1546 | 224 | 1.93 | 31.15 | 0.81 | 44.82 | 1560 |
| 162 | 1.83 | 39.62 | 1.03 | 50.81 | 1540 | 226 | 1.91 | 32.64 | 0.85 | 45.97 | 1562 |
| 164 | 1.80 | 42.54 | 1.11 | 52.59 | 1542 | 228 | 1.95 | 30.05 | 0.78 | 43.93 | 1565 |
| 166 | 1.93 | 31.14 | 0.81 | 44.81 | 1571 | 230 | 1.91 | 33.17 | 0.86 | 46.37 | 1568 |
| 168 | 1.99 | 26.72 | 0.70 | 41.06 | 1601 | 232 | 1.89 | 34.83 | 0.91 | 47.59 | 1567 |
| 170 | 1.96 | 29.39 | 0.77 | 43.39 | 1593 | 234 | 1.90 | 33.81 | 0.88 | 46.85 | 1561 |
| 172 | 1.95 | 30.00 | 0.78 | 43.89 | 1585 | 236 | 1.89 | 34.23 | 0.89 | 47.16 | 1563 |
| 174 | 1.96 | 28.82 | 0.75 | 42.90 | 1597 | 238 | 1.91 | 32.69 | 0.85 | 46.01 | 1563 |
| 176 | 1.98 | 27.72 | 0.72 | 41.95 | 1586 | 240 | 1.91 | 32.92 | 0.86 | 46.19 | 1567 |
| 178 | 1.98 | 27.55 | 0.72 | 41.80 | 1590 | 242 | 1.91 | 33.28 | 0.87 | 46.46 | 1570 |
| 180 | 1.99 | 27.26 | 0.71 | 41.55 | 1596 | 244 | 1.94 | 30.71 | 0.80 | 44.47 | 1569 |
| 182 | 1.99 | 27.25 | 0.71 | 41.54 | 1592 | 246 | 1.93 | 31.27 | 0.82 | 44.92 | 1574 |
| 184 | 1.99 | 27.20 | 0.71 | 41.49 | 1599 | 248 | 1.79 | 43.63 | 1.14 | 53.22 | |
| 186 | 1.99 | 27.29 | 0.71 | 41.58 | 1602 | 250 | 1.83 | 39.62 | 1.03 | 50.81 | 1536 |
| 188 | 1.98 | 27.80 | 0.72 | 42.03 | 1592 | 252 | 1.89 | 34.88 | 0.91 | 47.63 | 1579 |

HM 64

HM 64

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.71 | 54.31 | 1.42 | 58.61 | 1498 |
| 2 | 1.84 | 39.23 | 1.02 | 50.57 | | 62 | 1.68 | 57.72 | 1.50 | 60.08 | 1497 |
| 4 | 1.83 | 39.95 | 1.04 | 51.02 | | 64 | 1.71 | 53.26 | 1.39 | 58.14 | 1506 |
| 6 | 1.83 | 40.02 | 1.04 | 51.06 | | 66 | 1.69 | 55.79 | 1.45 | 59.26 | 1499 |
| 8 | 1.91 | 33.01 | 0.86 | 46.26 | 1568 | 68 | 1.69 | 56.57 | 1.48 | 59.60 | 1500 |
| 10 | 1.89 | 34.52 | 0.90 | 47.37 | 1550 | 70 | 1.72 | 52.41 | 1.37 | 57.74 | 1504 |
| 12 | 1.89 | 34.39 | 0.90 | 47.28 | 1563 | 72 | 1.71 | 53.79 | 1.40 | 58.38 | 1504 |
| 14 | 1.92 | 31.85 | 0.83 | 45.37 | 1574 | 74 | 1.76 | 47.51 | 1.24 | 55.33 | 1520 |
| 16 | 1.98 | 28.01 | 0.73 | 42.20 | 1550 | 76 | 1.83 | 40.08 | 1.05 | 51.10 | 1540 |
| 18 | 1.89 | 34.30 | 0.89 | 47.21 | 1568 | 78 | 1.86 | 37.43 | 0.98 | 49.39 | 1548 |
| 20 | 1.95 | 30.12 | 0.79 | 43.99 | 1595 | 80 | 1.86 | 36.97 | 0.96 | 49.08 | 1547 |
| 22 | 1.86 | 36.72 | 0.96 | 48.91 | 1552 | 82 | 1.91 | 32.56 | 0.85 | 45.92 | 1566 |
| 24 | 1.84 | 39.38 | 1.03 | 50.66 | 1550 | 84 | 1.89 | 34.83 | 0.91 | 47.59 | 1562 |
| 26 | 1.85 | 38.33 | 1.00 | 49.99 | 1552 | 86 | 1.89 | 34.28 | 0.89 | 47.19 | 1565 |
| 28 | 1.93 | 31.38 | 0.82 | 45.00 | 1571 | 88 | 1.95 | 29.71 | 0.77 | 43.65 | 1579 |
| 30 | 1.91 | 32.53 | 0.85 | 45.90 | 1565 | 90 | 1.86 | 36.93 | 0.96 | 49.06 | 1573 |
| 32 | 1.80 | 42.54 | 1.11 | 52.59 | 1535 | 92 | 1.85 | 38.25 | 1.00 | 49.94 | 1547 |
| 34 | 1.76 | 46.96 | 1.22 | 55.04 | 1519 | 94 | 1.92 | 32.23 | 0.84 | 45.67 | 1568 |
| 36 | 1.70 | 55.23 | 1.44 | 59.02 | | 96 | 1.91 | 32.55 | 0.85 | 45.91 | 1566 |
| 38 | 1.76 | 47.75 | 1.25 | 55.46 | 1546 | 98 | 1.95 | 29.65 | 0.77 | 43.60 | 1575 |
| 40 | 1.79 | 44.27 | 1.15 | 53.58 | 1553 | 100 | 1.90 | 33.32 | 0.87 | 46.49 | 1571 |
| 42 | | | | | | 102 | 1.95 | 29.90 | 0.78 | 43.81 | 1590 |
| 44 | 1.68 | 57.70 | 1.50 | 60.07 | | 104 | 1.89 | 34.36 | 0.90 | 47.26 | 1584 |
| 46 | 1.72 | 52.77 | 1.38 | 57.91 | | 106 | 1.89 | 34.57 | 0.90 | 47.41 | 1567 |
| 48 | 1.76 | 48.00 | 1.25 | 55.59 | | 108 | 1.93 | 31.61 | 0.82 | 45.18 | 1587 |
| 50 | 1.67 | 59.86 | 1.56 | 60.95 | 1489 | 110 | 1.95 | 29.64 | 0.77 | 43.59 | 1584 |
| 52 | 1.66 | 60.28 | 1.57 | 61.12 | 1498 | 112 | 1.94 | 30.49 | 0.79 | 44.29 | 1594 |
| 54 | 1.69 | 57.11 | 1.49 | 59.82 | 1497 | 114 | 1.94 | 30.52 | 0.80 | 44.31 | 1588 |
| 56 | 1.69 | 57.04 | 1.49 | 59.79 | 1498 | 116 | 1.94 | 30.65 | 0.80 | 44.42 | 1593 |
| 58 | 1.68 | 57.32 | 1.49 | 59.91 | 1496 | 118 | 1.96 | 28.84 | 0.75 | 42.92 | 1585 |
| | | | | | | 120 | 1.95 | 29.55 | 0.77 | 43.52 | 1582 |

HM 64

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.95 | 29.72 | 0.77 | 43.66 | 1586 |
| 124 | 1.95 | 29.94 | 0.78 | 43.84 | 1590 |
| 126 | 1.95 | 29.96 | 0.78 | 43.86 | 1586 |
| 128 | 1.96 | 29.21 | 0.76 | 43.23 | 1587 |
| 130 | 1.96 | 29.16 | 0.76 | 43.20 | 1595 |
| 132 | 2.00 | 26.01 | 0.68 | 40.41 | 1581 |
| 134 | 1.88 | 35.20 | 0.92 | 47.86 | |
| 136 | 1.86 | 37.18 | 0.97 | 49.22 | |
| 138 | 1.90 | 33.87 | 0.88 | 46.90 | |

Hm 65

Hm 65

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.91 | 32.76 | 0.85 | 46.07 | 1566 |
| 2 | | | | | | 62 | 1.93 | 31.62 | 0.82 | 45.19 | 1576 |
| 4 | | | | | | 64 | 1.94 | 30.78 | 0.80 | 44.52 | 1576 |
| 6 | | | | | | 66 | 1.89 | 34.31 | 0.89 | 47.22 | 1570 |
| 8 | | | | | | 68 | 1.78 | 45.15 | 1.18 | 54.07 | 1532 |
| 10 | | | | | | 70 | 1.95 | 29.85 | 0.78 | 43.76 | 1588 |
| 12 | | | | | | 72 | 1.88 | 35.04 | 0.91 | 47.74 | 1562 |
| 14 | | | | | | 74 | 1.78 | 45.21 | 1.18 | 54.10 | 1529 |
| 16 | 1.96 | 28.78 | 0.75 | 42.87 | 1539 | 76 | 1.94 | 30.48 | 0.79 | 44.28 | 1589 |
| 18 | 1.98 | 27.94 | 0.73 | 42.15 | 1614 | 78 | 1.87 | 36.53 | 0.95 | 48.79 | 1558 |
| 20 | 1.95 | 29.53 | 0.77 | 43.50 | 1595 | 80 | 1.82 | 41.26 | 1.08 | 51.83 | 1544 |
| 22 | 1.97 | 28.71 | 0.75 | 42.81 | 1602 | 82 | 1.86 | 37.38 | 0.97 | 49.36 | 1541 |
| 24 | 1.97 | 28.59 | 0.75 | 42.71 | 1580 | 84 | 1.87 | 36.12 | 0.94 | 48.50 | 1557 |
| 26 | 1.89 | 34.18 | 0.89 | 47.13 | 1588 | 86 | 1.96 | 29.26 | 0.76 | 43.28 | 1587 |
| 28 | 1.79 | 44.26 | 1.15 | 53.58 | 1572 | 88 | 1.93 | 31.11 | 0.81 | 44.79 | 1582 |
| 30 | 1.90 | 34.06 | 0.89 | 47.03 | 1556 | 90 | 1.94 | 30.36 | 0.79 | 44.19 | 1586 |
| 32 | 1.86 | 36.90 | 0.96 | 49.03 | 1564 | 92 | 1.96 | 29.34 | 0.77 | 43.35 | 1587 |
| 34 | 1.90 | 33.52 | 0.87 | 46.64 | 1573 | 94 | 1.87 | 36.06 | 0.94 | 48.46 | |
| 36 | 1.88 | 35.59 | 0.93 | 48.13 | 1571 | 96 | 1.91 | 33.11 | 0.86 | 46.33 | 1513 |
| 38 | 1.89 | 34.74 | 0.91 | 47.53 | 1573 | 98 | 1.94 | 30.44 | 0.79 | 44.25 | 1537 |
| 40 | 1.91 | 33.17 | 0.87 | 46.38 | 1575 | 100 | | | | | |
| 42 | 1.91 | 32.81 | 0.86 | 46.10 | 1571 | 102 | 1.94 | 30.47 | 0.79 | 44.27 | |
| 44 | 1.91 | 32.59 | 0.85 | 45.94 | 1577 | 104 | 1.89 | 34.48 | 0.90 | 47.34 | |
| 46 | 1.92 | 32.28 | 0.84 | 45.70 | 1573 | 106 | 1.85 | 37.83 | 0.99 | 49.66 | |
| 48 | 1.91 | 32.56 | 0.85 | 45.92 | 1575 | 108 | 1.94 | 30.44 | 0.79 | 44.25 | 1536 |
| 50 | 1.92 | 32.30 | 0.84 | 45.72 | 1575 | 110 | 1.98 | 27.79 | 0.72 | 42.02 | 1529 |
| 52 | 1.92 | 32.13 | 0.84 | 45.59 | 1580 | 112 | 1.94 | 30.52 | 0.80 | 44.31 | 1584 |
| 54 | 1.94 | 30.47 | 0.79 | 44.27 | 1583 | 114 | 1.98 | 27.98 | 0.73 | 42.19 | 1592 |
| 56 | 1.94 | 30.76 | 0.80 | 44.50 | 1583 | 116 | 1.98 | 27.78 | 0.72 | 42.01 | 1597 |
| 58 | 1.91 | 33.09 | 0.86 | 46.31 | 1577 | 118 | 1.97 | 28.30 | 0.74 | 42.46 | 1587 |
| | 1.90 | 34.07 | 0.89 | 47.05 | 1566 | 120 | 1.97 | 28.61 | 0.75 | 42.72 | 1587 |

Hm 65

Hm 65

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.98 | 27.36 | 0.71 | 41.64 | 1596 | 184 | 1.97 | 28.17 | 0.73 | 42.34 | 1593 |
| 124 | 1.96 | 28.94 | 0.75 | 43.01 | 1594 | 186 | 1.97 | 28.03 | 0.73 | 42.23 | 1592 |
| 126 | 1.98 | 27.38 | 0.71 | 41.66 | 1599 | 188 | 1.89 | 34.38 | 0.90 | 47.27 | 1590 |
| 128 | 2.00 | 26.65 | 0.69 | 41.00 | 1602 | 190 | 1.94 | 30.90 | 0.81 | 44.62 | |
| 130 | 1.86 | 37.48 | 0.98 | 49.43 | 1586 | 192 | 1.87 | 36.58 | 0.95 | 48.82 | |
| 132 | 1.92 | 32.04 | 0.84 | 45.51 | | 194 | 1.98 | 27.47 | 0.72 | 41.73 | |
| 134 | 1.94 | 30.43 | 0.79 | 44.24 | 1579 | 196 | 1.89 | 34.35 | 0.90 | 47.25 | |
| 136 | 1.89 | 34.41 | 0.90 | 47.29 | 1559 | | | | | | |
| 138 | 1.95 | 29.56 | 0.77 | 43.53 | 1591 | | | | | | |
| 140 | 1.97 | 28.08 | 0.73 | 42.27 | 1593 | | | | | | |
| 142 | 1.96 | 29.01 | 0.76 | 43.07 | 1593 | | | | | | |
| 144 | 1.95 | 29.80 | 0.78 | 43.73 | 1594 | | | | | | |
| 146 | 1.99 | 27.16 | 0.71 | 41.46 | 1598 | | | | | | |
| 148 | 2.00 | 26.37 | 0.69 | 40.74 | 1604 | | | | | | |
| 150 | 1.82 | 41.21 | 1.07 | 51.80 | 1604 | | | | | | |
| 152 | 1.92 | 31.75 | 0.83 | 45.29 | 1536 | | | | | | |
| 154 | 2.01 | 25.42 | 0.66 | 39.86 | 1608 | | | | | | |
| 156 | 1.86 | 37.57 | 0.98 | 49.49 | 1545 | | | | | | |
| 158 | 1.91 | 33.04 | 0.86 | 46.28 | 1574 | | | | | | |
| 160 | 1.93 | 31.66 | 0.83 | 45.22 | 1570 | | | | | | |
| 162 | 1.97 | 28.38 | 0.74 | 42.53 | | | | | | | |
| 164 | 1.96 | 29.41 | 0.77 | 43.40 | 1583 | | | | | | |
| 166 | 1.95 | 30.17 | 0.79 | 44.03 | 1586 | | | | | | |
| 168 | 1.95 | 29.78 | 0.78 | 43.71 | 1587 | | | | | | |
| 170 | 1.97 | 28.56 | 0.74 | 42.68 | 1588 | | | | | | |
| 172 | 1.94 | 30.75 | 0.80 | 44.50 | 1588 | | | | | | |
| 174 | 1.96 | 29.07 | 0.76 | 43.12 | 1592 | | | | | | |
| 176 | 1.99 | 26.79 | 0.70 | 41.12 | 1592 | | | | | | |
| 178 | 1.96 | 28.89 | 0.75 | 42.96 | 1591 | | | | | | |
| 180 | 1.98 | 27.46 | 0.72 | 41.72 | 1595 | | | | | | |
| 182 | 1.97 | 28.33 | 0.74 | 42.49 | 1596 | | | | | | |

Hm 68

Hm 68

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.57 | 77.93 | 2.03 | 67.02 | 1497 |
| 2 | | | | | | 62 | 1.54 | 84.85 | 2.21 | 68.87 | 1492 |
| 4 | | | | | | 64 | 1.52 | 89.04 | 2.32 | 69.90 | 1492 |
| 6 | | | | | | 66 | 1.52 | 88.65 | 2.31 | 69.80 | 1494 |
| 8 | | | | | | 68 | 1.54 | 84.01 | 2.19 | 68.66 | 1494 |
| 10 | | | | | | 70 | 1.53 | 86.33 | 2.25 | 69.24 | 1494 |
| 12 | | | | | | 72 | 1.52 | 88.78 | 2.31 | 69.83 | 1492 |
| 14 | | | | | | 74 | 1.53 | 85.27 | 2.22 | 68.98 | 1491 |
| 16 | | | | | | 76 | 1.57 | 77.96 | 2.03 | 67.03 | 1493 |
| 18 | 1.54 | 84.45 | 2.20 | 68.77 | | 78 | 1.55 | 82.69 | 2.16 | 68.31 | 1493 |
| 20 | 1.58 | 74.50 | 1.94 | 66.02 | | 80 | 1.54 | 83.50 | 2.18 | 68.52 | 1492 |
| 22 | 1.62 | 67.28 | 1.75 | 63.69 | | 82 | 1.57 | 77.38 | 2.02 | 66.86 | 1494 |
| 24 | 1.71 | 54.08 | 1.41 | 58.51 | | 84 | 1.56 | 78.82 | 2.06 | 67.27 | 1494 |
| 26 | 1.66 | 60.96 | 1.59 | 61.38 | | 86 | 1.56 | 78.60 | 2.05 | 67.21 | 1493 |
| 28 | 1.69 | 56.45 | 1.47 | 59.54 | | 88 | 1.57 | 77.57 | 2.02 | 66.92 | 1495 |
| 30 | 1.69 | 56.35 | 1.47 | 59.50 | | 90 | 1.54 | 85.16 | 2.22 | 68.95 | 1494 |
| 32 | 1.69 | 56.76 | 1.48 | 59.68 | | 92 | 1.57 | 77.83 | 2.03 | 66.99 | 1493 |
| 34 | 1.64 | 63.51 | 1.66 | 62.35 | 1511 | 94 | 1.57 | 76.43 | 1.99 | 66.59 | 1497 |
| 36 | 1.65 | 63.28 | 1.65 | 62.26 | 1509 | 96 | 1.53 | 86.17 | 2.25 | 69.20 | 1518 |
| 38 | 1.66 | 61.17 | 1.59 | 61.46 | 1507 | 98 | 1.60 | 71.38 | 1.86 | 65.05 | 1527 |
| 40 | 1.64 | 64.51 | 1.68 | 62.72 | 1508 | 100 | 1.58 | 74.80 | 1.95 | 66.10 | |
| 42 | 1.65 | 62.52 | 1.63 | 61.98 | 1505 | 102 | | | | | |
| 44 | 1.64 | 64.41 | 1.68 | 62.68 | 1506 | 104 | | | | | |
| 46 | 1.61 | 69.87 | 1.82 | 64.56 | 1500 | 106 | | | | | |
| 48 | 1.56 | 78.61 | 2.05 | 67.21 | 1499 | 108 | 1.59 | 73.61 | 1.92 | 65.74 | |
| 50 | 1.57 | 77.88 | 2.03 | 67.00 | 1498 | 110 | 1.58 | 74.84 | 1.95 | 66.12 | 1504 |
| 52 | 1.59 | 72.61 | 1.89 | 65.44 | 1497 | 112 | 1.56 | 78.64 | 2.05 | 67.22 | 1495 |
| 54 | 1.58 | 75.17 | 1.96 | 66.22 | 1499 | 114 | 1.56 | 80.45 | 2.10 | 67.72 | 1494 |
| 56 | 1.56 | 78.83 | 2.06 | 67.27 | 1494 | 116 | 1.56 | 79.16 | 2.06 | 67.36 | 1492 |
| 58 | 1.55 | 82.26 | 2.14 | 68.20 | 1496 | 118 | 1.56 | 78.46 | 2.05 | 67.17 | 1494 |
| | | | | | | 120 | 1.56 | 80.28 | 2.09 | 67.67 | 1493 |

Hm 68

Hm 68

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------|---------------------------------------|-------------------|------------|--------------|----------|-------------------|---------------------------------------|-------------------|------------|--------------|----------|
| 122 | 1.55 | 82.71 | 2.16 | 68.32 | 1490 | 184 | 1.59 | 72.90 | 1.90 | 65.53 | 1493 |
| 124 | 1.55 | 82.24 | 2.14 | 68.20 | 1489 | 186 | 1.60 | 70.96 | 1.85 | 64.91 | 1494 |
| 126 | 1.55 | 80.96 | 2.11 | 67.86 | 1493 | 188 | 1.57 | 76.67 | 2.00 | 66.66 | 1491 |
| 128 | 1.57 | 78.01 | 2.03 | 67.04 | 1491 | 190 | 1.57 | 78.11 | 2.04 | 67.07 | 1491 |
| 130 | 1.56 | 79.93 | 2.08 | 67.58 | 1495 | 192 | 1.59 | 72.38 | 1.89 | 65.37 | 1492 |
| 132 | 1.55 | 80.93 | 2.11 | 67.85 | 1495 | 194 | 1.62 | 68.11 | 1.78 | 63.98 | 1496 |
| 134 | 1.57 | 78.21 | 2.04 | 67.10 | 1498 | 196 | 1.59 | 74.11 | 1.93 | 65.90 | |
| 136 | 1.58 | 75.23 | 1.96 | 66.23 | 1497 | 198 | 1.65 | 62.87 | 1.64 | 62.11 | |
| 138 | 1.62 | 68.30 | 1.78 | 64.04 | 1499 | 200 | 1.69 | 56.47 | 1.47 | 59.55 | |
| 140 | 1.58 | 74.49 | 1.94 | 66.01 | 1500 | 202 | | | | | |
| 142 | 1.65 | 62.83 | 1.64 | 62.10 | 1509 | 204 | | | | | |
| 144 | 1.64 | 64.08 | 1.67 | 62.56 | 1507 | 206 | | | | | |
| 146 | 1.61 | 69.57 | 1.81 | 64.46 | 1502 | 208 | 1.64 | 64.10 | 1.67 | 62.56 | |
| 148 | 1.60 | 72.05 | 1.88 | 65.26 | 1499 | 210 | 1.68 | 57.62 | 1.50 | 60.04 | |
| 150 | 1.59 | 73.10 | 1.91 | 65.59 | 1496 | 212 | 1.66 | 61.24 | 1.60 | 61.49 | |
| 152 | 1.58 | 75.72 | 1.97 | 66.38 | 1495 | 214 | 1.65 | 62.62 | 1.63 | 62.02 | |
| 154 | 1.60 | 71.04 | 1.85 | 64.94 | 1498 | 216 | 1.66 | 60.81 | 1.59 | 61.32 | |
| 156 | 1.62 | 68.35 | 1.78 | 64.06 | 1500 | 218 | 1.65 | 61.94 | 1.61 | 61.76 | |
| 158 | 1.62 | 68.17 | 1.78 | 63.99 | 1500 | 220 | 1.66 | 61.28 | 1.60 | 61.51 | |
| 160 | 1.61 | 69.33 | 1.81 | 64.38 | 1501 | 222 | 1.71 | 54.16 | 1.41 | 58.54 | |
| 162 | 1.62 | 67.29 | 1.75 | 63.70 | 1503 | 224 | 1.76 | 47.82 | 1.25 | 55.49 | |
| 164 | 1.64 | 63.85 | 1.66 | 62.48 | 1503 | 226 | 1.71 | 53.35 | 1.39 | 58.18 | |
| 166 | 1.67 | 58.85 | 1.53 | 60.55 | 1509 | 228 | 1.72 | 52.52 | 1.37 | 57.79 | |
| 168 | 1.66 | 60.97 | 1.59 | 61.38 | 1506 | 230 | 1.70 | 55.39 | 1.44 | 59.09 | |
| 170 | 1.66 | 60.69 | 1.58 | 61.28 | 1512 | 232 | 1.71 | 54.26 | 1.41 | 58.59 | |
| 172 | 1.60 | 70.72 | 1.84 | 64.84 | 1501 | 234 | 1.72 | 52.36 | 1.37 | 57.72 | |
| 174 | 1.61 | 68.91 | 1.80 | 64.25 | 1502 | 236 | 1.70 | 54.58 | 1.42 | 58.73 | |
| 176 | 1.60 | 71.48 | 1.86 | 65.08 | 1496 | 238 | 1.71 | 54.31 | 1.42 | 58.61 | 1502 |
| 178 | 1.61 | 69.69 | 1.82 | 64.50 | 1500 | 240 | 1.75 | 48.59 | 1.27 | 55.89 | |
| 180 | 1.61 | 69.59 | 1.81 | 64.47 | 1498 | 242 | 1.68 | 57.58 | 1.50 | 60.02 | 1495 |
| 182 | 1.57 | 78.12 | 2.04 | 67.07 | 1492 | 244 | 1.66 | 60.20 | 1.57 | 61.09 | 1496 |

Hm 68

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.66 | 60.48 | 1.58 | 61.20 | 1495 |
| 248 | 1.65 | 62.02 | 1.62 | 61.79 | 1493 |
| 250 | 1.67 | 58.98 | 1.54 | 60.60 | 1496 |
| 252 | 1.67 | 58.67 | 1.53 | 60.47 | 1498 |
| 254 | 1.72 | 52.48 | 1.37 | 57.78 | 1507 |
| 256 | 1.71 | 53.05 | 1.38 | 58.04 | 1507 |
| 258 | 1.70 | 54.58 | 1.42 | 58.73 | 1504 |
| 260 | 1.67 | 59.80 | 1.56 | 60.93 | 1500 |
| 262 | 1.67 | 59.63 | 1.55 | 60.86 | 1499 |
| 264 | 1.69 | 56.25 | 1.47 | 59.46 | 1500 |
| 266 | 1.68 | 58.47 | 1.52 | 60.39 | 1502 |
| 268 | 1.64 | 63.37 | 1.65 | 62.30 | 1497 |
| 270 | 1.64 | 64.57 | 1.68 | 62.74 | 1494 |
| 272 | 1.63 | 65.32 | 1.70 | 63.00 | 1497 |
| 274 | 1.72 | 52.53 | 1.37 | 57.80 | |
| 276 | 1.66 | 61.16 | 1.59 | 61.46 | 1498 |
| 278 | 1.67 | 59.32 | 1.55 | 60.73 | 1501 |
| 280 | 1.65 | 61.71 | 1.61 | 61.67 | 1502 |
| 282 | 1.66 | 60.76 | 1.58 | 61.30 | 1501 |
| 284 | 1.68 | 57.95 | 1.51 | 60.17 | 1504 |
| 286 | 1.68 | 58.20 | 1.52 | 60.28 | 1506 |

Hm 69

Hm 69

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.58 | 75.67 | 1.97 | 66.36 | 1496 |
| 2 | | | | | | 62 | 1.56 | 80.14 | 2.09 | 67.63 | 1492 |
| 4 | | | | | | 64 | 1.58 | 74.18 | 1.93 | 65.92 | 1495 |
| 6 | 1.60 | 71.96 | 1.88 | 65.23 | | 66 | 1.54 | 84.83 | 2.21 | 68.87 | 1492 |
| 8 | 1.65 | 62.16 | 1.62 | 61.84 | 1519 | 68 | 1.52 | 89.01 | 2.32 | 69.89 | 1491 |
| 10 | 1.57 | 77.36 | 2.02 | 66.85 | 1508 | 70 | 1.56 | 80.21 | 2.09 | 67.65 | 1492 |
| 12 | 1.56 | 78.93 | 2.06 | 67.30 | 1504 | 72 | 1.54 | 82.82 | 2.16 | 68.35 | 1490 |
| 14 | 1.55 | 81.37 | 2.12 | 67.97 | 1503 | 74 | 1.54 | 84.71 | 2.21 | 68.83 | 1489 |
| 16 | 1.57 | 76.75 | 2.00 | 66.68 | 1506 | 76 | 1.53 | 87.58 | 2.28 | 69.54 | 1490 |
| 18 | 1.55 | 81.30 | 2.12 | 67.95 | 1501 | 78 | 1.57 | 77.34 | 2.02 | 66.85 | 1492 |
| 20 | 1.57 | 77.87 | 2.03 | 67.00 | 1504 | 80 | 1.54 | 84.96 | 2.22 | 68.90 | 1493 |
| 22 | 1.58 | 75.79 | 1.98 | 66.40 | 1502 | 82 | 1.53 | 86.86 | 2.26 | 69.37 | 1493 |
| 24 | 1.54 | 82.86 | 2.16 | 68.36 | 1497 | 84 | 1.59 | 72.99 | 1.90 | 65.55 | 1499 |
| 26 | 1.55 | 80.75 | 2.11 | 67.80 | 1499 | 86 | 1.60 | 71.00 | 1.85 | 64.93 | 1499 |
| 28 | 1.52 | 87.81 | 2.29 | 69.60 | 1497 | 88 | 1.62 | 67.62 | 1.76 | 63.81 | 1501 |
| 30 | 1.52 | 88.46 | 2.31 | 69.76 | 1497 | 90 | 1.65 | 61.71 | 1.61 | 61.67 | 1509 |
| 32 | 1.53 | 86.91 | 2.27 | 69.38 | 1497 | 92 | 1.65 | 62.45 | 1.63 | 61.95 | 1513 |
| 34 | 1.55 | 81.18 | 2.12 | 67.91 | 1497 | 94 | 1.61 | 70.07 | 1.83 | 64.63 | |
| 36 | 1.55 | 81.85 | 2.13 | 68.09 | 1498 | 96 | 1.63 | 65.31 | 1.70 | 63.00 | 1536 |
| 38 | 1.55 | 81.71 | 2.13 | 68.06 | 1496 | 98 | 1.65 | 62.21 | 1.62 | 61.86 | 1528 |
| 40 | 1.56 | 79.48 | 2.07 | 67.45 | 1495 | 100 | | | | | |
| 42 | 1.56 | 79.76 | 2.08 | 67.53 | 1496 | 102 | | | | | |
| 44 | 1.57 | 76.27 | 1.99 | 66.54 | 1498 | 104 | | | | | |
| 46 | 1.56 | 80.46 | 2.10 | 67.72 | 1496 | 106 | | | | | |
| 48 | 1.57 | 77.27 | 2.01 | 66.83 | 1497 | 108 | 1.64 | 64.51 | 1.68 | 62.71 | |
| 50 | 1.57 | 78.03 | 2.03 | 67.05 | 1498 | 110 | 1.67 | 59.79 | 1.56 | 60.92 | |
| 52 | 1.57 | 77.47 | 2.02 | 66.89 | 1498 | 112 | 1.71 | 53.23 | 1.39 | 58.12 | |
| 54 | 1.58 | 75.52 | 1.97 | 66.32 | 1496 | 114 | 1.74 | 50.31 | 1.31 | 56.74 | 1529 |
| 56 | 1.59 | 73.22 | 1.91 | 65.63 | 1497 | 116 | 1.71 | 53.90 | 1.41 | 58.43 | 1526 |
| 58 | 1.56 | 78.47 | 2.05 | 67.17 | 1496 | 118 | 1.69 | 56.66 | 1.48 | 59.63 | 1524 |
| | | | | | | 120 | 1.67 | 58.96 | 1.54 | 60.59 | 1520 |

Hm 69

Hm 69

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.64 | 63.84 | 1.66 | 62.47 | 1504 | 184 | 1.66 | 61.14 | 1.59 | 61.45 | 1502 |
| 124 | 1.63 | 66.32 | 1.73 | 63.36 | 1501 | 186 | 1.68 | 57.78 | 1.51 | 60.11 | 1508 |
| 126 | 1.62 | 67.89 | 1.77 | 63.90 | 1497 | 188 | 1.70 | 54.86 | 1.43 | 58.85 | 1509 |
| 128 | 1.61 | 69.47 | 1.81 | 64.43 | 1494 | 190 | 1.69 | 55.87 | 1.46 | 59.30 | 1510 |
| 130 | 1.63 | 65.92 | 1.72 | 63.22 | 1494 | 192 | 1.70 | 54.86 | 1.43 | 58.86 | 1508 |
| 132 | 1.60 | 71.78 | 1.87 | 65.18 | 1490 | 194 | 1.70 | 55.44 | 1.45 | 59.11 | 1510 |
| 134 | 1.60 | 70.81 | 1.85 | 64.87 | 1492 | 196 | 1.61 | 68.67 | 1.79 | 64.16 | 1511 |
| 136 | 1.59 | 72.42 | 1.89 | 65.38 | 1493 | 198 | 1.66 | 61.45 | 1.60 | 61.57 | 1522 |
| 138 | 1.60 | 70.36 | 1.83 | 64.72 | 1495 | 200 | 1.62 | 67.76 | 1.77 | 63.86 | |
| 140 | 1.63 | 66.60 | 1.74 | 63.46 | 1497 | 202 | | | | | |
| 142 | 1.64 | 64.38 | 1.68 | 62.67 | 1496 | 204 | | | | | |
| 144 | 1.66 | 61.46 | 1.60 | 61.58 | 1497 | 206 | | | | | |
| 146 | 1.70 | 55.06 | 1.44 | 58.95 | 1509 | 208 | 1.62 | 66.82 | 1.74 | 63.53 | |
| 148 | 1.75 | 49.04 | 1.28 | 56.11 | 1514 | 210 | 1.63 | 66.60 | 1.74 | 63.46 | |
| 150 | 1.69 | 56.11 | 1.46 | 59.40 | 1513 | 212 | 1.61 | 69.43 | 1.81 | 64.42 | |
| 152 | 1.67 | 58.90 | 1.54 | 60.56 | 1508 | 214 | 1.65 | 62.53 | 1.63 | 61.98 | |
| 154 | 1.66 | 61.66 | 1.61 | 61.65 | 1502 | 216 | 1.65 | 62.36 | 1.63 | 61.92 | |
| 156 | 1.68 | 58.57 | 1.53 | 60.43 | 1507 | 218 | 1.65 | 62.77 | 1.64 | 62.07 | |
| 158 | 1.72 | 52.50 | 1.37 | 57.79 | 1516 | 220 | 1.64 | 64.02 | 1.67 | 62.54 | |
| 160 | 1.70 | 55.27 | 1.44 | 59.03 | 1512 | 222 | 1.66 | 61.62 | 1.61 | 61.64 | |
| 162 | 1.70 | 55.33 | 1.44 | 59.06 | 1507 | 224 | 1.65 | 61.89 | 1.61 | 61.74 | |
| 164 | 1.70 | 55.37 | 1.44 | 59.08 | 1507 | 226 | 1.65 | 62.63 | 1.63 | 62.02 | |
| 166 | 1.66 | 60.26 | 1.57 | 61.11 | 1500 | 228 | 1.73 | 51.50 | 1.34 | 57.32 | |
| 168 | 1.67 | 59.00 | 1.54 | 60.60 | 1501 | 230 | 1.69 | 55.99 | 1.46 | 59.35 | |
| 170 | 1.67 | 59.43 | 1.55 | 60.78 | 1504 | 232 | 1.73 | 50.53 | 1.32 | 56.85 | |
| 172 | 1.69 | 56.46 | 1.47 | 59.55 | 1505 | 234 | 1.72 | 52.21 | 1.36 | 57.65 | |
| 174 | 1.71 | 54.28 | 1.42 | 58.60 | 1506 | 236 | 1.71 | 53.70 | 1.40 | 58.34 | |
| 176 | 1.66 | 60.72 | 1.58 | 61.29 | 1499 | 238 | 1.72 | 52.90 | 1.38 | 57.97 | 1520 |
| 178 | 1.67 | 59.72 | 1.56 | 60.89 | 1499 | 240 | 1.74 | 50.35 | 1.31 | 56.76 | 1517 |
| 180 | 1.65 | 62.75 | 1.64 | 62.07 | 1498 | 242 | 1.73 | 51.52 | 1.34 | 57.32 | 1518 |
| 182 | 1.66 | 60.27 | 1.57 | 61.11 | 1498 | 244 | 1.75 | 49.02 | 1.28 | 56.10 | 1521 |

Hm 69

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.72 | 52.06 | 1.36 | 57.58 | 1520 |
| 248 | 1.75 | 48.10 | 1.25 | 55.64 | 1513 |
| 250 | 1.69 | 56.73 | 1.48 | 59.67 | 1508 |
| 252 | 1.71 | 53.19 | 1.39 | 58.10 | 1509 |
| 254 | 1.72 | 52.83 | 1.38 | 57.94 | 1513 |
| 256 | 1.73 | 51.23 | 1.34 | 57.19 | 1515 |
| 258 | 1.74 | 50.43 | 1.31 | 56.80 | 1510 |
| 260 | 1.75 | 48.86 | 1.27 | 56.02 | 1510 |
| 262 | 1.74 | 50.04 | 1.30 | 56.61 | 1510 |
| 264 | 1.73 | 51.40 | 1.34 | 57.27 | 1510 |
| 266 | 1.73 | 50.78 | 1.32 | 56.97 | 1509 |
| 268 | 1.73 | 51.56 | 1.34 | 57.34 | 1504 |
| 270 | 1.72 | 52.98 | 1.38 | 58.01 | 1504 |
| 272 | 1.73 | 50.73 | 1.32 | 56.95 | 1511 |
| 274 | 1.70 | 55.50 | 1.45 | 59.14 | 1501 |
| 276 | 1.69 | 56.06 | 1.46 | 59.38 | 1502 |
| 278 | 1.70 | 55.09 | 1.44 | 58.96 | 1504 |
| 280 | 1.68 | 57.77 | 1.51 | 60.10 | 1503 |
| 282 | 1.67 | 58.79 | 1.53 | 60.52 | 1500 |
| 284 | 1.71 | 53.86 | 1.40 | 58.41 | 1504 |
| 286 | 1.71 | 53.97 | 1.41 | 58.46 | 1509 |
| 288 | 1.72 | 52.25 | 1.36 | 57.67 | 1509 |
| 290 | 1.72 | 52.42 | 1.37 | 57.75 | 1508 |
| 292 | 1.72 | 51.79 | 1.35 | 57.45 | 1511 |
| 294 | 1.67 | 59.25 | 1.54 | 60.70 | |
| 296 | 1.58 | 75.43 | 1.97 | 66.29 | |
| 298 | 1.65 | 61.87 | 1.61 | 61.73 | |

HM 72

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | |
| 2 | | | | | |
| 4 | | | | | |
| 6 | | | | | |
| 8 | | | | | |
| 10 | | | | | 1486 |
| 12 | 1.70 | 54.92 | 1.43 | 58.88 | 1496 |
| 14 | 1.58 | 74.77 | 1.95 | 66.10 | 1498 |
| 16 | 1.70 | 54.69 | 1.43 | 58.78 | 1516 |
| 18 | 1.69 | 56.67 | 1.48 | 59.64 | 1478 |
| 20 | 1.72 | 52.03 | 1.36 | 57.56 | 1480 |
| 22 | 1.71 | 53.18 | 1.39 | 58.10 | 1491 |
| 24 | 1.69 | 55.81 | 1.46 | 59.27 | 1477 |
| 26 | 1.75 | 48.10 | 1.25 | 55.64 | 1532 |
| 28 | 1.74 | 49.42 | 1.29 | 56.31 | 1529 |
| 30 | 1.73 | 51.15 | 1.33 | 57.15 | 1522 |
| 32 | 1.72 | 51.99 | 1.36 | 57.55 | |
| 34 | 1.75 | 48.86 | 1.27 | 56.03 | 1479 |
| 36 | 1.80 | 42.51 | 1.11 | 52.57 | 1537 |
| 38 | | | | | |
| 40 | | | | | |
| 42 | | | | | |
| 44 | | | | | |
| 46 | | | | | |
| 48 | | | | | |
| 50 | | | | | 1499 |
| 52 | 1.69 | 57.04 | 1.49 | 59.79 | 1503 |
| 54 | 1.69 | 57.10 | 1.49 | 59.82 | 1509 |
| 56 | 1.66 | 61.59 | 1.61 | 61.62 | 1518 |
| 58 | 1.72 | 51.84 | 1.35 | 57.48 | 1516 |

HM 72

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 60 | 1.69 | 56.93 | 1.48 | 59.75 | 1521 |
| 62 | 1.69 | 56.76 | 1.48 | 59.68 | 1514 |
| 64 | 1.74 | 50.30 | 1.31 | 56.74 | 1519 |
| 66 | 1.70 | 55.21 | 1.44 | 59.01 | 1473 |
| 68 | 1.70 | 54.52 | 1.42 | 58.70 | 1482 |
| 70 | 1.67 | 58.93 | 1.54 | 60.58 | 1488 |
| 72 | 1.61 | 69.64 | 1.82 | 64.49 | 1486 |
| 74 | 1.53 | 85.37 | 2.23 | 69.00 | 1478 |
| 76 | 1.70 | 55.02 | 1.43 | 58.92 | 1485 |
| 78 | 1.60 | 70.80 | 1.85 | 64.86 | 1447 |
| 80 | 1.65 | 63.17 | 1.65 | 62.22 | 1444 |
| 82 | 1.59 | 73.88 | 1.93 | 65.83 | 1455 |
| 84 | 1.66 | 60.76 | 1.58 | 61.30 | |
| 86 | 1.70 | 55.13 | 1.44 | 58.97 | |
| 88 | 1.61 | 69.35 | 1.81 | 64.39 | |
| 90 | 1.60 | 70.82 | 1.85 | 64.87 | |
| 92 | 1.63 | 66.37 | 1.73 | 63.38 | |
| 94 | 1.58 | 75.33 | 1.96 | 66.26 | |
| 96 | 1.57 | 76.65 | 2.00 | 66.65 | |
| 98 | 1.65 | 62.05 | 1.62 | 61.80 | |
| 100 | 1.59 | 72.65 | 1.89 | 65.45 | |
| 102 | 1.68 | 57.51 | 1.50 | 59.99 | |
| 104 | 1.63 | 65.03 | 1.70 | 62.90 | |
| 106 | 1.60 | 70.95 | 1.85 | 64.91 | |
| 108 | 1.67 | 59.98 | 1.56 | 61.00 | 1441 |
| 110 | 1.85 | 37.76 | 0.98 | 49.61 | |

HM 73

HM 73

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.86 | 36.80 | 0.96 | 48.97 | |
| 2 | | | | | | 62 | 1.93 | 31.65 | 0.83 | 45.21 | 1614 |
| 4 | | | | | | 64 | 1.90 | 33.38 | 0.87 | 46.53 | 1621 |
| 6 | | | | | | | | | | | |
| 8 | | | | | | | | | | | |
| 10 | | | | | | | | | | | |
| 12 | 1.65 | 62.84 | 1.64 | 62.10 | | | | | | | |
| 14 | 1.75 | 48.20 | 1.26 | 55.69 | 1573 | | | | | | |
| 16 | 1.77 | 46.27 | 1.21 | 54.68 | 1590 | | | | | | |
| 18 | 1.69 | 56.90 | 1.48 | 59.73 | 1500 | | | | | | |
| 20 | 1.70 | 55.09 | 1.44 | 58.96 | 1502 | | | | | | |
| 22 | 1.69 | 57.02 | 1.49 | 59.79 | 1501 | | | | | | |
| 24 | 1.72 | 52.75 | 1.38 | 57.90 | 1502 | | | | | | |
| 26 | 1.78 | 44.65 | 1.16 | 53.80 | 1572 | | | | | | |
| 28 | 1.76 | 47.08 | 1.23 | 55.11 | 1577 | | | | | | |
| 30 | 1.88 | 35.04 | 0.91 | 47.74 | 1525 | | | | | | |
| 32 | 1.81 | 41.68 | 1.09 | 52.08 | 1522 | | | | | | |
| 34 | 1.76 | 46.87 | 1.22 | 55.00 | 1514 | | | | | | |
| 36 | 1.76 | 47.67 | 1.24 | 55.42 | 1513 | | | | | | |
| 38 | 1.78 | 45.14 | 1.18 | 54.07 | 1525 | | | | | | |
| 40 | 1.74 | 49.48 | 1.29 | 56.34 | 1522 | | | | | | |
| 42 | 1.80 | 42.92 | 1.12 | 52.81 | 1534 | | | | | | |
| 44 | 1.85 | 37.84 | 0.99 | 49.67 | 1542 | | | | | | |
| 46 | 1.87 | 36.10 | 0.94 | 48.49 | 1556 | | | | | | |
| 48 | 1.89 | 34.29 | 0.89 | 47.21 | 1557 | | | | | | |
| 50 | 1.92 | 32.28 | 0.84 | 45.70 | 1567 | | | | | | |
| 52 | 1.94 | 30.71 | 0.80 | 44.47 | 1571 | | | | | | |
| 54 | 1.93 | 31.55 | 0.82 | 45.13 | 1569 | | | | | | |
| 56 | 1.96 | 29.40 | 0.77 | 43.40 | 1572 | | | | | | |
| 58 | 1.98 | 27.44 | 0.72 | 41.71 | 1579 | | | | | | |

HM 74

HM 74

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.86 | 36.94 | 0.96 | 49.06 | 1550 |
| 2 | | | | | | 62 | 1.84 | 39.43 | 1.03 | 50.69 | 1554 |
| 4 | | | | | | 64 | 1.87 | 36.64 | 0.96 | 48.86 | 1561 |
| 6 | 1.52 | 88.55 | 2.31 | 69.78 | | 66 | 1.88 | 35.45 | 0.92 | 48.03 | 1564 |
| 8 | 1.76 | 46.89 | 1.22 | 55.01 | 1520 | 68 | 1.87 | 36.01 | 0.94 | 48.43 | 1552 |
| 10 | 1.74 | 49.45 | 1.29 | 56.32 | 1518 | 70 | 1.82 | 40.98 | 1.07 | 51.66 | |
| 12 | 1.75 | 48.57 | 1.27 | 55.88 | 1515 | 72 | 1.89 | 34.16 | 0.89 | 47.11 | 1550 |
| 14 | 1.78 | 45.55 | 1.19 | 54.29 | 1519 | 74 | 1.86 | 37.23 | 0.97 | 49.26 | |
| 16 | 1.77 | 46.33 | 1.21 | 54.71 | 1516 | 76 | | | | | 1515 |
| 18 | 1.74 | 50.25 | 1.31 | 56.71 | 1501 | 78 | | | | | |
| 20 | 1.66 | 60.40 | 1.57 | 61.16 | 1499 | 80 | 1.74 | 49.40 | 1.29 | 56.29 | |
| 22 | 1.62 | 67.97 | 1.77 | 63.93 | 1491 | 82 | 1.83 | 40.22 | 1.05 | 51.19 | |
| 24 | 1.63 | 66.17 | 1.73 | 63.31 | 1488 | 84 | 1.90 | 34.05 | 0.89 | 47.03 | |
| 26 | 1.67 | 59.50 | 1.55 | 60.81 | 1498 | 86 | 1.93 | 31.53 | 0.82 | 45.12 | 1475 |
| 28 | 1.80 | 43.28 | 1.13 | 53.02 | 1519 | 88 | 1.94 | 30.49 | 0.80 | 44.29 | 1536 |
| 30 | 1.76 | 47.30 | 1.23 | 55.22 | 1539 | 90 | 1.94 | 30.62 | 0.80 | 44.39 | 1550 |
| 32 | 1.89 | 34.16 | 0.89 | 47.11 | 1568 | 92 | 1.90 | 33.61 | 0.88 | 46.70 | 1618 |
| 34 | 1.84 | 38.66 | 1.01 | 50.20 | 1552 | 94 | 1.92 | 32.44 | 0.85 | 45.82 | 1581 |
| 36 | 1.90 | 33.47 | 0.87 | 46.60 | 1564 | 96 | 2.04 | 24.05 | 0.63 | 38.54 | 1566 |
| 38 | 1.93 | 30.94 | 0.81 | 44.65 | 1578 | 98 | 1.87 | 36.24 | 0.94 | 48.58 | |
| 40 | 1.64 | 63.94 | 1.67 | 62.51 | 1496 | 100 | 1.86 | 36.95 | 0.96 | 49.07 | 1536 |
| 42 | 1.60 | 70.95 | 1.85 | 64.91 | 1486 | 102 | 1.86 | 36.91 | 0.96 | 49.04 | 1545 |
| 44 | 1.68 | 57.59 | 1.50 | 60.03 | 1502 | 104 | 1.82 | 40.71 | 1.06 | 51.49 | 1530 |
| 46 | 1.74 | 49.86 | 1.30 | 56.52 | 1517 | 106 | 1.85 | 37.91 | 0.99 | 49.71 | 1535 |
| 48 | 1.73 | 51.59 | 1.35 | 57.36 | 1517 | 108 | 1.86 | 37.27 | 0.97 | 49.28 | 1539 |
| 50 | 1.76 | 47.39 | 1.24 | 55.27 | 1532 | 110 | 1.85 | 38.23 | 1.00 | 49.92 | 1537 |
| 52 | 1.78 | 44.99 | 1.17 | 53.98 | 1537 | 112 | 1.82 | 40.91 | 1.07 | 51.61 | 1538 |
| 54 | 1.71 | 53.97 | 1.41 | 58.46 | 1516 | 114 | 1.83 | 40.26 | 1.05 | 51.22 | 1535 |
| 56 | 1.83 | 39.69 | 1.03 | 50.86 | 1544 | 116 | 1.83 | 39.55 | 1.03 | 50.77 | 1535 |
| 58 | 1.86 | 37.33 | 0.97 | 49.32 | 1549 | 118 | 1.94 | 30.73 | 0.80 | 44.48 | 1561 |
| | | | | | | 120 | 1.95 | 29.73 | 0.78 | 43.67 | 1571 |

HM 74

HM 74

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.90 | 34.05 | 0.89 | 47.03 | 1557 | 184 | 1.76 | 47.51 | 1.24 | 55.33 | |
| 124 | 1.85 | 37.82 | 0.99 | 49.65 | 1537 | 186 | 1.80 | 43.24 | 1.13 | 52.99 | 1487 |
| 126 | 1.91 | 32.76 | 0.85 | 46.06 | 1574 | 188 | 1.85 | 38.38 | 1.00 | 50.02 | 1525 |
| 128 | 2.00 | 26.60 | 0.69 | 40.95 | 1596 | 190 | 1.79 | 43.85 | 1.14 | 53.35 | 1516 |
| 130 | 1.88 | 35.33 | 0.92 | 47.95 | 1587 | 192 | 1.77 | 46.75 | 1.22 | 54.93 | 1507 |
| 132 | 1.61 | 69.14 | 1.80 | 64.32 | 1480 | 194 | 1.75 | 48.46 | 1.26 | 55.82 | 1498 |
| 134 | 1.79 | 44.00 | 1.15 | 53.43 | 1506 | 196 | 1.75 | 48.61 | 1.27 | 55.90 | 1494 |
| 136 | 1.90 | 33.55 | 0.87 | 46.66 | 1555 | 198 | 1.72 | 52.58 | 1.37 | 57.82 | 1493 |
| 138 | 1.76 | 47.44 | 1.24 | 55.30 | 1507 | 200 | 1.73 | 50.69 | 1.32 | 56.93 | 1494 |
| 140 | 1.73 | 50.88 | 1.33 | 57.02 | 1503 | 202 | 1.75 | 48.43 | 1.26 | 55.81 | 1497 |
| 142 | 1.68 | 57.76 | 1.51 | 60.09 | 1490 | 204 | 1.74 | 50.08 | 1.31 | 56.63 | 1497 |
| 144 | 1.72 | 52.25 | 1.36 | 57.67 | 1497 | 206 | 1.70 | 54.50 | 1.42 | 58.69 | 1494 |
| 146 | 1.69 | 56.69 | 1.48 | 59.65 | 1496 | 208 | 1.72 | 52.50 | 1.37 | 57.79 | 1496 |
| 148 | 1.72 | 52.68 | 1.37 | 57.87 | 1498 | 210 | 1.73 | 51.35 | 1.34 | 57.25 | 1498 |
| 150 | 1.73 | 51.16 | 1.33 | 57.15 | 1509 | 212 | 1.75 | 49.10 | 1.28 | 56.14 | 1497 |
| 152 | 1.71 | 53.27 | 1.39 | 58.14 | 1499 | 214 | 1.74 | 50.04 | 1.30 | 56.61 | 1497 |
| 154 | 1.69 | 56.31 | 1.47 | 59.48 | 1493 | 216 | 1.73 | 50.66 | 1.32 | 56.91 | 1495 |
| 156 | 1.70 | 54.56 | 1.42 | 58.72 | 1494 | 218 | 1.74 | 49.49 | 1.29 | 56.34 | 1498 |
| 158 | 1.68 | 57.28 | 1.49 | 59.90 | 1493 | 220 | 1.74 | 49.62 | 1.29 | 56.40 | 1497 |
| 160 | 1.68 | 57.67 | 1.50 | 60.06 | 1496 | 222 | 1.73 | 51.53 | 1.34 | 57.33 | 1501 |
| 162 | 1.71 | 53.52 | 1.40 | 58.26 | 1504 | 224 | 1.74 | 49.78 | 1.30 | 56.48 | 1503 |
| 164 | 1.78 | 45.52 | 1.19 | 54.27 | 1530 | 226 | 1.75 | 48.69 | 1.27 | 55.94 | 1504 |
| 166 | 1.77 | 46.45 | 1.21 | 54.77 | 1519 | 228 | 1.75 | 48.02 | 1.25 | 55.60 | 1513 |
| 168 | 1.76 | 47.02 | 1.23 | 55.08 | 1513 | 230 | 1.67 | 60.09 | 1.57 | 61.04 | 1505 |
| 170 | 1.75 | 48.55 | 1.27 | 55.87 | 1516 | 232 | 1.76 | 47.66 | 1.24 | 55.41 | |
| 172 | 1.71 | 54.27 | 1.42 | 58.59 | | 234 | 1.83 | 39.92 | 1.04 | 51.00 | 1517 |
| 174 | 1.71 | 53.11 | 1.38 | 58.07 | 1546 | 236 | | | | | 1497 |
| 176 | 1.78 | 44.80 | 1.17 | 53.88 | 1553 | | | | | | |
| 178 | | | | | | | | | | | |
| 180 | 1.72 | 52.26 | 1.36 | 57.67 | | | | | | | |
| 182 | 1.70 | 55.69 | 1.45 | 59.22 | | | | | | | |

HM 75

HM 75

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.68 | 57.28 | 1.49 | 59.89 | 1499 |
| 2 | | | | | | 62 | 1.64 | 64.59 | 1.68 | 62.75 | 1499 |
| 4 | | | | | | 64 | 1.66 | 61.04 | 1.59 | 61.41 | 1501 |
| 6 | | | | | | 66 | 1.71 | 53.63 | 1.40 | 58.31 | 1503 |
| 8 | | | | | | 68 | 1.70 | 55.42 | 1.45 | 59.10 | 1503 |
| 10 | | | | | | 70 | 1.65 | 62.50 | 1.63 | 61.97 | 1501 |
| 12 | | | | | | 72 | 1.61 | 69.94 | 1.82 | 64.59 | 1502 |
| 14 | | | | | | 74 | 1.60 | 70.67 | 1.84 | 64.82 | 1502 |
| 16 | | | | | 1538 | 76 | 1.56 | 78.54 | 2.05 | 67.19 | 1494 |
| 18 | 1.69 | 56.25 | 1.47 | 59.46 | 1546 | 78 | 1.57 | 76.42 | 1.99 | 66.59 | 1488 |
| 20 | 1.78 | 44.94 | 1.17 | 53.96 | 1529 | 80 | 1.59 | 72.79 | 1.90 | 65.49 | 1489 |
| 22 | 1.80 | 43.07 | 1.12 | 52.90 | 1524 | 82 | 1.62 | 67.54 | 1.76 | 63.78 | 1492 |
| 24 | 1.80 | 42.61 | 1.11 | 52.63 | 1518 | 84 | 1.67 | 59.16 | 1.54 | 60.67 | 1491 |
| 26 | 1.81 | 41.75 | 1.09 | 52.12 | 1520 | 86 | 1.77 | 46.27 | 1.21 | 54.68 | 1491 |
| 28 | 1.75 | 48.84 | 1.27 | 56.02 | 1511 | 88 | 1.74 | 50.10 | 1.31 | 56.64 | 1492 |
| 30 | 1.77 | 45.99 | 1.20 | 54.53 | 1502 | 90 | 1.73 | 51.04 | 1.33 | 57.10 | 1490 |
| 32 | 1.78 | 45.08 | 1.18 | 54.03 | 1495 | 92 | 1.73 | 51.07 | 1.33 | 57.11 | 1492 |
| 34 | 1.75 | 48.87 | 1.27 | 56.03 | 1500 | 94 | 1.74 | 49.23 | 1.28 | 56.21 | 1491 |
| 36 | 1.78 | 45.22 | 1.18 | 54.11 | 1518 | 96 | 1.73 | 51.30 | 1.34 | 57.22 | 1510 |
| 38 | 1.71 | 53.20 | 1.39 | 58.11 | 1511 | 98 | | | | | 1518 |
| 40 | 1.71 | 53.26 | 1.39 | 58.14 | 1504 | 100 | | | | | 1524 |
| 42 | 1.72 | 52.50 | 1.37 | 57.78 | 1498 | 102 | | | | | |
| 44 | 1.73 | 51.43 | 1.34 | 57.29 | 1498 | 104 | | | | | |
| 46 | 1.71 | 54.16 | 1.41 | 58.54 | 1493 | 106 | | | | | |
| 48 | 1.72 | 52.95 | 1.38 | 58.00 | 1492 | 108 | 1.61 | 68.72 | 1.79 | 64.18 | |
| 50 | 1.72 | 51.76 | 1.35 | 57.44 | 1494 | 110 | 1.61 | 70.08 | 1.83 | 64.63 | |
| 52 | 1.74 | 50.36 | 1.31 | 56.77 | 1496 | 112 | 1.67 | 59.91 | 1.56 | 60.97 | 1513 |
| 54 | 1.77 | 46.61 | 1.22 | 54.86 | 1492 | 114 | 1.64 | 64.84 | 1.69 | 62.83 | 1505 |
| 56 | 1.72 | 52.08 | 1.36 | 57.59 | 1494 | 116 | 1.67 | 59.55 | 1.55 | 60.83 | 1502 |
| 58 | 1.74 | 49.54 | 1.29 | 56.36 | 1499 | 118 | 1.71 | 53.67 | 1.40 | 58.32 | 1509 |
| | | | | | | 120 | 1.76 | 47.25 | 1.23 | 55.20 | 1526 |

HM 75

HM 75

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.84 | 39.45 | 1.03 | 50.71 | 1540 | 184 | 1.81 | 42.46 | 1.11 | 52.54 | 1526 |
| 124 | 1.77 | 45.83 | 1.19 | 54.44 | 1534 | 186 | 1.83 | 40.41 | 1.05 | 51.31 | 1526 |
| 126 | 1.78 | 44.93 | 1.17 | 53.95 | 1538 | 188 | 1.84 | 39.13 | 1.02 | 50.50 | 1532 |
| 128 | 1.79 | 43.73 | 1.14 | 53.27 | 1539 | 190 | 1.90 | 33.82 | 0.88 | 46.86 | 1548 |
| 130 | 1.79 | 44.43 | 1.16 | 53.67 | 1537 | 192 | 1.84 | 38.89 | 1.01 | 50.35 | 1535 |
| 132 | 1.75 | 48.96 | 1.28 | 56.08 | 1526 | 194 | 1.79 | 44.52 | 1.16 | 53.72 | 1516 |
| 134 | 1.73 | 50.68 | 1.32 | 56.93 | 1521 | 196 | 1.66 | 61.09 | 1.59 | 61.43 | |
| 136 | 1.78 | 45.07 | 1.18 | 54.03 | 1534 | 198 | 1.72 | 52.00 | 1.36 | 57.55 | 1496 |
| 138 | 1.74 | 49.72 | 1.30 | 56.45 | 1530 | 200 | 1.79 | 44.15 | 1.15 | 53.52 | |
| 140 | 1.69 | 56.40 | 1.47 | 59.53 | 1510 | 202 | | | | | |
| 142 | 1.65 | 61.77 | 1.61 | 61.69 | 1504 | 204 | | | | | |
| 144 | 1.66 | 60.76 | 1.58 | 61.30 | 1506 | 206 | | | | | |
| 146 | 1.73 | 50.85 | 1.33 | 57.00 | 1516 | 208 | 1.75 | 48.98 | 1.28 | 56.09 | 1446 |
| 148 | 1.79 | 44.19 | 1.15 | 53.54 | 1531 | 210 | 1.70 | 54.87 | 1.43 | 58.86 | |
| 150 | 1.80 | 43.20 | 1.13 | 52.97 | 1536 | 212 | 1.72 | 51.85 | 1.35 | 57.48 | |
| 152 | 1.78 | 45.35 | 1.18 | 54.18 | 1533 | 214 | 1.71 | 53.61 | 1.40 | 58.30 | 1453 |
| 154 | 1.75 | 48.42 | 1.26 | 55.80 | 1520 | 216 | 1.77 | 46.14 | 1.20 | 54.61 | |
| 156 | 1.76 | 47.03 | 1.23 | 55.08 | 1515 | 218 | 1.77 | 46.73 | 1.22 | 54.93 | 1453 |
| 158 | 1.72 | 52.56 | 1.37 | 57.81 | 1507 | 220 | | | | | 1525 |
| 160 | 1.73 | 50.66 | 1.32 | 56.91 | 1508 | 222 | 1.78 | 45.35 | 1.18 | 54.18 | 1523 |
| 162 | 1.76 | 48.00 | 1.25 | 55.58 | 1514 | 224 | 1.79 | 43.87 | 1.14 | 53.35 | 1528 |
| 164 | 1.69 | 56.45 | 1.47 | 59.54 | 1503 | 226 | 1.78 | 45.45 | 1.19 | 54.24 | 1526 |
| 166 | 1.71 | 53.13 | 1.39 | 58.08 | 1510 | 228 | 1.81 | 41.52 | 1.08 | 51.99 | 1536 |
| 168 | 1.74 | 49.88 | 1.30 | 56.53 | 1512 | 230 | 1.85 | 38.17 | 1.00 | 49.88 | 1540 |
| 170 | 1.73 | 51.45 | 1.34 | 57.29 | 1511 | 232 | | | | | |
| 172 | 1.72 | 52.25 | 1.36 | 57.67 | 1507 | 234 | 1.86 | 37.22 | 0.97 | 49.25 | 1548 |
| 174 | 1.74 | 49.98 | 1.30 | 56.58 | 1508 | 236 | 1.88 | 35.67 | 0.93 | 48.19 | 1552 |
| 176 | 1.74 | 49.61 | 1.29 | 56.40 | 1512 | 238 | 1.86 | 37.59 | 0.98 | 49.50 | 1554 |
| 178 | 1.76 | 47.02 | 1.23 | 55.08 | 1514 | 240 | 1.88 | 35.15 | 0.92 | 47.82 | 1555 |
| 180 | 1.78 | 44.92 | 1.17 | 53.94 | 1519 | 242 | 1.90 | 34.03 | 0.89 | 47.01 | 1560 |
| 182 | 1.80 | 43.29 | 1.13 | 53.02 | 1520 | 244 | 1.90 | 33.67 | 0.88 | 46.75 | 1561 |

HM 75

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.91 | 32.91 | 0.86 | 46.18 | 1560 |
| 248 | 1.93 | 31.57 | 0.82 | 45.15 | 1561 |
| 250 | 1.87 | 36.49 | 0.95 | 48.76 | 1557 |
| 252 | 1.89 | 34.74 | 0.91 | 47.53 | 1562 |
| 254 | 1.89 | 34.77 | 0.91 | 47.55 | 1568 |
| 256 | 1.93 | 31.48 | 0.82 | 45.08 | 1557 |
| 258 | 1.90 | 33.52 | 0.87 | 46.64 | 1559 |
| 260 | 1.91 | 33.03 | 0.86 | 46.27 | 1558 |
| 262 | 1.92 | 31.94 | 0.83 | 45.44 | 1562 |
| 264 | 1.89 | 34.14 | 0.89 | 47.10 | 1557 |
| 266 | 1.85 | 38.47 | 1.00 | 50.08 | 1548 |
| 268 | 1.88 | 35.52 | 0.93 | 48.08 | 1550 |
| 270 | 1.89 | 34.13 | 0.89 | 47.09 | 1548 |
| 272 | 1.82 | 40.53 | 1.06 | 51.38 | |

Hm 77

Hm 77

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|----------------------|--|----------------------|------------|-----------------|-------------|----------------------|--|----------------------|------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.66 | 60.54 | 1.58 | 61.22 | 1499 |
| 2 | | | | | | 62 | 1.65 | 62.06 | 1.62 | 61.80 | 1499 |
| 4 | | | | | | 64 | 1.67 | 59.29 | 1.55 | 60.72 | 1501 |
| 6 | | | | | | 66 | 1.70 | 55.16 | 1.44 | 58.99 | 1503 |
| 8 | | | | | | 68 | 1.70 | 55.08 | 1.44 | 58.95 | 1503 |
| 10 | | | | | | 70 | 1.70 | 55.51 | 1.45 | 59.14 | 1501 |
| 12 | | | | | | 72 | 1.69 | 56.05 | 1.46 | 59.37 | 1502 |
| 14 | | | | | | 74 | 1.69 | 56.32 | 1.47 | 59.49 | 1502 |
| 16 | | | | | | 76 | 1.63 | 65.14 | 1.70 | 62.94 | 1494 |
| 18 | 1.73 | 50.96 | 1.33 | 57.06 | 1538 | 78 | 1.61 | 68.65 | 1.79 | 64.16 | 1488 |
| 20 | 1.70 | 54.62 | 1.42 | 58.75 | 1546 | 80 | 1.60 | 71.10 | 1.85 | 64.96 | 1489 |
| 22 | 1.72 | 51.82 | 1.35 | 57.47 | 1529 | 82 | 1.62 | 66.96 | 1.75 | 63.58 | 1492 |
| 24 | 1.71 | 54.05 | 1.41 | 58.49 | 1518 | 84 | 1.64 | 64.31 | 1.68 | 62.64 | 1491 |
| 26 | 1.69 | 55.98 | 1.46 | 59.34 | 1520 | 86 | 1.63 | 65.80 | 1.72 | 63.18 | 1491 |
| 28 | 1.68 | 57.41 | 1.50 | 59.95 | 1511 | 88 | 1.64 | 64.30 | 1.68 | 62.64 | 1492 |
| 30 | 1.64 | 64.45 | 1.68 | 62.69 | 1502 | 90 | 1.62 | 67.13 | 1.75 | 63.64 | 1490 |
| 32 | 1.59 | 72.94 | 1.90 | 65.54 | 1495 | 92 | 1.64 | 64.52 | 1.68 | 62.72 | 1492 |
| 34 | 1.73 | 51.12 | 1.33 | 57.13 | 1500 | 94 | 1.65 | 62.26 | 1.62 | 61.88 | 1491 |
| 36 | 1.70 | 54.62 | 1.42 | 58.75 | 1518 | 96 | 1.60 | 72.04 | 1.88 | 65.26 | 1510 |
| 38 | 1.66 | 61.41 | 1.60 | 61.56 | 1511 | 98 | 1.67 | 58.92 | 1.54 | 60.57 | 1518 |
| 40 | 1.67 | 59.91 | 1.56 | 60.97 | 1504 | 100 | | | | | 1524 |
| 42 | 1.65 | 61.76 | 1.61 | 61.69 | 1498 | 102 | | | | | |
| 44 | 1.64 | 63.40 | 1.65 | 62.31 | 1498 | 104 | | | | | |
| 46 | 1.71 | 53.46 | 1.39 | 58.23 | 1493 | 106 | | | | | |
| 48 | 1.62 | 67.16 | 1.75 | 63.65 | 1492 | 108 | 1.64 | 63.43 | 1.65 | 62.32 | |
| 50 | 1.62 | 67.01 | 1.75 | 63.60 | 1494 | 110 | 1.64 | 64.24 | 1.67 | 62.62 | |
| 52 | 1.62 | 67.86 | 1.77 | 63.89 | 1496 | 112 | 1.63 | 65.22 | 1.70 | 62.97 | 1494 |
| 54 | 1.61 | 68.78 | 1.79 | 64.20 | 1492 | 114 | 1.65 | 61.84 | 1.61 | 61.72 | 1499 |
| 56 | 1.60 | 70.76 | 1.85 | 64.85 | 1494 | 116 | 1.66 | 60.29 | 1.57 | 61.12 | 1496 |
| 58 | 1.65 | 62.64 | 1.63 | 62.03 | 1499 | 118 | 1.64 | 64.53 | 1.68 | 62.72 | 1492 |
| | | | | | | 120 | 1.63 | 65.21 | 1.70 | 62.97 | 1493 |

Hm 77

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.63 | 66.26 | 1.73 | 63.34 | 1489 | 184 | 1.89 | 34.87 | 0.91 | 47.63 | 1557 |
| 124 | 1.64 | 63.46 | 1.65 | 62.33 | 1493 | 186 | 1.86 | 37.04 | 0.97 | 49.13 | 1557 |
| 126 | 1.64 | 63.76 | 1.66 | 62.44 | 1493 | 188 | 1.87 | 36.53 | 0.95 | 48.78 | 1558 |
| 128 | 1.63 | 65.36 | 1.70 | 63.02 | 1494 | 190 | 1.88 | 35.06 | 0.91 | 47.76 | 1554 |
| 130 | 1.67 | 59.79 | 1.56 | 60.92 | 1498 | 192 | 1.89 | 34.40 | 0.90 | 47.29 | 1558 |
| 132 | 1.67 | 60.01 | 1.56 | 61.01 | 1499 | 194 | 1.89 | 34.66 | 0.90 | 47.47 | 1558 |
| 134 | 1.64 | 64.18 | 1.67 | 62.60 | 1493 | 196 | 1.81 | 42.01 | 1.10 | 52.27 | |
| 136 | 1.60 | 71.74 | 1.87 | 65.16 | 1487 | 198 | 1.85 | 38.34 | 1.00 | 49.99 | 1594 |
| 138 | 1.64 | 64.72 | 1.69 | 62.79 | 1495 | 200 | 1.89 | 34.30 | 0.89 | 47.21 | 1604 |
| 140 | 1.73 | 51.11 | 1.33 | 57.13 | 1519 | 202 | 1.73 | 51.31 | 1.34 | 57.23 | |
| 142 | 1.77 | 46.55 | 1.21 | 54.83 | 1535 | 204 | 1.82 | 41.00 | 1.07 | 51.67 | |
| 144 | 1.81 | 41.48 | 1.08 | 51.96 | 1554 | 206 | 1.79 | 43.53 | 1.14 | 53.16 | |
| 146 | | | | | 1559 | 208 | 1.88 | 35.68 | 0.93 | 48.19 | 1566 |
| 148 | | | | | 1582 | 210 | 1.90 | 33.47 | 0.87 | 46.60 | 1561 |
| 150 | | | | | 1496 | 212 | 1.89 | 34.58 | 0.90 | 47.41 | 1558 |
| 152 | | | | | 1500 | 214 | 1.89 | 34.68 | 0.90 | 47.48 | 1553 |
| 154 | 1.76 | 47.76 | 1.25 | 55.46 | 1520 | 216 | 1.90 | 33.63 | 0.88 | 46.72 | 1554 |
| 156 | 1.74 | 50.07 | 1.31 | 56.62 | 1525 | 218 | 1.89 | 34.25 | 0.89 | 47.17 | 1557 |
| 158 | 1.74 | 49.38 | 1.29 | 56.29 | 1529 | 220 | 1.90 | 33.99 | 0.89 | 46.99 | 1556 |
| 160 | 1.77 | 46.43 | 1.21 | 54.77 | 1531 | 222 | 1.88 | 35.83 | 0.93 | 48.30 | 1558 |
| 162 | 1.84 | 39.13 | 1.02 | 50.50 | | 224 | 1.91 | 32.60 | 0.85 | 45.95 | 1556 |
| 164 | 1.87 | 35.95 | 0.94 | 48.38 | 1554 | 226 | 1.89 | 34.30 | 0.89 | 47.21 | 1557 |
| 166 | 1.88 | 35.59 | 0.93 | 48.13 | 1557 | 228 | 1.90 | 33.73 | 0.88 | 46.79 | 1556 |
| 168 | 1.85 | 37.65 | 0.98 | 49.53 | 1552 | 230 | 1.89 | 34.34 | 0.90 | 47.24 | 1556 |
| 170 | 1.88 | 35.04 | 0.91 | 47.75 | 1553 | 232 | 1.95 | 29.55 | 0.77 | 43.52 | |
| 172 | 1.86 | 36.79 | 0.96 | 48.96 | 1556 | 234 | 1.89 | 34.69 | 0.90 | 47.49 | 1558 |
| 174 | 1.90 | 33.36 | 0.87 | 46.52 | 1554 | 236 | 1.90 | 33.63 | 0.88 | 46.72 | 1562 |
| 176 | 1.89 | 34.59 | 0.90 | 47.42 | 1555 | 238 | 1.97 | 28.09 | 0.73 | 42.28 | |
| 178 | 1.86 | 37.56 | 0.98 | 49.48 | 1553 | 240 | 1.91 | 32.56 | 0.85 | 45.92 | 1558 |
| 180 | 1.88 | 35.37 | 0.92 | 47.98 | 1548 | 242 | 1.90 | 33.35 | 0.87 | 46.52 | 1561 |
| 182 | 1.89 | 34.63 | 0.90 | 47.45 | 1558 | 244 | 1.91 | 33.18 | 0.87 | 46.39 | 1563 |

Hm 77

Hm 77

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.89 | 34.34 | 0.90 | 47.24 | 1562 |
| 248 | 1.91 | 33.14 | 0.86 | 46.36 | 1559 |
| 250 | 1.89 | 34.17 | 0.89 | 47.12 | 1559 |
| 252 | 1.88 | 35.20 | 0.92 | 47.86 | 1563 |
| 254 | 1.92 | 32.07 | 0.84 | 45.54 | 1562 |
| 256 | 1.89 | 34.74 | 0.91 | 47.53 | 1563 |
| 258 | 1.89 | 34.64 | 0.90 | 47.46 | 1564 |
| 260 | 1.90 | 33.85 | 0.88 | 46.88 | 1569 |
| 262 | 1.85 | 37.74 | 0.98 | 49.60 | |
| 264 | 1.81 | 41.85 | 1.09 | 52.18 | |
| 266 | 1.85 | 38.33 | 1.00 | 49.99 | |
| 268 | 1.94 | 30.51 | 0.80 | 44.31 | |

Hm 78

Hm 78

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.59 | 73.07 | 1.91 | 65.58 | 1508 |
| 2 | | | | | | 62 | 1.61 | 69.12 | 1.80 | 64.31 | 1506 |
| 4 | | | | | | 64 | 1.61 | 69.26 | 1.81 | 64.36 | 1502 |
| 6 | | | | | | 66 | 1.59 | 74.01 | 1.93 | 65.87 | 1503 |
| 8 | | | | | | 68 | 1.59 | 72.39 | 1.89 | 65.37 | 1505 |
| 10 | | | | | | 70 | 1.62 | 67.73 | 1.77 | 63.85 | 1506 |
| 12 | 1.57 | 77.30 | 2.02 | 66.84 | | 72 | 1.61 | 68.90 | 1.80 | 64.24 | 1513 |
| 14 | 1.63 | 65.44 | 1.71 | 63.05 | 1525 | 74 | 1.61 | 68.61 | 1.79 | 64.14 | 1507 |
| 16 | 1.62 | 66.93 | 1.75 | 63.57 | 1520 | 76 | 1.62 | 67.76 | 1.77 | 63.86 | 1506 |
| 18 | 1.62 | 66.83 | 1.74 | 63.54 | 1521 | 78 | 1.58 | 75.81 | 1.98 | 66.41 | 1504 |
| 20 | 1.65 | 62.42 | 1.63 | 61.94 | 1520 | 80 | 1.65 | 62.83 | 1.64 | 62.09 | 1511 |
| 22 | 1.66 | 60.60 | 1.58 | 61.24 | 1521 | 82 | 1.59 | 73.00 | 1.90 | 65.56 | 1501 |
| 24 | 1.68 | 57.23 | 1.49 | 59.88 | 1523 | 84 | 1.60 | 71.69 | 1.87 | 65.15 | 1499 |
| 26 | 1.69 | 56.34 | 1.47 | 59.50 | 1519 | 86 | 1.66 | 61.30 | 1.60 | 61.52 | 1507 |
| 28 | 1.70 | 55.24 | 1.44 | 59.02 | 1519 | 88 | 1.65 | 62.64 | 1.63 | 62.02 | 1508 |
| 30 | 1.68 | 58.42 | 1.52 | 60.37 | 1519 | 90 | 1.64 | 63.55 | 1.66 | 62.36 | 1506 |
| 32 | 1.67 | 59.57 | 1.55 | 60.83 | 1519 | 92 | 1.64 | 64.44 | 1.68 | 62.69 | 1506 |
| 34 | 1.65 | 62.28 | 1.62 | 61.89 | 1524 | 94 | 1.56 | 79.64 | 2.08 | 67.50 | |
| 36 | 1.68 | 57.59 | 1.50 | 60.02 | 1524 | 96 | 1.61 | 68.60 | 1.79 | 64.14 | 1488 |
| 38 | 1.68 | 57.38 | 1.50 | 59.94 | 1515 | 98 | | | | | |
| 40 | 1.65 | 63.00 | 1.64 | 62.16 | 1500 | 100 | | | | | |
| 42 | 1.58 | 74.83 | 1.95 | 66.12 | 1501 | 102 | | | | | |
| 44 | 1.62 | 67.71 | 1.77 | 63.84 | 1500 | 104 | | | | | |
| 46 | 1.65 | 61.73 | 1.61 | 61.68 | 1506 | 106 | 1.56 | 79.56 | 2.07 | 67.48 | |
| 48 | 1.62 | 68.04 | 1.77 | 63.95 | 1503 | 108 | 1.58 | 75.86 | 1.98 | 66.42 | |
| 50 | 1.65 | 62.50 | 1.63 | 61.97 | 1507 | 110 | 1.56 | 79.00 | 2.06 | 67.32 | 1500 |
| 52 | 1.64 | 63.70 | 1.66 | 62.42 | 1512 | 112 | 1.60 | 71.06 | 1.85 | 64.95 | 1506 |
| 54 | 1.57 | 76.98 | 2.01 | 66.75 | 1509 | 114 | 1.55 | 82.21 | 2.14 | 68.19 | 1498 |
| 56 | 1.60 | 71.79 | 1.87 | 65.18 | 1514 | 116 | 1.56 | 79.35 | 2.07 | 67.42 | 1499 |
| 58 | 1.58 | 74.69 | 1.95 | 66.07 | 1501 | 118 | 1.55 | 82.68 | 2.16 | 68.31 | 1499 |
| | | | | | | 120 | 1.55 | 81.69 | 2.13 | 68.05 | 1496 |

Hm 78

Hm 78

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.57 | 78.33 | 2.04 | 67.13 | 1492 | 184 | 1.52 | 89.28 | 2.33 | 69.95 | 1484 |
| 124 | 1.58 | 75.52 | 1.97 | 66.32 | 1497 | 186 | 1.55 | 82.62 | 2.15 | 68.30 | 1485 |
| 126 | 1.58 | 75.07 | 1.96 | 66.19 | 1491 | 188 | 1.55 | 80.90 | 2.11 | 67.84 | 1487 |
| 128 | 1.59 | 72.97 | 1.90 | 65.55 | 1497 | 190 | 1.56 | 78.66 | 2.05 | 67.22 | 1488 |
| 130 | 1.61 | 69.20 | 1.80 | 64.34 | 1502 | 192 | 1.60 | 70.78 | 1.85 | 64.86 | 1493 |
| 132 | 1.60 | 70.89 | 1.85 | 64.89 | 1505 | 194 | 1.60 | 71.33 | 1.86 | 65.03 | 1493 |
| 134 | 1.59 | 72.69 | 1.90 | 65.46 | 1497 | 196 | 1.53 | 87.35 | 2.28 | 69.49 | |
| 136 | 1.57 | 76.94 | 2.01 | 66.74 | 1504 | 198 | 1.58 | 74.85 | 1.95 | 66.12 | 1480 |
| 138 | 1.57 | 77.88 | 2.03 | 67.00 | 1501 | 200 | 1.62 | 68.13 | 1.78 | 63.98 | |
| 140 | 1.56 | 78.76 | 2.05 | 67.25 | 1493 | 202 | | | | | |
| 142 | 1.58 | 75.03 | 1.96 | 66.17 | 1497 | 204 | 1.53 | 85.45 | 2.23 | 69.02 | |
| 144 | 1.56 | 78.80 | 2.05 | 67.26 | 1493 | 206 | 1.58 | 75.35 | 1.96 | 66.27 | |
| 146 | 1.60 | 70.46 | 1.84 | 64.75 | 1494 | 208 | 1.63 | 66.24 | 1.73 | 63.33 | |
| 148 | 1.56 | 80.02 | 2.09 | 67.60 | 1495 | 210 | 1.67 | 58.83 | 1.53 | 60.53 | 1502 |
| 150 | 1.59 | 73.08 | 1.91 | 65.58 | 1496 | 212 | 1.64 | 63.82 | 1.66 | 62.46 | 1509 |
| 152 | 1.57 | 76.66 | 2.00 | 66.65 | 1493 | 214 | 1.64 | 63.91 | 1.67 | 62.49 | 1503 |
| 154 | 1.59 | 73.72 | 1.92 | 65.78 | 1494 | 216 | 1.66 | 60.34 | 1.57 | 61.14 | 1501 |
| 156 | 1.57 | 77.26 | 2.01 | 66.83 | 1490 | 218 | 1.62 | 67.35 | 1.76 | 63.72 | 1508 |
| 158 | 1.59 | 73.63 | 1.92 | 65.75 | 1491 | 220 | 1.64 | 64.60 | 1.68 | 62.75 | 1496 |
| 160 | 1.56 | 79.10 | 2.06 | 67.35 | 1490 | 222 | 1.63 | 65.17 | 1.70 | 62.95 | 1497 |
| 162 | 1.57 | 78.15 | 2.04 | 67.08 | 1486 | 224 | 1.62 | 68.20 | 1.78 | 64.01 | 1496 |
| 164 | 1.57 | 78.09 | 2.04 | 67.06 | 1489 | 226 | 1.64 | 64.84 | 1.69 | 62.84 | 1493 |
| 166 | 1.57 | 77.28 | 2.01 | 66.83 | 1488 | 228 | 1.60 | 70.59 | 1.84 | 64.80 | 1496 |
| 168 | 1.56 | 79.22 | 2.07 | 67.38 | 1487 | 230 | 1.59 | 72.31 | 1.89 | 65.34 | 1480 |
| 170 | 1.55 | 82.28 | 2.15 | 68.21 | 1484 | 232 | 1.62 | 67.68 | 1.76 | 63.83 | 1484 |
| 172 | 1.55 | 82.10 | 2.14 | 68.16 | 1486 | 234 | 1.62 | 67.64 | 1.76 | 63.82 | 1490 |
| 174 | 1.52 | 88.15 | 2.30 | 69.68 | 1486 | 236 | 1.63 | 65.03 | 1.70 | 62.90 | 1493 |
| 176 | 1.53 | 85.28 | 2.22 | 68.98 | 1486 | 238 | 1.63 | 66.51 | 1.73 | 63.42 | 1494 |
| 178 | 1.55 | 81.77 | 2.13 | 68.07 | 1485 | 240 | 1.59 | 72.85 | 1.90 | 65.51 | 1493 |
| 180 | 1.53 | 86.50 | 2.26 | 69.28 | 1486 | 242 | 1.64 | 64.82 | 1.69 | 62.83 | 1486 |
| 182 | 1.55 | 82.64 | 2.15 | 68.30 | 1486 | 244 | 1.65 | 63.07 | 1.64 | 62.19 | 1489 |

Hm 78

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.62 | 67.26 | 1.75 | 63.69 | 1486 |
| 248 | 1.62 | 68.30 | 1.78 | 64.04 | 1488 |
| 250 | 1.63 | 66.07 | 1.72 | 63.27 | 1492 |
| 252 | 1.64 | 63.75 | 1.66 | 62.44 | 1496 |
| 254 | 1.59 | 73.31 | 1.91 | 65.65 | 1486 |
| 256 | 1.58 | 75.59 | 1.97 | 66.34 | 1484 |
| 258 | 1.63 | 66.52 | 1.73 | 63.43 | 1493 |
| 260 | 1.65 | 62.87 | 1.64 | 62.11 | 1494 |
| 262 | 1.64 | 64.39 | 1.68 | 62.67 | 1489 |
| 264 | 1.63 | 65.59 | 1.71 | 63.10 | 1491 |
| 266 | 1.62 | 67.66 | 1.76 | 63.82 | 1487 |
| 268 | 1.61 | 69.99 | 1.83 | 64.60 | 1488 |
| 270 | 1.62 | 66.93 | 1.75 | 63.57 | 1488 |
| 272 | 1.63 | 65.03 | 1.70 | 62.90 | 1494 |
| 274 | 1.65 | 63.18 | 1.65 | 62.23 | 1496 |
| 276 | 1.66 | 60.24 | 1.57 | 61.10 | 1493 |
| 278 | 1.64 | 64.58 | 1.68 | 62.74 | 1491 |
| 280 | 1.64 | 64.34 | 1.68 | 62.65 | 1490 |
| 282 | 1.61 | 68.49 | 1.79 | 64.11 | 1488 |
| 284 | 1.63 | 66.10 | 1.72 | 63.28 | 1489 |
| 286 | 1.64 | 63.53 | 1.66 | 62.36 | 1491 |
| 288 | 1.64 | 63.95 | 1.67 | 62.51 | 1492 |
| 290 | 1.64 | 63.31 | 1.65 | 62.27 | 1491 |
| 292 | 1.63 | 65.39 | 1.70 | 63.03 | 1490 |
| 294 | 1.64 | 64.33 | 1.68 | 62.65 | 1490 |
| 296 | | | | | |
| 298 | 1.64 | 63.34 | 1.65 | 62.28 | 1470 |
| 300 | 1.70 | 55.57 | 1.45 | 59.17 | |

HM 80

HM 80

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.63 | 65.63 | 1.71 | 63.12 | 1504 |
| 2 | | | | | | 62 | 1.60 | 70.61 | 1.84 | 64.80 | 1502 |
| 4 | | | | | | 64 | 1.59 | 72.32 | 1.89 | 65.35 | 1498 |
| 6 | | | | | | 66 | 1.57 | 77.32 | 2.02 | 66.84 | 1497 |
| 8 | | | | | | 68 | 1.56 | 79.28 | 2.07 | 67.40 | 1496 |
| 10 | | | | | | 70 | 1.58 | 75.73 | 1.97 | 66.38 | 1497 |
| 12 | | | | | | 72 | 1.60 | 71.48 | 1.86 | 65.08 | 1502 |
| 14 | 1.61 | 68.64 | 1.79 | 64.15 | 1501 | 74 | 1.58 | 75.72 | 1.97 | 66.38 | 1497 |
| 16 | 1.63 | 65.00 | 1.69 | 62.89 | 1508 | 76 | 1.56 | 78.59 | 2.05 | 67.20 | 1493 |
| 18 | 1.63 | 65.72 | 1.71 | 63.15 | 1511 | 78 | 1.58 | 74.94 | 1.95 | 66.15 | 1497 |
| 20 | 1.64 | 64.39 | 1.68 | 62.67 | 1513 | 80 | 1.58 | 74.46 | 1.94 | 66.00 | 1497 |
| 22 | 1.67 | 58.69 | 1.53 | 60.48 | 1512 | 82 | 1.60 | 71.67 | 1.87 | 65.14 | 1494 |
| 24 | 1.68 | 57.75 | 1.51 | 60.09 | 1516 | 84 | 1.57 | 76.76 | 2.00 | 66.68 | 1495 |
| 26 | 1.71 | 53.14 | 1.39 | 58.08 | 1519 | 86 | 1.57 | 76.30 | 1.99 | 66.55 | 1494 |
| 28 | 1.68 | 57.82 | 1.51 | 60.12 | 1520 | 88 | 1.56 | 79.31 | 2.07 | 67.41 | 1494 |
| 30 | 1.68 | 57.72 | 1.50 | 60.08 | 1515 | 90 | 1.60 | 71.75 | 1.87 | 65.17 | 1496 |
| 32 | 1.66 | 60.93 | 1.59 | 61.37 | 1516 | 92 | 1.57 | 77.40 | 2.02 | 66.87 | 1496 |
| 34 | 1.64 | 63.38 | 1.65 | 62.30 | 1509 | 94 | 1.52 | 89.94 | 2.35 | 70.11 | |
| 36 | 1.63 | 65.14 | 1.70 | 62.94 | 1505 | 96 | 1.54 | 84.46 | 2.20 | 68.77 | 1518 |
| 38 | 1.63 | 65.80 | 1.72 | 63.18 | 1503 | 98 | | | | | |
| 40 | 1.65 | 62.96 | 1.64 | 62.14 | 1504 | 100 | | | | | |
| 42 | 1.61 | 69.30 | 1.81 | 64.38 | 1503 | 102 | | | | | |
| 44 | 1.61 | 70.09 | 1.83 | 64.63 | 1503 | 104 | | | | | |
| 46 | 1.62 | 67.94 | 1.77 | 63.92 | 1501 | 106 | | | | | |
| 48 | 1.61 | 68.65 | 1.79 | 64.16 | 1504 | 108 | | | | | |
| 50 | 1.62 | 68.04 | 1.77 | 63.95 | 1507 | 110 | 1.54 | 84.00 | 2.19 | 68.65 | |
| 52 | 1.61 | 69.66 | 1.82 | 64.49 | 1503 | 112 | 1.59 | 74.12 | 1.93 | 65.90 | |
| 54 | 1.56 | 80.52 | 2.10 | 67.74 | 1498 | 114 | 1.59 | 74.17 | 1.93 | 65.92 | |
| 56 | 1.57 | 76.66 | 2.00 | 66.65 | 1497 | 116 | 1.62 | 68.17 | 1.78 | 64.00 | |
| 58 | 1.59 | 72.89 | 1.90 | 65.52 | 1502 | 118 | 1.61 | 70.08 | 1.83 | 64.63 | |
| | | | | | | 120 | 1.57 | 76.88 | 2.00 | 66.72 | |

HM 80

HM 80

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.59 | 73.92 | 1.93 | 65.84 | 1481 | 184 | 1.62 | 68.02 | 1.77 | 63.94 | 1499 |
| 124 | 1.55 | 81.08 | 2.11 | 67.89 | 1481 | 186 | 1.62 | 66.79 | 1.74 | 63.53 | 1497 |
| 126 | 1.57 | 78.33 | 2.04 | 67.13 | 1487 | 188 | 1.63 | 66.68 | 1.74 | 63.49 | 1496 |
| 128 | 1.60 | 71.96 | 1.88 | 65.23 | 1499 | 190 | 1.64 | 64.77 | 1.69 | 62.81 | 1495 |
| 130 | 1.59 | 73.68 | 1.92 | 65.77 | 1494 | 192 | 1.64 | 63.46 | 1.65 | 62.33 | 1498 |
| 132 | 1.59 | 73.99 | 1.93 | 65.86 | 1496 | 194 | 1.60 | 71.09 | 1.85 | 64.96 | 1493 |
| 134 | 1.58 | 74.77 | 1.95 | 66.10 | 1494 | 196 | | | | | |
| 136 | 1.58 | 75.41 | 1.97 | 66.29 | 1492 | 198 | 1.62 | 67.21 | 1.75 | 63.67 | 1512 |
| 138 | 1.56 | 79.67 | 2.08 | 67.50 | 1490 | 200 | 1.62 | 67.72 | 1.77 | 63.84 | 1519 |
| 140 | 1.57 | 78.11 | 2.04 | 67.07 | 1488 | 202 | | | | | |
| 142 | 1.56 | 79.49 | 2.07 | 67.45 | 1491 | 204 | | | | | |
| 144 | 1.56 | 79.00 | 2.06 | 67.32 | 1491 | 206 | | | | | |
| 146 | 1.54 | 83.42 | 2.18 | 68.51 | 1488 | 208 | | | | | |
| 148 | 1.52 | 88.43 | 2.31 | 69.75 | 1487 | 210 | | | | | |
| 150 | 1.53 | 87.12 | 2.27 | 69.43 | 1487 | 212 | | | | | |
| 152 | 1.53 | 86.54 | 2.26 | 69.29 | 1487 | 214 | | | | | |
| 154 | 1.53 | 86.35 | 2.25 | 69.24 | 1487 | 216 | 1.58 | 75.23 | 1.96 | 66.23 | |
| 156 | 1.52 | 87.72 | 2.29 | 69.58 | 1487 | 218 | 1.56 | 78.64 | 2.05 | 67.22 | |
| 158 | 1.55 | 82.63 | 2.15 | 68.30 | 1487 | 220 | 1.54 | 84.67 | 2.21 | 68.83 | |
| 160 | 1.55 | 82.44 | 2.15 | 68.25 | 1489 | 222 | 1.57 | 77.49 | 2.02 | 66.89 | |
| 162 | 1.57 | 77.47 | 2.02 | 66.89 | 1489 | 224 | 1.55 | 81.38 | 2.12 | 67.97 | |
| 164 | 1.60 | 71.76 | 1.87 | 65.17 | 1491 | 226 | 1.61 | 70.01 | 1.83 | 64.61 | |
| 166 | 1.60 | 71.54 | 1.87 | 65.10 | 1492 | 228 | 1.56 | 79.40 | 2.07 | 67.43 | |
| 168 | 1.56 | 79.83 | 2.08 | 67.55 | 1489 | 230 | 1.60 | 71.31 | 1.86 | 65.03 | |
| 170 | 1.57 | 77.63 | 2.02 | 66.93 | 1489 | 232 | 1.61 | 70.29 | 1.83 | 64.70 | |
| 172 | 1.58 | 76.15 | 1.99 | 66.51 | 1489 | 234 | 1.61 | 68.48 | 1.79 | 64.10 | |
| 174 | 1.56 | 80.11 | 2.09 | 67.63 | 1488 | 236 | 1.66 | 61.56 | 1.61 | 61.61 | |
| 176 | 1.60 | 71.32 | 1.86 | 65.03 | 1492 | 238 | 1.62 | 67.41 | 1.76 | 63.74 | |
| 178 | 1.60 | 71.04 | 1.85 | 64.94 | 1497 | 240 | 1.64 | 64.85 | 1.69 | 62.84 | 1508 |
| 180 | 1.65 | 62.37 | 1.63 | 61.92 | 1499 | 242 | 1.60 | 70.87 | 1.85 | 64.89 | |
| 182 | 1.63 | 65.36 | 1.70 | 63.02 | 1497 | 244 | | | | | |

HM 80

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.56 | 78.97 | 2.06 | 67.31 | 1493 |
| 248 | 1.62 | 67.08 | 1.75 | 63.63 | 1495 |
| 250 | 1.62 | 67.25 | 1.75 | 63.68 | 1500 |
| 252 | 1.61 | 69.99 | 1.82 | 64.60 | 1498 |
| 254 | 1.64 | 64.38 | 1.68 | 62.67 | 1491 |
| 256 | 1.63 | 65.18 | 1.70 | 62.96 | 1489 |
| 258 | 1.62 | 66.94 | 1.75 | 63.57 | 1487 |
| 260 | 1.62 | 67.48 | 1.76 | 63.76 | 1486 |
| 262 | 1.60 | 71.83 | 1.87 | 65.19 | 1488 |
| 264 | 1.62 | 67.52 | 1.76 | 63.78 | 1488 |
| 266 | 1.61 | 68.65 | 1.79 | 64.16 | 1488 |
| 268 | 1.63 | 66.67 | 1.74 | 63.48 | 1488 |
| 270 | 1.60 | 70.98 | 1.85 | 64.92 | 1486 |
| 272 | 1.61 | 70.16 | 1.83 | 64.66 | 1487 |
| 274 | 1.60 | 70.43 | 1.84 | 64.74 | 1487 |
| 276 | 1.63 | 65.79 | 1.72 | 63.17 | 1488 |
| 278 | 1.59 | 72.32 | 1.89 | 65.35 | 1490 |
| 280 | 1.62 | 67.49 | 1.76 | 63.76 | 1490 |
| 282 | 1.60 | 71.88 | 1.87 | 65.21 | 1484 |
| 284 | 1.54 | 82.95 | 2.16 | 68.38 | 1487 |
| 286 | 1.60 | 71.44 | 1.86 | 65.07 | 1487 |
| 288 | 1.60 | 70.32 | 1.83 | 64.71 | 1488 |
| 290 | 1.57 | 76.87 | 2.00 | 66.71 | 1487 |
| 292 | 1.60 | 71.06 | 1.85 | 64.95 | 1487 |
| 294 | 1.59 | 73.31 | 1.91 | 65.65 | 1484 |
| 296 | 1.59 | 73.04 | 1.90 | 65.57 | |
| 298 | 1.53 | 85.61 | 2.23 | 69.06 | |

HM 81

HM 81

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.60 | 71.08 | 1.85 | 64.95 | 1483 |
| 2 | | | | | | 62 | 1.61 | 69.70 | 1.82 | 64.51 | 1487 |
| 4 | | | | | | 64 | 1.64 | 64.45 | 1.68 | 62.69 | 1490 |
| 6 | | | | | | 66 | 1.62 | 66.91 | 1.74 | 63.56 | 1489 |
| 8 | | | | | | 68 | 1.60 | 70.70 | 1.84 | 64.83 | 1487 |
| 10 | | | | | | 70 | 1.66 | 61.17 | 1.59 | 61.46 | 1488 |
| 12 | | | | | | 72 | 1.62 | 67.77 | 1.77 | 63.86 | 1487 |
| 14 | | | | | | 74 | 1.65 | 62.78 | 1.64 | 62.08 | 1490 |
| 16 | | | | | | 76 | 1.65 | 62.88 | 1.64 | 62.11 | 1491 |
| 18 | 1.66 | 60.16 | 1.57 | 61.07 | | 78 | 1.65 | 62.31 | 1.62 | 61.90 | 1491 |
| 20 | 1.68 | 57.24 | 1.49 | 59.88 | | 80 | 1.64 | 64.31 | 1.68 | 62.64 | 1490 |
| 22 | 1.66 | 61.57 | 1.61 | 61.62 | | 82 | 1.66 | 60.40 | 1.57 | 61.16 | 1498 |
| 24 | 1.66 | 60.70 | 1.58 | 61.28 | 1493 | 84 | 1.71 | 53.77 | 1.40 | 58.37 | 1515 |
| 26 | 1.62 | 67.27 | 1.75 | 63.69 | 1491 | 86 | 1.82 | 40.78 | 1.06 | 51.53 | 1551 |
| 28 | 1.64 | 64.03 | 1.67 | 62.54 | 1490 | 88 | 1.83 | 39.75 | 1.04 | 50.89 | 1561 |
| 30 | 1.60 | 71.56 | 1.87 | 65.11 | 1487 | 90 | 1.92 | 32.29 | 0.84 | 45.71 | 1580 |
| 32 | 1.59 | 72.22 | 1.88 | 65.31 | 1487 | 92 | 1.97 | 28.33 | 0.74 | 42.49 | 1589 |
| 34 | 1.61 | 70.10 | 1.83 | 64.64 | 1487 | 94 | | | | | |
| 36 | 1.60 | 70.46 | 1.84 | 64.75 | 1488 | 96 | 1.71 | 53.61 | 1.40 | 58.30 | 1572 |
| 38 | 1.60 | 70.91 | 1.85 | 64.90 | 1490 | 98 | 1.93 | 31.49 | 0.82 | 45.09 | |
| 40 | 1.65 | 62.81 | 1.64 | 62.09 | 1494 | 100 | | | | | |
| 42 | 1.66 | 60.75 | 1.58 | 61.30 | 1493 | 102 | 1.80 | 42.92 | 1.12 | 52.81 | |
| 44 | 1.59 | 73.14 | 1.91 | 65.60 | 1485 | 104 | 1.91 | 33.22 | 0.87 | 46.41 | |
| 46 | 1.57 | 76.79 | 2.00 | 66.69 | 1482 | 106 | 1.94 | 30.22 | 0.79 | 44.07 | |
| 48 | 1.58 | 75.95 | 1.98 | 66.45 | 1482 | 108 | 1.96 | 28.98 | 0.76 | 43.04 | |
| 50 | 1.59 | 73.57 | 1.92 | 65.73 | 1482 | 110 | 2.10 | 20.58 | 0.54 | 34.92 | |
| 52 | 1.58 | 74.54 | 1.94 | 66.03 | 1482 | 112 | 2.05 | 23.00 | 0.60 | 37.49 | |
| 54 | 1.60 | 70.79 | 1.85 | 64.86 | 1482 | 114 | 2.05 | 23.36 | 0.61 | 37.85 | |
| 56 | 1.63 | 65.29 | 1.70 | 63.00 | 1485 | 116 | 2.05 | 23.37 | 0.61 | 37.86 | 1466 |
| 58 | 1.62 | 67.78 | 1.77 | 63.86 | 1484 | 118 | | | | | 1526 |
| | | | | | | 120 | 1.71 | 53.41 | 1.39 | 58.20 | |

HM 81

HM 81

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.85 | 37.74 | 0.98 | 49.60 | | 184 | 1.69 | 55.76 | 1.45 | 59.25 | 1505 |
| 124 | 1.88 | 35.50 | 0.93 | 48.07 | | 186 | 1.71 | 53.89 | 1.41 | 58.42 | 1501 |
| 126 | 1.77 | 46.13 | 1.20 | 54.60 | | 188 | 1.70 | 54.85 | 1.43 | 58.85 | 1500 |
| 128 | 1.63 | 65.29 | 1.70 | 63.00 | | 190 | 1.71 | 53.23 | 1.39 | 58.12 | 1505 |
| 130 | 1.67 | 59.22 | 1.54 | 60.69 | | 192 | 1.69 | 56.22 | 1.47 | 59.45 | 1504 |
| 132 | 1.68 | 57.36 | 1.50 | 59.93 | | 194 | 1.69 | 56.94 | 1.48 | 59.75 | 1503 |
| 134 | 1.71 | 54.23 | 1.41 | 58.57 | | 196 | 1.62 | 66.71 | 1.74 | 63.50 | |
| 136 | 1.68 | 57.53 | 1.50 | 60.00 | 1492 | 198 | 1.68 | 57.48 | 1.50 | 59.98 | 1524 |
| 138 | 1.66 | 61.39 | 1.60 | 61.55 | 1494 | 200 | 1.69 | 55.81 | 1.46 | 59.27 | 1523 |
| 140 | 1.67 | 59.69 | 1.56 | 60.88 | 1491 | 202 | | | | | |
| 142 | 1.66 | 61.48 | 1.60 | 61.58 | 1490 | 204 | | | | | |
| 144 | 1.66 | 60.56 | 1.58 | 61.22 | 1489 | 206 | 1.65 | 62.18 | 1.62 | 61.85 | |
| 146 | 1.67 | 59.14 | 1.54 | 60.66 | 1491 | 208 | 1.67 | 59.12 | 1.54 | 60.65 | |
| 148 | 1.64 | 64.13 | 1.67 | 62.58 | 1491 | 210 | 1.69 | 57.14 | 1.49 | 59.84 | |
| 150 | 1.66 | 61.11 | 1.59 | 61.44 | 1493 | 212 | 1.68 | 57.79 | 1.51 | 60.11 | |
| 152 | 1.68 | 58.34 | 1.52 | 60.34 | 1496 | 214 | 1.72 | 52.55 | 1.37 | 57.81 | |
| 154 | 1.69 | 56.77 | 1.48 | 59.68 | 1502 | 216 | 1.70 | 54.94 | 1.43 | 58.89 | |
| 156 | 1.71 | 53.10 | 1.38 | 58.07 | 1504 | 218 | 1.72 | 52.71 | 1.37 | 57.88 | |
| 158 | 1.66 | 60.91 | 1.59 | 61.36 | 1494 | 220 | 1.74 | 49.42 | 1.29 | 56.30 | 1499 |
| 160 | 1.66 | 61.12 | 1.59 | 61.44 | 1489 | 222 | 1.75 | 48.95 | 1.28 | 56.07 | 1498 |
| 162 | 1.65 | 62.98 | 1.64 | 62.15 | 1490 | 224 | 1.72 | 52.01 | 1.36 | 57.56 | 1496 |
| 164 | 1.67 | 58.81 | 1.53 | 60.53 | 1491 | 226 | 1.70 | 55.21 | 1.44 | 59.01 | 1490 |
| 166 | 1.65 | 62.44 | 1.63 | 61.95 | 1490 | 228 | 1.69 | 56.35 | 1.47 | 59.50 | 1490 |
| 168 | 1.65 | 62.90 | 1.64 | 62.12 | 1489 | 230 | 1.71 | 53.51 | 1.40 | 58.25 | 1490 |
| 170 | 1.70 | 55.03 | 1.43 | 58.93 | 1497 | 232 | 1.71 | 53.04 | 1.38 | 58.04 | 1493 |
| 172 | 1.73 | 50.80 | 1.32 | 56.98 | 1504 | 234 | 1.71 | 53.96 | 1.41 | 58.45 | 1491 |
| 174 | 1.71 | 54.12 | 1.41 | 58.53 | 1505 | 236 | 1.70 | 55.37 | 1.44 | 59.08 | 1492 |
| 176 | 1.72 | 52.05 | 1.36 | 57.57 | 1506 | 238 | 1.73 | 51.44 | 1.34 | 57.29 | 1498 |
| 178 | 1.76 | 47.73 | 1.24 | 55.45 | 1513 | 240 | 1.75 | 49.02 | 1.28 | 56.10 | 1495 |
| 180 | 1.74 | 50.35 | 1.31 | 56.76 | 1517 | 242 | 1.75 | 48.57 | 1.27 | 55.88 | 1495 |
| 182 | 1.71 | 54.19 | 1.41 | 58.56 | 1509 | 244 | 1.73 | 51.56 | 1.34 | 57.35 | 1494 |

HM 81

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 246 | 1.71 | 53.78 | 1.40 | 58.37 | 1493 |
| 248 | 1.71 | 53.67 | 1.40 | 58.33 | 1492 |
| 250 | 1.71 | 54.12 | 1.41 | 58.52 | 1491 |
| 252 | 1.68 | 58.08 | 1.51 | 60.23 | 1488 |
| 254 | 1.68 | 57.90 | 1.51 | 60.16 | 1489 |
| 256 | 1.70 | 55.72 | 1.45 | 59.23 | 1490 |
| 258 | 1.68 | 58.31 | 1.52 | 60.32 | 1490 |
| 260 | 1.70 | 54.49 | 1.42 | 58.69 | 1491 |
| 262 | 1.68 | 58.42 | 1.52 | 60.37 | 1491 |
| 264 | 1.68 | 57.54 | 1.50 | 60.00 | 1492 |
| 266 | 1.71 | 53.34 | 1.39 | 58.17 | 1492 |
| 268 | 1.69 | 56.22 | 1.47 | 59.45 | 1492 |
| 270 | 1.68 | 57.17 | 1.49 | 59.85 | 1490 |
| 272 | 1.71 | 53.05 | 1.38 | 58.04 | 1491 |
| 274 | 1.68 | 58.40 | 1.52 | 60.36 | 1493 |
| 276 | 1.68 | 58.20 | 1.52 | 60.28 | 1494 |
| 278 | 1.74 | 49.51 | 1.29 | 56.35 | 1504 |
| 280 | 1.78 | 44.83 | 1.17 | 53.89 | 1520 |
| 282 | 1.82 | 41.18 | 1.07 | 51.78 | 1527 |
| 284 | 1.81 | 42.46 | 1.11 | 52.54 | 1527 |
| 286 | 1.72 | 51.76 | 1.35 | 57.44 | |
| 288 | 1.83 | 40.06 | 1.04 | 51.09 | 1553 |
| 290 | 1.81 | 41.73 | 1.09 | 52.11 | 1565 |

HM 86

HM 86

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 60 | 1.96 | 29.05 | 0.76 | 43.10 | 1561 |
| 2 | | | | | | 62 | 1.89 | 34.83 | 0.91 | 47.59 | 1564 |
| 4 | | | | | | 64 | 1.93 | 31.31 | 0.82 | 44.94 | 1566 |
| 6 | 1.78 | 44.78 | 1.17 | 53.87 | | 66 | 1.88 | 35.81 | 0.93 | 48.28 | 1568 |
| 8 | 1.80 | 42.96 | 1.12 | 52.83 | | 68 | 1.94 | 30.81 | 0.80 | 44.55 | 1575 |
| 10 | 1.83 | 39.83 | 1.04 | 50.94 | | 70 | 1.91 | 33.16 | 0.86 | 46.37 | 1566 |
| 12 | 1.77 | 46.35 | 1.21 | 54.72 | | 72 | 1.89 | 34.54 | 0.90 | 47.39 | 1564 |
| 14 | 1.79 | 44.19 | 1.15 | 53.54 | 1547 | 74 | 1.91 | 32.80 | 0.86 | 46.10 | 1565 |
| 16 | 1.83 | 40.28 | 1.05 | 51.22 | 1558 | 76 | 1.89 | 34.75 | 0.91 | 47.54 | 1568 |
| 18 | 1.87 | 36.40 | 0.95 | 48.70 | 1562 | 78 | 1.88 | 35.23 | 0.92 | 47.88 | 1567 |
| 20 | 1.84 | 38.64 | 1.01 | 50.19 | 1561 | 80 | 1.86 | 37.51 | 0.98 | 49.44 | 1565 |
| 22 | 1.84 | 39.28 | 1.02 | 50.60 | 1557 | 82 | 1.86 | 36.85 | 0.96 | 49.00 | 1560 |
| 24 | 1.87 | 36.68 | 0.96 | 48.88 | 1560 | 84 | 1.86 | 36.84 | 0.96 | 48.99 | 1560 |
| 26 | 1.85 | 37.80 | 0.99 | 49.64 | 1557 | 86 | 1.91 | 33.13 | 0.86 | 46.35 | 1560 |
| 28 | 1.87 | 36.42 | 0.95 | 48.71 | 1562 | 88 | 1.91 | 32.64 | 0.85 | 45.98 | 1576 |
| 30 | 1.84 | 38.89 | 1.01 | 50.35 | 1550 | 90 | 1.91 | 33.02 | 0.86 | 46.26 | 1577 |
| 32 | 1.83 | 39.61 | 1.03 | 50.81 | 1550 | 92 | 1.94 | 30.34 | 0.79 | 44.16 | 1589 |
| 34 | 1.87 | 36.62 | 0.95 | 48.84 | 1563 | 94 | 1.84 | 39.21 | 1.02 | 50.55 | |
| 36 | 1.84 | 39.29 | 1.02 | 50.60 | 1552 | 96 | 1.87 | 36.20 | 0.94 | 48.55 | 1552 |
| 38 | 1.84 | 38.83 | 1.01 | 50.31 | 1554 | 98 | 1.95 | 29.90 | 0.78 | 43.81 | |
| 40 | 1.86 | 37.24 | 0.97 | 49.26 | 1556 | 100 | | | | | |
| 42 | 1.85 | 38.08 | 0.99 | 49.82 | 1553 | 102 | 1.91 | 32.96 | 0.86 | 46.22 | |
| 44 | 1.85 | 38.27 | 1.00 | 49.94 | 1555 | 104 | 1.85 | 38.24 | 1.00 | 49.93 | |
| 46 | 1.87 | 36.45 | 0.95 | 48.73 | 1557 | 106 | 1.86 | 37.10 | 0.97 | 49.17 | |
| 48 | 1.86 | 36.99 | 0.96 | 49.10 | 1551 | 108 | 1.92 | 32.12 | 0.84 | 45.58 | |
| 50 | 1.85 | 38.23 | 1.00 | 49.92 | 1551 | 110 | 1.92 | 32.14 | 0.84 | 45.59 | 1531 |
| 52 | 1.89 | 34.76 | 0.91 | 47.55 | 1560 | 112 | 1.95 | 29.97 | 0.78 | 43.87 | |
| 54 | 1.87 | 36.01 | 0.94 | 48.43 | 1565 | 114 | 1.90 | 33.85 | 0.88 | 46.88 | 1569 |
| 56 | 1.89 | 34.90 | 0.91 | 47.65 | 1567 | 116 | 1.96 | 29.24 | 0.76 | 43.26 | 1575 |
| 58 | 1.87 | 35.92 | 0.94 | 48.36 | 1558 | 118 | 1.94 | 30.25 | 0.79 | 44.10 | 1580 |
| | | | | | | 120 | 1.93 | 31.09 | 0.81 | 44.77 | |

HM 86

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 122 | 1.89 | 34.22 | 0.89 | 47.16 | 1597 |
| 124 | 1.92 | 32.39 | 0.84 | 45.78 | 1581 |
| 126 | 1.91 | 33.17 | 0.86 | 46.38 | |
| 128 | 1.89 | 34.70 | 0.90 | 47.50 | 1589 |
| 130 | 1.91 | 32.71 | 0.85 | 46.03 | 1593 |
| 132 | 1.92 | 32.21 | 0.84 | 45.64 | 1588 |
| 134 | 1.84 | 39.11 | 1.02 | 50.49 | |
| 136 | 1.88 | 35.78 | 0.93 | 48.26 | 1542 |
| 138 | 1.96 | 29.18 | 0.76 | 43.21 | 1570 |
| 140 | 1.87 | 36.47 | 0.95 | 48.74 | 1555 |
| 142 | 1.88 | 34.99 | 0.91 | 47.71 | 1558 |
| 144 | 1.89 | 34.56 | 0.90 | 47.40 | 1558 |
| 146 | 1.87 | 36.63 | 0.96 | 48.85 | 1552 |
| 148 | 1.94 | 30.34 | 0.79 | 44.17 | 1587 |
| 150 | 1.98 | 27.51 | 0.72 | 41.77 | 1586 |
| 152 | 1.96 | 29.15 | 0.76 | 43.18 | 1582 |
| 154 | 1.91 | 32.80 | 0.86 | 46.10 | 1572 |
| 156 | 1.93 | 31.66 | 0.83 | 45.22 | 1569 |
| 158 | 1.92 | 31.86 | 0.83 | 45.38 | 1576 |
| 160 | 1.92 | 31.77 | 0.83 | 45.31 | 1575 |
| 162 | 1.95 | 30.19 | 0.79 | 44.04 | 1580 |
| 164 | 1.95 | 29.95 | 0.78 | 43.85 | 1584 |
| 166 | 1.93 | 31.34 | 0.82 | 44.97 | 1581 |
| 168 | 1.93 | 31.08 | 0.81 | 44.76 | 1575 |
| 170 | 1.92 | 31.91 | 0.83 | 45.41 | |
| 172 | 1.96 | 29.39 | 0.77 | 43.38 | 1585 |
| 174 | 1.94 | 30.81 | 0.80 | 44.55 | 1575 |
| 176 | 1.92 | 32.25 | 0.84 | 45.68 | 1575 |
| 178 | 1.97 | 28.31 | 0.74 | 42.47 | 1574 |
| 180 | 1.94 | 30.91 | 0.81 | 44.63 | |
| 182 | 1.92 | 32.01 | 0.83 | 45.50 | |

HM 86

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 184 | 1.92 | 32.42 | 0.85 | 45.81 | 1585 |
| 186 | 1.92 | 32.23 | 0.84 | 45.66 | 1582 |
| 188 | 1.86 | 36.74 | 0.96 | 48.93 | 1564 |
| 190 | 1.84 | 39.31 | 1.02 | 50.61 | |
| 192 | 1.79 | 43.89 | 1.14 | 53.37 | |
| 194 | 1.74 | 49.67 | 1.29 | 56.43 | |

Hm 87

Hm 87


| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 0 | | | | | | 62 | 1.79 | 44.48 | 1.16 | 53.70 | 1519 |
| 2 | | | | | | 64 | 1.80 | 43.44 | 1.13 | 53.11 | 1517 |
| 4 | | | | | | 66 | 1.78 | 45.65 | 1.19 | 54.34 | 1509 |
| 6 | | | | | | 68 | 1.71 | 53.10 | 1.38 | 58.06 | 1486 |
| 8 | | | | | | 70 | 1.72 | 52.19 | 1.36 | 57.64 | 1486 |
| 10 | | | | | | 72 | 1.71 | 53.39 | 1.39 | 58.19 | 1487 |
| 12 | | | | | | 74 | 1.70 | 54.68 | 1.43 | 58.78 | 1484 |
| 14 | | | | | | 76 | 1.70 | 55.69 | 1.45 | 59.22 | 1485 |
| 16 | 1.64 | 64.50 | 1.68 | 62.71 | 1512 | 78 | 1.71 | 53.87 | 1.40 | 58.41 | 1489 |
| 18 | 1.76 | 46.94 | 1.22 | 55.04 | 1512 | 80 | 1.73 | 50.67 | 1.32 | 56.92 | 1495 |
| 20 | 1.79 | 43.87 | 1.14 | 53.36 | 1502 | 82 | 1.74 | 50.21 | 1.31 | 56.69 | 1510 |
| 22 | 1.79 | 43.94 | 1.15 | 53.39 | 1513 | 84 | 1.76 | 47.43 | 1.24 | 55.29 | 1519 |
| 24 | 1.87 | 36.13 | 0.94 | 48.51 | 1516 | 86 | 1.79 | 43.64 | 1.14 | 53.22 | 1538 |
| 26 | 1.69 | 56.41 | 1.47 | 59.53 | 1490 | 88 | 1.85 | 38.35 | 1.00 | 50.00 | 1545 |
| 28 | 1.69 | 57.13 | 1.49 | 59.83 | 1489 | 90 | 1.76 | 47.14 | 1.23 | 55.14 | 1526 |
| 30 | 1.73 | 51.58 | 1.34 | 57.35 | 1499 | 92 | 1.65 | 62.59 | 1.63 | 62.01 | 1493 |
| 32 | 1.69 | 57.12 | 1.49 | 59.83 | 1485 | 94 | 1.65 | 62.11 | 1.62 | 61.82 | 1499 |
| 34 | 1.70 | 55.63 | 1.45 | 59.19 | 1491 | 96 | 1.66 | 61.33 | 1.60 | 61.53 | 1509 |
| 36 | 1.80 | 42.95 | 1.12 | 52.83 | 1500 | 98 | 1.79 | 44.43 | 1.16 | 53.67 | 1536 |
| 38 | 1.69 | 56.77 | 1.48 | 59.68 | 1482 | 100 | 1.69 | 56.22 | 1.47 | 59.45 | 1547 |
| 40 | 1.69 | 56.63 | 1.48 | 59.62 | 1484 | 102 | | | | | |
| 42 | 1.71 | 53.70 | 1.40 | 58.34 | 1489 | 104 | 1.49 | 98.49 | 2.57 | 71.97 | |
| 44 | 1.83 | 40.14 | 1.05 | 51.14 | 1538 | 106 | 1.62 | 68.41 | 1.78 | 64.08 | 1496 |
| 46 | 1.89 | 34.16 | 0.89 | 47.11 | 1519 | 108 | 1.73 | 51.60 | 1.35 | 57.36 | 1495 |
| 48 | 1.96 | 29.34 | 0.77 | 43.34 | 1565 | 110 | 1.71 | 53.42 | 1.39 | 58.21 | 1495 |
| 50 | 1.87 | 36.40 | 0.95 | 48.70 | 1548 | 112 | 1.69 | 55.82 | 1.46 | 59.28 | 1507 |
| 52 | 1.86 | 37.48 | 0.98 | 49.43 | 1563 | 114 | 1.72 | 52.49 | 1.37 | 57.78 | 1515 |
| 54 | 1.79 | 43.84 | 1.14 | 53.34 | 1519 | 116 | 1.69 | 56.87 | 1.48 | 59.72 | 1502 |
| 56 | 1.77 | 46.31 | 1.21 | 54.70 | 1507 | 118 | 1.79 | 44.06 | 1.15 | 53.46 | 1544 |
| 58 | 1.77 | 46.68 | 1.22 | 54.90 | 1504 | 120 | 1.91 | 32.66 | 0.85 | 45.99 | 1561 |
| 60 | 1.84 | 38.89 | 1.01 | 50.35 | 1535 | 122 | 2.04 | 23.74 | 0.62 | 38.24 | 1537 |

Hm 87


Hm 87

| Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) | Sample Depth (cm) | Wet Bulk Density (g/cm ³) | Water Content (%) | Void Ratio | Porosity (%) | Vp (m/s) |
|-------------------------|---|-------------------------|---------------|-----------------|-------------|-------------------------|---|-------------------------|---------------|-----------------|-------------|
| 124 | 1.79 | 44.49 | 1.16 | 53.71 | 1512 | 188 | 1.74 | 49.59 | 1.29 | 56.39 | 1498 |
| 126 | 1.88 | 35.56 | 0.93 | 48.11 | 1569 | 190 | 1.82 | 41.25 | 1.08 | 51.82 | 1507 |
| 128 | 1.93 | 30.95 | 0.81 | 44.66 | 1604 | 192 | 1.71 | 53.41 | 1.39 | 58.21 | 1496 |
| 130 | 1.95 | 29.77 | 0.78 | 43.70 | 1607 | 194 | 1.78 | 45.50 | 1.19 | 54.26 | 1496 |
| 132 | 1.89 | 34.48 | 0.90 | 47.34 | 1588 | 196 | 1.65 | 62.50 | 1.63 | 61.97 | |
| 134 | 2.06 | 22.43 | 0.58 | 36.90 | | 198 | 1.81 | 42.44 | 1.11 | 52.53 | |
| 136 | 2.16 | 17.25 | 0.45 | 31.02 | | 200 | | | | | 1519 |
| 138 | 2.05 | 22.92 | 0.60 | 37.41 | | 202 | | | | | |
| 140 | 1.81 | 42.18 | 1.10 | 52.37 | 1521 | 204 | | | | | |
| 142 | 1.74 | 50.37 | 1.31 | 56.77 | 1503 | 206 | 1.70 | 54.61 | 1.42 | 58.74 | |
| 144 | 1.74 | 49.75 | 1.30 | 56.47 | 1497 | 208 | 1.77 | 46.25 | 1.21 | 54.67 | 1506 |
| 146 | 1.75 | 48.04 | 1.25 | 55.61 | 1502 | 210 | 1.76 | 47.73 | 1.24 | 55.45 | 1502 |
| 148 | 1.72 | 51.92 | 1.35 | 57.52 | 1498 | 212 | 1.76 | 47.12 | 1.23 | 55.13 | 1502 |
| 150 | 1.71 | 53.50 | 1.39 | 58.24 | 1502 | 214 | 1.74 | 50.03 | 1.30 | 56.61 | 1495 |
| 152 | 1.89 | 34.35 | 0.90 | 47.24 | 1507 | 216 | 1.74 | 49.56 | 1.29 | 56.37 | 1493 |
| 154 | 1.78 | 45.04 | 1.17 | 54.01 | 1527 | 218 | 1.73 | 51.27 | 1.34 | 57.20 | 1493 |
| 156 | 1.74 | 49.79 | 1.30 | 56.49 | 1516 | 220 | 1.76 | 48.01 | 1.25 | 55.59 | 1494 |
| 158 | 1.76 | 47.65 | 1.24 | 55.41 | 1504 | 222 | 1.75 | 48.40 | 1.26 | 55.79 | 1495 |
| 160 | 1.80 | 42.51 | 1.11 | 52.57 | 1518 | 224 | 1.77 | 46.50 | 1.21 | 54.80 | 1499 |
| 162 | 1.74 | 49.60 | 1.29 | 56.40 | 1512 | 226 | 1.74 | 49.23 | 1.28 | 56.21 | 1502 |
| 164 | 1.79 | 44.41 | 1.16 | 53.66 | 1522 | 228 | 1.75 | 49.05 | 1.28 | 56.12 | 1499 |
| 166 | 1.79 | 43.81 | 1.14 | 53.32 | 1520 | 230 | 1.83 | 40.14 | 1.05 | 51.14 | 1507 |
| 168 | 1.76 | 47.57 | 1.24 | 55.36 | 1522 | 232 | 1.86 | 37.19 | 0.97 | 49.23 | 1509 |
| 170 | 1.73 | 50.44 | 1.32 | 56.81 | 1513 | 234 | 1.74 | 50.30 | 1.31 | 56.74 | 1497 |
| 172 | 1.73 | 50.98 | 1.33 | 57.07 | 1507 | 236 | 1.76 | 47.47 | 1.24 | 55.31 | 1498 |
| 174 | 1.73 | 51.47 | 1.34 | 57.30 | 1498 | 238 | 1.75 | 48.21 | 1.26 | 55.69 | 1498 |
| 176 | 1.69 | 55.93 | 1.46 | 59.32 | 1498 | 240 | 1.74 | 49.88 | 1.30 | 56.53 | 1497 |
| 178 | 1.70 | 55.01 | 1.43 | 58.92 | 1497 | 242 | 1.87 | 36.05 | 0.94 | 48.45 | 1505 |
| 180 | 1.73 | 51.08 | 1.33 | 57.12 | 1498 | 244 | 1.74 | 49.79 | 1.30 | 56.49 | 1501 |
| 182 | 1.73 | 51.59 | 1.35 | 57.36 | 1505 | 246 | 1.62 | 66.86 | 1.74 | 63.55 | |
| 184 | 1.75 | 48.81 | 1.27 | 56.00 | 1495 | 248 | | | | | 1464 |
| 186 | 1.83 | 40.40 | 1.05 | 51.30 | 1507 | | | | | | |


HM 3, TAMU GEOTEK LOGGER DATA




HM 4, TAMU GEOTEK LOGGER DATA




HM 5, TAMU GEOTEK LOGGER DATA




HM 9, TAMU GEOTEK LOGGER DATA




HM 11, TAMU GEOTEK LOGGER DATA




HM 12, TAMU GEOTEK LOGGER DATA




HM 16, TAMU GEOTEK LOGGER DATA




HM 17, TAMU GEOTEK LOGGER DATA




HM 19, TAMU GEOTEK LOGGER DATA




HM 29, TAMU GEOTEK LOGGER DATA




HM 31, TAMU GEOTEK LOGGER DATA




HM 32, TAMU GEOTEK LOGGER DATA




HM 34, TAMU GEOTEK LOGGER DATA




HM 36, TAMU GEOTEK LOGGER DATA




HM 37, TAMU GEOTEK LOGGER DATA




HM 38, TAMU GEOTEK LOGGER DATA




HM 40, TAMU GEOTEK LOGGER DATA




HM 41, TAMU GEOTEK LOGGER DATA




HM 43, TAMU GEOTEK LOGGER DATA




HM 44, TAMU GEOTEK LOGGER DATA




HM 46, TAMU GEOTEK LOGGER DATA




HM 48, TAMU GEOTEK LOGGER DATA




HM 49, TAMU GEOTEK LOGGER DATA




HM 50, TAMU GEOTEK LOGGER DATA




HM 51, TAMU GEOTEK LOGGER DATA




HM 52, TAMU GEOTEK LOGGER DATA




HM 53, TAMU GEOTEK LOGGER DATA




HM 54, TAMU GEOTEK LOGGER DATA




HM 56, TAMU GEOTEK LOGGER DATA




HM 58, TAMU GEOTEK LOGGER DATA




HM 59, TAMU GEOTEK LOGGER DATA




HM 60, TAMU GEOTEK LOGGER DATA




HM 63, TAMU GEOTEK LOGGER DATA




HM 64, TAMU GEOTEK LOGGER DATA




HM 65, TAMU GEOTEK LOGGER DATA




HM 68, TAMU GEOTEK LOGGER DATA




HM 69, TAMU GEOTEK LOGGER DATA




HM 72, TAMU GEOTEK LOGGER DATA




HM 73, TAMU GEOTEK LOGGER DATA




HM 74, TAMU GEOTEK LOGGER DATA




HM 75, TAMU GEOTEK LOGGER DATA




HM 77, TAMU GEOTEK LOGGER DATA




HM 78, TAMU GEOTEK LOGGER DATA




HM 80, TAMU GEOTEK LOGGER DATA




HM 81, TAMU GEOTEK LOGGER DATA



HM 86, TAMU GEOTEK LOGGER DATA



HM 87, TAMU GEOTEK LOGGER DATA



Appendix

```

* This program reads in logger generated PC file then calculate velocity,
  Boyce density, porosity, water content, and void ratio.
  Note: Need to "crush" the data file first.
        Need an input AL calibrated file "aluminum.par" with calibrated slope
        on the first line and intercept on the second line.
                                           Jia Y. Liu 8/7/96 */

include <stdio.h>
include <math.h>

define buffer 3000                /* store up to 3000 records */

define R_fc 1.128                  /* Boyce density parameters */
define R_g 2.65
define R_f 1.024
define R_gc 2.65

define grain_den 2.67
define water_den 1.024

void main(int argc, char *argv[]) {
FILE *ifp1,*ifp2,*ofp1,*ofp2,*ofp3,*ofp4,*ofp5;

char vel_file[20],den_file[20],porosity_file[20],void_file[20],water_file[20];
int samp_interval;
double temp,core_diameter;
float liner_thickness,p_wave_offset,p_wave,gamma_count_time;
float gamma_cycle,section_length,temperature;
int i,depth,DBS;
float velocity[buffer],density[buffer],boyce_den[buffer];
float porosity[buffer],voidratio[buffer],water[buffer];
float section_depth[buffer];
float deviation[buffer];
double travel_time[buffer];
long gamma[buffer];
double C2,C1;
double slope,intercept;
char ch;

/* Check if the input command is correct */
if (argc!=3) {
printf("\n");
printf("This program reads in PC logger file then output velocity, Boyce de
printf("porosity, void ratio, and water content files.\n\n");
printf("Note: 1. You need to \"crush\" the data file before running this pr
printf("          e.g. crush test.dat > test_new.dat\n");
printf("          2. Need an input AL calibrated file \"aluminum.par\" with slo
printf("          first line and intercept on the second line \n");
printf("                                           Jia Y. Liu 8/96\n\n");
printf("Usage: logger <input file> <length of previous sections>\n\n");
exit(1);
}

/* Make sure the input file name exists */
ifp1=fopen(argv[1],"r");
if (ifp1==NULL) {
printf("Cannot open input file \"%s\"!\n",argv[1]);
exit(1);
}

```

```

/* Make sure the slope and intercept exists */
ifp2=fopen("aluminum.par","r");
if (ifp2==NULL) {
    printf("Cannot open input parameter file \"aluminum.par\"!\n",argv[1]);
    exit(1);
}

/* Make sure the starting depth exists */
if (argv[2]==NULL) {
    printf("Need input the length of previous sections!\n");
    exit(1);
}
DBS=atoi(argv[2]);

/* Read the slope and intercept file */
fscanf(ifp2, "%lf\n",&slope);
fscanf(ifp2, "%lf\n",&intercept);

/* Read the header. Note: the delimiter is TAB */
for (i=1;i<=16;i++) {
    if (i!=2 && i!=3 && i!=4 && i!=5 && i!=8 && i!=9 && i!=12 && i!=13 && i!=16)
        while (fgetc(ifp1)!='\n') ;
    else {
        while (fgetc(ifp1)!='\t') ;
        fscanf(ifp1,"%lf\n",&temp);
        if (i==2)
            samp_interval=temp;
        if (i==3)
            core_diameter=temp;
        if (i==4)
            liner_thickness=temp;
        if (i==5)
            p_wave_offset=temp;
        if (i==8)
            gamma_count_time=temp;
        if (i==9)
            gamma_cycle=temp;
        if (i==12)
            p_wave=temp;
        if (i==13)
            section_length=temp;
        if (i==16)
            temperature=temp;
    }
}

if (p_wave!=0.) {
    strcpy(vel_file,argv[1]);
    strcat(vel_file,".vel");
    ofp1=fopen(vel_file,"w");
}

if (gamma_count_time!=0.) {
    strcpy(den_file,argv[1]);
    strcat(den_file,".den");
    ofp2=fopen(den_file,"w");
    strcpy(porosity_file,argv[1]);
    strcat(porosity_file,".por");
    ofp3=fopen(porosity_file,"w");
}

```

```

strcpy(void_file,argv[1]);
strcat(void_file,".voi");
ofp4=fopen(void_file,"w");
strcpy(water_file,argv[1]);
strcat(water_file,".wat");
ofp5=fopen(water_file,"w");
}

for (i=0;i<=(int)(section_length)+16;i++)
  fscanf(ifp1,"%f %f %lf %*f %d %*d %*d \n",&section_depth[i],&deviation[i],&tra

/* Calculate density, porosity, void ratio, and water content */
if (DBS == 0) {
  fprintf(ofp2,"Depth(cm)\tBulk density(g/cc)\n");
  fprintf(ofp3,"Depth(cm)\tPorosity (%) \n");
  fprintf(ofp4,"Depth(cm)\tVoid ratio\n");
  fprintf(ofp5,"Depth(cm)\tWater content (%) \n");
}

for (depth=1+14/samp_interval;depth<=(int)(section_length+14)/samp_interval;d
  density[depth-14/samp_interval]=(log(gamma[depth]/(gamma_count_time*gamma_c
  boyce_den[depth-14/samp_interval]=(density[depth-14/samp_interval]-R_fc)*(R
  fprintf(ofp2,"%d\t%f\n",samp_interval*(depth-14/samp_interval)+DBS,boyce_de

  porosity[depth-14/samp_interval]=(grain_den-boyce_den[depth-14/samp_interva
  fprintf(ofp3,"%d\t%f\n",samp_interval*(depth-14/samp_interval)+DBS,porosity

  voidratio[depth-14/samp_interval]=porosity[depth-14/samp_interval]/100./(1-
  fprintf(ofp4,"%d\t%f\n",samp_interval*(depth-14/samp_interval)+DBS,voidrati

  water[depth-14/samp_interval]=(water_den/grain_den)*voidratio[depth-14/samp
  fprintf(ofp5,"%d\t%f\n",samp_interval*(depth-14/samp_interval)+DBS,water[de
}

/* Calculate velocity */
if (p_wave!=0.) {
  if (DBS == 0)
    fprintf(ofp1,"Depth(cm)\tVelocity(m/sec)\n");
  for (depth=1;depth<=(int)(section_length/samp_interval);depth++) {
    velocity[depth]=(core_diameter+deviation[depth]-2.*liner_thickness)/(travel
    fprintf(ofp1,"%d\t%f\n",samp_interval*depth+DBS,velocity[depth]);
  }
}

/* Print out output file names */
printf("\n");
printf("The output velocity file is: %s.vel \n",argv[1]);
printf("The output Boyce density file is: %s.den \n",argv[1]);
printf("The output porosity file is: %s.por \n",argv[1]);
printf("The output void ratio file is: %s.voi \n",argv[1]);
printf("The output water content file is: %s.wat \n\n",argv[1]);

```